

Grizzly **Industrial, Inc.**®

MODEL T24463/T24464 **6" BENCH GRINDERS** **OWNER'S MANUAL**

(For models manufactured since 02/16)

Model T24463



For Model
T24464
Only



Model T24464



COPYRIGHT © MAY, 2012 BY GRIZZLY INDUSTRIAL, INC. REVISED MARCH, 2016 (MN)
**WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE
OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.**

#KN14983 PRINTED IN CHINA

V2.10.16



WARNING!

This manual provides critical safety instructions on the proper setup, operation, maintenance, and service of this machine/tool. Save this document, refer to it often, and use it to instruct other operators.

Failure to read, understand and follow the instructions in this manual may result in fire or serious personal injury—including amputation, electrocution, or death.

The owner of this machine/tool is solely responsible for its safe use. This responsibility includes but is not limited to proper installation in a safe environment, personnel training and usage authorization, proper inspection and maintenance, manual availability and comprehension, application of safety devices, cutting/sanding/grinding tool integrity, and the usage of personal protective equipment.

The manufacturer will not be held liable for injury or property damage from negligence, improper training, machine modifications or misuse.



WARNING!

Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

- **Lead from lead-based paints.**
- **Crystalline silica from bricks, cement and other masonry products.**
- **Arsenic and chromium from chemically-treated lumber.**

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: Work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.

Table of Contents

| | | | |
|--|-----------|-------------------------------------|-----------|
| INTRODUCTION | 2 | SECTION 4: OPERATIONS | 16 |
| Manual Accuracy | 2 | Operation Overview | 16 |
| Contact Info..... | 2 | Wheel Selection | 17 |
| Machine Description | 2 | Wheel Inspection | 18 |
| Identification | 3 | Wheel Dressing..... | 18 |
| Machine Data Sheet | 4 | Wheel Removal & Installation..... | 19 |
| SECTION 1: SAFETY | 5 | SECTION 5: ACCESSORIES | 20 |
| Safety Instructions for Machinery | 5 | SECTION 6: MAINTENANCE..... | 21 |
| Additional Safety Instructions for Grinders | 7 | Schedule | 21 |
| SECTION 2: POWER SUPPLY | 8 | Grinding Wheels | 21 |
| Availability..... | 8 | Wheel Dressing..... | 21 |
| Full-Load Current Rating | 8 | SECTION 7: SERVICE | 22 |
| Circuit Requirements | 8 | Troubleshooting | 22 |
| Grounding & Plug Requirements..... | 9 | Motor & Electrical | 22 |
| Extension Cords | 9 | SECTION 8: WIRING..... | 23 |
| SECTION 3: SETUP | 10 | Wiring Safety Instructions | 23 |
| Needed for Setup..... | 10 | T24463 Wiring..... | 24 |
| Unpacking | 10 | T24464 Wiring..... | 25 |
| Inventory | 11 | SECTION 9: PARTS | 26 |
| Model T24463 Inventory..... | 11 | T24463 Breakdown..... | 26 |
| Model T24464 Inventory..... | 11 | T24463 Parts List..... | 27 |
| Site Considerations..... | 12 | T24464 Breakdown..... | 28 |
| Weight Load | 12 | T24464 Parts List..... | 29 |
| Space Allocation..... | 12 | T24463/T24464 Labels | 30 |
| Physical Environment..... | 12 | WARRANTY & RETURNS | 33 |
| Electrical Installation..... | 12 | | |
| Lighting | 12 | | |
| Mounting | 13 | | |
| Through Mount with Rubber Feet | 13 | | |
| Through Mounting | 13 | | |
| Surface Mounting | 13 | | |
| Assembly | 14 | | |
| Spark Deflector Adjustment..... | 14 | | |
| Tool Rest Adjustment..... | 14 | | |
| Power Connection..... | 15 | | |
| Connecting Power | 15 | | |
| Disconnecting Power..... | 15 | | |
| Test Run | 15 | | |

INTRODUCTION

Contact Info

We stand behind our machines! If you have questions or need help, contact us with the information below. Before contacting, make sure you get the **serial number** and **manufacture date** from the machine ID label. This will help us help you faster.

Grizzly Technical Support
1815 W. Battlefield
Springfield, MO 65807
Phone: (570) 546-9663
Email: techsupport@grizzly.com

We want your feedback on this manual. What did you like about it? Where could it be improved? Please take a few minutes to give us feedback.

Grizzly Documentation Manager
P.O. Box 2069
Bellingham, WA 98227-2069
Email: manuals@grizzly.com

Machine Description

The Model T24463 6" Bench Grinder is a great grinder for the hobbyist or small shop. Model T24463 gives the user a lot of options with features like a wire wheel, a grinding wheel, wheel dressing tool, worklight, and coolant tray.

Model T24464 is a dedicated grinder with two wheel grits included on the machine. Its straightforward, compact design will make it an indispensable machine for your shop.


Manual Accuracy

We are proud to provide a high-quality owner's manual with your new machine!

We made every effort to be exact with the instructions, specifications, drawings, and photographs in this manual. Sometimes we make mistakes, but our policy of continuous improvement also means that **sometimes the machine you receive is slightly different than shown in the manual.**

If you find this to be the case, and the difference between the manual and machine leaves you confused or unsure about something, check our website for an updated version. We post current manuals and manual updates for free on our website at **www.grizzly.com**.

Alternatively, you can call our Technical Support for help. Before calling, make sure you write down the **Manufacture Date** and **Serial Number** from the machine ID label (see below). This information is required for us to provide proper tech support, and it helps us determine if updated documentation is available for your machine.

| | | | |
|--|--|--|--|
|  | | MODEL GXXXX | |
| | | MACHINE NAME | |
| SPECIFICATIONS | | WARNING! | |
| Motor: | | To reduce risk of serious injury when using this machine: | |
| Specification: | | Read manual before operation. | |
| Specification: | | Wear safety glasses and respirator. | |
| Specification: | | Ensure machine is properly adjusted/setup and | |
| Specification: | | power is connected to grounded circuit before starting. | |
| Weight: | | 4. Make sure the motor has stopped and disconnect | |
| | | power before adjustments, maintenance, or service. | |
| | | 5. DO NOT expose to rain or dampness. | |
| | | 6. DO NOT modify this machine in any way. | |
| | | 7. | |
| | | 8. | |
| | | 9. Do not use while tired, drowsy, or under the influence of drugs or alcohol. | |
| | | 10. Maintain machine carefully to prevent accidents. | |
| Manufactured for Grizzly in Taiwan | | | |

Manufacture Date []

Serial Number []

Identification





Figure 1. Machine identification.



⚠ WARNING

To reduce your risk of serious injury, read this entire manual **BEFORE** using machine.





MACHINE DATA SHEET

Customer Service #: (570) 546-9663 · To Order Call: (800) 523-4777 · Fax #: (800) 438-5901

MODEL T24463, T24464 6" Bench Grinders

| Model Number | T24463 | T24464 |
|---|--------------------------------|-------------------|
| Product Dimensions | | |
| Weight | 19 lbs. | 17 lbs. |
| Width (side-to-side)/Depth (front-to-back)/Height | 7½" x 13¾" x 9" | 8¼" x 14¾" x 10¼" |
| Foot Print (Width/Depth) | 5" x 24" | 5½" x 4¾" |
| Shipping Dimensions | | |
| Type | Cardboard | |
| Weight | 21 lbs. | 19 lbs. |
| Width (side-to-side)/Depth (front-to-back)/Height | 11" x 17" x 12" | 10" x 14" x 10" |
| Electrical | | |
| Power Requirement | 120V, Single-Phase, 60 Hz | |
| Switch Voltage | 120V | |
| Cord Length | 6½ ft. | |
| Cord Gauge | 16AWG | |
| Minimum Circuit Size | 15 Amp | |
| Included Plug Type | NEMA 5-15 | |
| Main | | |
| Spindle Diameter | ½" | |
| Grinding Wheel Grit | 36 | 36/60 |
| Grinding Wheel Size (Diameter x Width x Bore) | 6" x ¾" x ½" | |
| Grinding Wheel Material | Aluminum Oxide | |
| Wheel Speed | 3450 RPM | |
| Motor | | |
| Type | TEFC Capacitor Start Induction | |
| Horsepower | ⅓ HP | |
| Amps | 2.1A | |
| Phase | Single | |
| Voltage | 120V | |
| Cycle | 60 Hz | |
| Speed | 3450 RPM | |
| Other | | |
| Coutry of Origin | China | |
| Warranty | 1 Year | |



SECTION 1: SAFETY

For Your Own Safety, Read Instruction Manual Before Operating This Machine

The purpose of safety symbols is to attract your attention to possible hazardous conditions. This manual uses a series of symbols and signal words intended to convey the level of importance of the safety messages. The progression of symbols is described below. Remember that safety messages by themselves do not eliminate danger and are not a substitute for proper accident prevention measures. Always use common sense and good judgment.



Indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, **COULD** result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTICE

Alerts the user to useful information about proper operation of the machine to avoid machine damage.

Safety Instructions for Machinery



OWNER'S MANUAL. Read and understand this owner's manual **BEFORE** using machine.

TRAINED OPERATORS ONLY. Untrained operators have a higher risk of being hurt or killed. Only allow trained/supervised people to use this machine. When machine is not being used, disconnect power, remove switch keys, or lock-out machine to prevent unauthorized use—especially around children. Make your workshop kid proof!

DANGEROUS ENVIRONMENTS. Do not use machinery in areas that are wet, cluttered, or have poor lighting. Operating machinery in these areas greatly increases the risk of accidents and injury.

MENTAL ALERTNESS REQUIRED. Full mental alertness is required for safe operation of machinery. Never operate under the influence of drugs or alcohol, when tired, or when distracted.

ELECTRICAL EQUIPMENT INJURY RISKS.

You can be shocked, burned, or killed by touching live electrical components or improperly grounded machinery. To reduce this risk, only allow qualified service personnel to do electrical installation or repair work, and always disconnect power before accessing or exposing electrical equipment.

DISCONNECT POWER FIRST. Always disconnect machine from power supply **BEFORE** making adjustments, changing tooling, or servicing machine. This prevents an injury risk from unintended startup or contact with live electrical components.

EYE PROTECTION. Always wear ANSI-approved safety glasses or a face shield when operating or observing machinery to reduce the risk of eye injury or blindness from flying particles. Everyday eyeglasses are **NOT** approved safety glasses.



WARNING

WEARING PROPER APPAREL. Do not wear clothing, apparel or jewelry that can become entangled in moving parts. Always tie back or cover long hair. Wear non-slip footwear to reduce risk of slipping and losing control or accidentally contacting cutting tool or moving parts.

HAZARDOUS DUST. Dust created by machinery operations may cause cancer, birth defects, or long-term respiratory damage. Be aware of dust hazards associated with each workpiece material. Always wear a NIOSH-approved respirator to reduce your risk.

HEARING PROTECTION. Always wear hearing protection when operating or observing loud machinery. Extended exposure to this noise without hearing protection can cause permanent hearing loss.

REMOVE ADJUSTING TOOLS. Tools left on machinery can become dangerous projectiles upon startup. Never leave chuck keys, wrenches, or any other tools on machine. Always verify removal before starting!

USE CORRECT TOOL FOR THE JOB. Only use this tool for its intended purpose—do not force it or an attachment to do a job for which it was not designed. Never make unapproved modifications—modifying tool or using it differently than intended may result in malfunction or mechanical failure that can lead to personal injury or death!

AWKWARD POSITIONS. Keep proper footing and balance at all times when operating machine. Do not overreach! Avoid awkward hand positions that make workpiece control difficult or increase the risk of accidental injury.

CHILDREN & BYSTANDERS. Keep children and bystanders at a safe distance from the work area. Stop using machine if they become a distraction.

GUARDS & COVERS. Guards and covers reduce accidental contact with moving parts or flying debris. Make sure they are properly installed, undamaged, and working correctly **BEFORE** operating machine.

FORCING MACHINERY. Do not force machine. It will do the job safer and better at the rate for which it was designed.

NEVER STAND ON MACHINE. Serious injury may occur if machine is tipped or if the cutting tool is unintentionally contacted.

STABLE MACHINE. Unexpected movement during operation greatly increases risk of injury or loss of control. Before starting, verify machine is stable and mobile base (if used) is locked.

USE RECOMMENDED ACCESSORIES. Consult this owner's manual or the manufacturer for recommended accessories. Using improper accessories will increase the risk of serious injury.

UNATTENDED OPERATION. To reduce the risk of accidental injury, turn machine **OFF** and ensure all moving parts completely stop before walking away. Never leave machine running while unattended.

MAINTAIN WITH CARE. Follow all maintenance instructions and lubrication schedules to keep machine in good working condition. A machine that is improperly maintained could malfunction, leading to serious personal injury or death.

DAMAGED PARTS. Regularly inspect machine for damaged, loose, or mis-adjusted parts—or any condition that could affect safe operation. Immediately repair/replace **BEFORE** operating machine. For your own safety, **DO NOT** operate machine with damaged parts!

MAINTAIN POWER CORDS. When disconnecting cord-connected machines from power, grab and pull the plug—**NOT** the cord. Pulling the cord may damage the wires inside. Do not handle cord/plug with wet hands. Avoid cord damage by keeping it away from heated surfaces, high traffic areas, harsh chemicals, and wet/damp locations.

EXPERIENCING DIFFICULTIES. If at any time you experience difficulties performing the intended operation, stop using the machine! Contact our Technical Support at (570) 546-9663.



Additional Safety Instructions for Grinders

WARNING

Serious injury or death can occur from impact injuries. Rotating grinding wheels can easily remove skin, or entanglement/amputation injuries can occur from being caught in moving parts or in-running pinch points. Flying sparks can ignite explosive or flammable materials. To minimize risk of getting hurt or killed, anyone operating machine **MUST** completely heed hazards and warnings below.

SAFE MOUNTING & WORK AREA. An unsecured grinder may become dangerously out of control during operation. Before use, verify grinder is **FIRMLY** secured in a location free of explosive or flammable materials.

STARTING GRINDER. If a wheel is damaged, it will usually fly apart shortly after start-up. To protect yourself, always stand to side of grinder when turning it **ON** and allow it to run for at least one minute before standing in front of it.

VISUAL INSPECTION. Verify that grinding wheels are free of cracks, chips, or dents in wheel surface before installing. Do not use wheel if it has any of these problems or it could break apart during operation.

RING TEST. Perform a “ring test” on grinding wheels before installation to ensure they are safe to use. A wheel that does **NOT** pass ring test may break or fly apart during operation.

WHEEL SPEED RATING. Wheels operated at a faster speed than rated for may break apart during operation. Before mounting a new wheel, be sure wheel RPM rating is equal or higher than speed of grinder. Never use unmarked wheels.

VIBRATING WHEEL. Never use a wheel that vibrates. Replace wheel or shaft bearings immediately.

SPARK DEFLECTOR GAP. Keep gap between end of spark deflector and grinding wheel between $\frac{1}{8}$ " and $\frac{1}{4}$ ". If the gap is larger, excessive sparks and abrasives can be expelled toward the operator.

SPINDLE NUT. Only tighten wheel spindle nut enough to drive wheel and prevent slippage.

EYE SHIELDS. Place eye shields close to grinding wheel and re-adjust as wheel wears down.

TOOL REST POSITION. If tool rest is too far away from wheel, workpiece may be pulled down, causing loss of control and pulling your hand into grinding wheel. Keep tool rest within $\frac{1}{8}$ " from wheel when operating. Replace grinding wheel when tool rest gap is wider than $\frac{1}{8}$ " and no additional adjustment can be made.

HAND & WHEEL CONTACT. Keep a firm grip on workpiece and position your hands a safe distance away when grinding. Anticipate when workpiece will heat up, and cool it before it becomes too hot to hold, or use an appropriate clamp. Avoid wearing gloves as they may get caught in grinding wheel and cause even more serious entanglement injuries.

WHEEL FLANGES. Only use flanges included with grinder when mounting wheels. Other flanges may not properly secure wheel and cause an accident. Do not use warped or damaged flanges, and always use paper discs (blotters) between wheels and flanges to reduce risk of flanges cracking wheel when tightened.

EYE, FACE, & LUNG PROTECTION. Grinding ejects small particles at a high rate of speed. These particles can cause blindness, skin injuries or respiratory damage. **ALWAYS** wear approved clothing, safety goggles, face shield, and a respirator for type of grinding to be done.


SIDE & TOP GRINDING. Grinding on side of wheels can cause them to crack and burst—unless wheel is rated for side grinding. Grinding on top of wheels greatly increases risk of workpiece kickback. Always grind on downward part of wheel.



SECTION 2: POWER SUPPLY

Availability

Before installing the machine, consider the availability and proximity of the required power supply circuit. If an existing circuit does not meet the requirements for this machine, a new circuit must be installed. To minimize the risk of electrocution, fire, or equipment damage, installation work and electrical wiring must be done by an electrician or qualified service personnel in accordance with all applicable codes and standards.



Full-Load Current Rating

The full-load current rating is the amperage a machine draws at 100% of the rated output power. On machines with multiple motors, this is the amperage drawn by the largest motor or sum of all motors and electrical devices that might operate at one time during normal operations.

Full-Load Current Rating at 120V 2.1 Amps

The full-load current is not the maximum amount of amps that the machine will draw. If the machine is overloaded, it will draw additional amps beyond the full-load rating.

If the machine is overloaded for a sufficient length of time, damage, overheating, or fire may result—especially if connected to an undersized circuit. To reduce the risk of these hazards, avoid overloading the machine during operation and make sure it is connected to a power supply circuit that meets the specified circuit requirements.

! WARNING

Serious injury could occur if you connect machine to power before completing setup process. DO NOT connect to power until instructed later in this manual.

Circuit Requirements

This machine is prewired to operate on a 120V power supply circuit that has a verified ground and meets the following requirements:

Nominal Voltage 120V
Cycle 60 Hz
Phase Single-Phase
Power Supply Circuit 15 Amps

A power supply circuit includes all electrical equipment between the breaker box or fuse panel in the building and the machine. The power supply circuit used for this machine must be sized to safely handle the full-load current drawn from the machine for an extended period of time. (If this machine is connected to a circuit protected by fuses, use a time delay fuse marked D.)

! CAUTION

For your own safety and protection of property, consult an electrician if you are unsure about wiring practices or electrical codes in your area.

Note: *Circuit requirements in this manual apply to a dedicated circuit—where only one machine will be running on the circuit at a time. If machine will be connected to a shared circuit where multiple machines may be running at the same time, consult an electrician or qualified service personnel to ensure circuit is properly sized for safe operation.*



Grounding & Plug Requirements

This machine **MUST** be grounded. In the event of certain malfunctions or breakdowns, grounding reduces the risk of electric shock by providing a path of least resistance for electric current.

For 120V operation: This machine is equipped with a power cord that has an equipment-grounding wire and a grounding plug (see following figure). The plug must only be inserted into a matching receptacle (outlet) that is properly installed and grounded in accordance with all local codes and ordinances.





Figure 2. Typical 5-15 plug and receptacle.



Improper connection of the equipment-grounding wire can result in a risk of electric shock. The wire with green insulation (with or without yellow stripes) is the equipment-grounding wire. If repair or replacement of the power cord or plug is necessary, do not connect the equipment-grounding wire to a live (current carrying) terminal.

Check with a qualified electrician or service personnel if you do not understand these grounding requirements, or if you are in doubt about whether the tool is properly grounded. If you ever notice that a cord or plug is damaged or worn, disconnect it from power, and immediately replace it with a new one.

Extension Cords

We do not recommend using an extension cord with this machine. If you must use an extension cord, only use it if absolutely necessary and only on a temporary basis.


Extension cords cause voltage drop, which can damage electrical components and shorten motor life. Voltage drop increases as the extension cord size gets longer and the gauge size gets smaller (higher gauge numbers indicate smaller sizes).

Any extension cord used with this machine must be in good condition and contain a ground wire and matching plug/receptacle. Additionally, it must meet the following size requirements:

Minimum Gauge Size16 AWG
Maximum Length (Shorter is Better).....50 ft.




SECTION 3: SETUP



!WARNING

This machine presents serious injury hazards to untrained users. Read through this entire manual to become familiar with the controls and operations before starting the machine!



!WARNING

Wear safety glasses during the entire setup process!

Needed for Setup


The following are needed to complete the setup process, but are not included with your machine.

| Description | Qty |
|---------------------------------|-----|
| • Safety Glasses | 1 |
| • Wrench 8mm | 1 |
| • Wrench 14mm | 1 |
| • Phillips Screwdriver #2 | 1 |
| • 3/8" Mounting Fasteners | 2 |

Unpacking

This machine was carefully packaged for safe transport. When unpacking, separate all enclosed items from packaging materials and inspect them for shipping damage. ***If items are damaged, please call us immediately at (570) 546-9663.***

IMPORTANT: Save all packaging materials until you are completely satisfied with the machine and have resolved any issues between Grizzly or the shipping agent. *You MUST have the original packaging to file a freight claim. It is also extremely helpful if you need to return your machine later.*



!WARNING

SUFFOCATION HAZARD!

Keep children and pets away from plastic bags or packing materials shipped with this machine.



Inventory

The following is a list of items shipped with your machine. Before beginning setup, lay these items out and inventory them.

If any non-proprietary parts are missing (e.g. a nut or a washer), we will gladly replace them; or for the sake of expediency, replacements can be obtained at your local hardware store.

Model T24463 Inventory

| Box 1: (Figure 3) | Qty |
|--|-------|
| A. Bench Grinder w/Grinding and Brush Wheel (Not Shown)..... | 1 |
| B. Safety Shield Brackets | 2 |
| C. Safety Shield w/Magnifier..... | 1 |
| D. Safety Shield | 1 |
| E. Safety Shield Arms (Right and Left)..... | 1 Ea. |
| F. Spark Deflectors..... | 2 |
| G. Tool Rests (Right and Left)..... | 1 Ea. |
| H. Arm Brackets..... | 2 |
| I. Wheel Dresser..... | 1 |
| J. Hardware (Not Shown) | |
| —Hex Bolt M8-1.25 x 14 | 2 |
| —Hex Bolt M8-1.25 x 10 | 4 |
| —Flat Washer 8mm | 6 |
| —Phillips Head Screws M5-.8 x 10..... | 2 |
| —Lock Washer 5mm..... | 2 |
| —Flat Washer 5mm | 2 |




Figure 3. Model T24463 inventory.

Model T24464 Inventory

| Box 1: (Figure 4) | Qty |
|---|-------|
| A. Bench Grinder | |
| w/Grinding Wheels (Not Shown) | 1 |
| B. Safety Shield Brackets | 2 |
| C. Safety Shield w/ Magnifier..... | 1 |
| D. Safety Shield | 1 |
| E. Safety Shield Arms (Right and Left)..... | 1 Ea. |
| F. Spark Deflectors..... | 2 |
| G. Tool Rests (Right and Left)..... | 1 Ea. |
| H. Tool Rest Knobs M6-1 | 2 |
| I. Arm Brackets..... | 2 |
| J. Hardware (Not Shown) | |
| —Phillips Head Screws M5-.8 x 10..... | 2 |
| —Lock Washer 5mm..... | 2 |
| —Flat Washer 5mm | 2 |
| —Carriage Bolt M6-1 x 14..... | 2 |
| —Hex Bolt M6-1 x 14 | 2 |
| —Flat Washer 6mm | 2 |




Figure 4. Model T24464 inventory.

NOTICE

If you cannot find an item on this list, carefully check around/inside the machine and packaging materials. Often, these items get lost in packaging materials while unpacking or they are pre-installed at the factory.




Site Considerations

Weight Load

Refer to the **Machine Data Sheet** for the weight of your machine. Make sure that the surface upon which the machine is placed will bear the weight of the machine, additional equipment that may be installed on the machine, and the heaviest workpiece that will be used. Additionally, consider the weight of the operator and any dynamic loading that may occur when operating the machine.

Space Allocation

Consider the largest size of workpiece that will be processed through this machine and provide enough space around the machine for adequate operator material handling or the installation of auxiliary equipment. With permanent installations, leave enough space around the machine to open or remove doors/covers as required by the maintenance and service described in this manual. **See below for required space allocation.**



Physical Environment

The physical environment where the machine is operated is important for safe operation and longevity of machine components. For best results, operate this machine in a dry environment that is free from excessive moisture, hazardous chemicals, airborne abrasives, or extreme conditions. Extreme conditions for this type of machinery are generally those where the ambient temperature range exceeds 41°–104°F; the relative humidity range exceeds 20%–95% (non-condensing); or the environment is subject to vibration, shocks, or bumps.

Electrical Installation

Place this machine near an existing power source. Make sure all power cords are protected from traffic, material handling, moisture, chemicals, or other hazards. Make sure to leave enough space around machine to disconnect power supply or apply a lockout/tagout device, if required.

Lighting

Lighting around the machine must be adequate enough that operations can be performed safely. Shadows, glare, or strobe effects that may distract or impede the operator must be eliminated.




Figure 5. Minimum working clearances.



Bench Mounting

Number of Mounting Slots 4
Diameter of Mounting Hardware Needed .. 1/2"

The base of this machine has mounting slots that allow it to be fastened to a workbench or other mounting surface to prevent it from moving during operation and causing accidental injury or damage.

The strongest mounting option is a "Through Mount" (see example below) where holes are drilled all the way through the workbench—and hex bolts, washers, and hex nuts are used to secure the machine in place.




Figure 6. "Through Mount" setup.

Another option is a "direct mount" (see example below) where the machine is secured directly to the workbench with lag screws and washers.




Figure 7. "Direct Mount" setup.



Assembly

Using the hardware from the **Inventory** list on **Page 11**, assemble the tool rest and safety shield as they are shown in **Figure 9**.




Figure 9. Model T24463 spark deflector, safety shield, and tool rest installation.

Note: The tool rests on Model T24464 attach using (1) M6-1 knob and (1) M6-1 x 14 carriage bolt.

Spark Deflector Adjustment

The spark deflector prevents sparks from showering the top of the workpiece. As the wheel wears, adjust the spark deflector closer to the grinding wheel to maintain a gap of $\frac{1}{8}$ "– $\frac{1}{4}$ " (see **Figure 10**). When the gap reaches $\frac{1}{4}$ " and no additional adjustments can be made, replace the grinding wheel.




Figure 10. Spark deflector gap.

Tool Rest Adjustment

The tool rest stabilizes the workpiece when grinding. It must always be positioned correctly when using the grinder. As the grinding wheel wears, adjust the tool rest closer to the grinding wheel to maintain a gap of $\frac{1}{16}$ "– $\frac{1}{8}$ " (see **Figure 9**). When the gap reaches $\frac{1}{8}$ " and no additional adjustments can be made, replace the grinding wheel.



Figure 11. Model T24463 tool rest gap.

⚠ CAUTION

NEVER grind without the tool rest in place and properly positioned. "Free hand" grinding or too large of a gap between the wheel and the tool rest increases the risk of kick-back, which may lead to serious injury.

NOTICE

Some grinding wheels must be replaced before the spark deflector or the tool rest reach their final adjustment. As the diameter of a grinding wheel is reduced, so is the available surface speed. Grinding under these conditions can lead to faster abrasive loss and poor grinding results. Always follow the wheel manufacturer's directions.



Power Connection

After you have completed all previous setup instructions and circuit requirements, the machine is ready to be connected to the power supply.

To avoid unexpected startups or cord damage, use the following steps whenever connecting or disconnecting the machine.

Connecting Power

1. Turn the machine power switch **OFF**.
2. Insert the power cord plug into a matching power supply receptacle. The machine is now connected to the power source.




Figure 12. Connecting power.

Disconnecting Power

1. Turn the machine power switch **OFF**.
2. Grasp the molded plug and pull it completely out of the receptacle. **DO NOT** pull by the cord as this may damage the wires inside.




Figure 13. Disconnecting power.

Test Run

Once assembly is complete, test run the machine to ensure it is properly connected to power and safety components are functioning correctly.

If you find an unusual problem during the test run, immediately stop the machine, disconnect it from power, and fix the problem **BEFORE** operating the machine again. The **Troubleshooting** table in the **SERVICE** section of this manual can help.

!WARNING

Serious injury or death can result from using this machine **BEFORE** understanding its controls and related safety information. **DO NOT** operate, or allow others to operate, machine until the information is understood.

!WARNING

DO NOT start machine until all preceding setup instructions have been performed. Operating an improperly set up machine may result in malfunction or unexpected results that can lead to serious injury, death, or machine/property damage.

To test run machine:

1. Clear all setup tools away from machine.
2. Connect machine to power supply.
3. Turn machine **ON**, verify motor operation, and then turn machine **OFF**.

The motor should run smoothly and without unusual problems or noises.




SECTION 4: OPERATIONS

Operation Overview

The purpose of this overview is to provide the novice machine operator with a basic understanding of how the machine is used during operation, so the machine controls/components discussed later in this manual are easier to understand.

Due to the generic nature of this overview, it is **not** intended to be an instructional guide. To learn more about specific operations, read this entire manual, seek additional training from experienced machine operators, and do additional research outside of this manual by reading "how-to" books, trade magazines, or websites.






!WARNING

To reduce the risk of serious injury when using this bench grinder, read and understand this entire manual before operating.

!WARNING

Damage to your eyes, lungs, and ears could result from using this machine without proper protective gear. Always wear safety goggles, a face shield, and a respirator when operating this machine.



!WARNING

Loose hair and clothing could get caught in machinery and cause serious personal injury. Keep loose clothing and long hair away from moving machinery.

To complete a typical operation, the operator does the following:

1. Examines the workpiece to make sure it is suitable for grinding.
2. Selects the correct grinding wheel for the type of workpiece grinding, inspects the wheel, performs a "ring test", and installs the wheel.
3. Verifies/adjusts the tool rest position so it is perpendicular to the grinding wheel and the gap is $\frac{1}{16}$ " to $\frac{1}{8}$ ".
4. Verifies/adjusts the spark deflector and wheel gap is between $\frac{1}{8}$ " to $\frac{1}{4}$ ".
5. Positions the safety shield for safe grinding.
6. Double checks that no combustibles or flammable materials are near and removes all potential ignition hazards.
7. Ensures that the ON/OFF switch is in the **OFF** position, and connects the grinder to power.
8. Puts on safety goggles, face shield, and respirator.
9. Stands aside, starts the grinder, and allows it to reach full speed.
10. Places the workpiece on the tool rest and positions it for grinding.
11. Using just enough force to allow the wheel to warm up evenly and get the job done, the operator gradually feeds the workpiece into the grinding wheel and moves the workpiece left and right to prevent grooves in the wheel.
12. Quenches the workpiece as required to prevent surface hardening or temper loss.
13. Stops the bench grinder.



WARNING

DO NOT use this grinder with a liquid cooling system required for wet grinding wheel operations. The electrical system is not waterproof. Ignoring this warning can lead to electrocution or machine damage.

Some workpieces are not suitable for grinding on a bench grinder. **Before grinding, inspect all workpieces for the following:**

- **Hard Workpiece:** Workpieces that are made of stone, carbide, stainless steel, ceramics, glass, or have hardened welds will wear out most general grade grinding wheels quickly. If hard materials are to be ground, you must install the correct type of grinding wheel.
- **Soft Workpiece:** Workpieces that are made of aluminum, brass, lead, and other nonferrous metals will load up in the grinding wheel and render the abrasive useless. Grinding wood, plastics, rubber, fiberglass, or other soft materials can also cause the same problem and lead to the wheel overheating and may burst during use if ignored. To restore a loaded grinding wheel surface redress with a dressing tool.
- **Flexible/Unstable Workpiece:** Grinding on the side or the ends of cable, chain, or round workpieces creates the hazard of workpiece twist or grab leading to entanglement with the wheel or shaft. This hazard must be avoided.
- **Loose Parts:** Make sure that the workpiece is free of any parts like springs, pins, balls, or other components that may loosen or dislodge during grinding, and hit the operator.
- **Strength:** Make sure that the workpiece is strong enough to be ground. Should it break, the broken piece may dig into the wheel and cause kickback or severe injury.

Wheel Selection

The Model T24463/T24464 only accepts Type 1 wheels with a 1/2" bore.

Aluminum oxide and silicon carbide wheels are marked in a somewhat uniform manner by all the major manufacturers. Understanding these markings will help you understand the capabilities of various wheels. Always refer to the manufacturer's grinding recommendations when selecting a wheel for your project.

The basic format for wheel numbering is:

| Prefix | Abrasive Type | Grit Size | Grade | Bond Type |
|--------|---------------|-----------|-------|-----------|
| 1 | A | 60 | L | V |

The **Prefix** is the manufacturer's designation for a particular wheel type (eg, Type 1 wheels).

The most common **Abrasive Types** used are A for Aluminum Oxide, C for Silicon Carbide, and occasionally SG for Seeded Gel.

The **Grit Size** is a number that refers to the size of the abrasive grain in the wheel. The lower the number, the coarser the wheel. Ten is a very coarse wheel for roughing and 220 is usually the upper range for fine finish work.

Grade is an indication of the hardness of the wheel—"A" being the softest and "Z" being the hardest.

Bond Type refers to the type of bonding material used to hold the abrasive material. Most general purpose wheels will have a "V" indicating Vitrified Clay is used. Vitrified Clay provides high strength and good porosity. The other common bond type is "B" for resin where synthetic resins are used. These are used to grind cemented carbide and ceramic materials.

Note: *There may be other numbers inserted that have meaning for a particular type of wheel. Refer to the manufacturer's technical data for a complete explanation.*



Wheel Inspection

Before mounting a new grinding wheel, it must be inspected. Do not assume that a wheel is in sound condition just because it is new—often damage can occur in shipping, with age, or with exposure to moisture.

First, do a **Visual Inspection**. Look for any cracks, chips, nicks or dents in the surface of the wheel. If you see any of these, **DO NOT** use the wheel.

Second, do a **Ring Test**. This test will give you an indication of any internal damage that may not be obvious during a visual inspection.

To perform a Ring Test:

1. Make sure the wheel that you test is clean and dry; otherwise, you may get false results.
2. If size permits, balance the wheel with your finger in the hole. If this is not possible, hang the wheel in the air with a piece of cord or string looped through the hole in the center.
3. At the spots shown in **Figure 14**, gently tap the wheel with a light non-metallic device such as the handle of a screwdriver or a wooden mallet.

Note: Finding the exact spot to tap will take several attempts.




Figure 14. Tapping locations when performing a ring test.

4. An undamaged wheel will emit a clear metallic ring or “ping” sound in each of these spots. A damaged wheel will respond with a dull thud that has no clear tone.
5. If you determine from the ring test that the wheel is damaged, **DO NOT** use it!

Wheel Dressing

Depending on the type of grinding you do, the grinding wheel may require periodic dressing.

There are several different types of wheel dressing devices available on the market (see **Page 20** for one example). Dressing restores the abrasive quality of the wheel surface and brings the wheel edge back to a square form.

For Model T24464:

Refer to the instructions that accompany your dressing accessory for complete details on how to properly dress the wheel.

For Model T24463:

1. Turn the grinder **ON**.
2. Place the wheel dresser on the tool rest with the dressing wheels toward the grinding wheel.
3. Slowly move the dressing wheel toward the grinding wheel and maintain slight pressure until a clear grinding surface appears on the wheel.
4. Turn the grinder **OFF**.
5. Adjust the spark deflector and tool rest per the instructions on **Page 14**.

⚠ CAUTION

Always adjust the tool rest and spark deflector after dressing or replacing the grinding wheel. Failure to do so could lead to workpiece kickback and injury.



Wheel Removal & Installation

⚠ CAUTION

ALWAYS visually inspect and perform a “ring test” on a wheel before assembly. **DO NOT** use damaged wheels!

Before installing any wheel, perform a “ring test” to make sure it is free of cracks. Never use a wheel which is suspected of having cracks, is damp, or if there are visual chips, nicks or dents in the wheel surface. Refer to the in-depth safety warnings in the **Safety Section** before installing the wheel.

To remove and install a grinding wheel:

1. DISCONNECT MACHINE FROM POWER!
2. Remove the three Phillips head screws and nuts which go through the outer guard.
3. Remove the outer guard and rim guard (as shown in **Figure 4**).
4. Use a $\frac{3}{4}$ " or 19mm open end wrench to remove the spindle nut. Hold the wheel from turning with the other hand.

Note: The spindle on the left side of the machine has left hand threads. Turn it clockwise to loosen.




Figure 15. Model T24464 wheel guard components.

5. Remove the outer wheel flange and the paper disc.
6. Remove the wheel from the spindle. Notice the paper or fiber disc between the wheel flanges and the wheel itself. This helps to spread the rotational forces across the inner area of the wheel (see **Figure 16**).




Figure 16. Assembly order for wheel installation.

⚠ CAUTION

NEVER assemble a grinding wheel on the arbor without paper or fiber discs between the wheel and the flange. Not using the discs can put stress on the wheel, causing it to crack and possibly fall apart.

7. Mount the new wheel in the order shown in **Figure 16**. Tighten the nut snugly but do not over tighten. Over tightening can crack the wheel.
8. While standing clear of the line of rotation, turn the machine **ON** and run the new wheel for at least 1-2 minutes.

—If grinder runs smoothly then the wheel may now be used.

—If the wheel appears to wobble, the grinder vibrates excessively, or any other unsafe condition appears with the new wheel, stop the grinder and refer to **Troubleshooting** on **Page 22**.



SECTION 5: ACCESSORIES

WARNING

Installing unapproved accessories may cause machine to malfunction, resulting in serious personal injury or machine damage. To reduce this risk, only install accessories recommended for this machine by Grizzly.

NOTICE

Refer to our website or latest catalog for additional recommended accessories.

Basic Eye Protection

T20501—Face Shield Crown Protector 4"

T20502—Face Shield Crown Protector 7"

T20503—Face Shield Window

T20451—"Kirova" Clear Safety Glasses

T20452—"Kirova" Anti-Reflective S. Glasses

H7194—Bifocal Safety Glasses 1.5

H7195—Bifocal Safety Glasses 2.0

H7196—Bifocal Safety Glasses 2.5



Figure 17. Assortment of basic eye protection.

Model H5944—#0 Wheel Dresser

Model H5945—#1 Wheel Dresser

Model H5946—#2 Wheel Dresser

Exposes new grains for aggressive cutting on all types of grinding wheels. Star wheels and discs are hardened steel. Cast iron handle provides stabilizing mass for better control.



Figure 18. Rotary-type dressing tools.

H5891— $\frac{1}{4}$ Carat Diamond Dresser

H5892— $\frac{3}{4}$ Carat Diamond Dresser

Industrial diamond for dressing grinding wheels. $8\frac{1}{4}$ " long round body with knurled grip for maximum control. Includes protective rubber end cap.




Figure 19. Diamond dressing tools.

order online at www.grizzly.com or call 1-800-523-4777



SECTION 6: MAINTENANCE



Schedule

For optimum performance from your machine, follow this maintenance schedule and refer to any specific instructions given in this section. Routinely check the condition of the following items and repair or replace as necessary:

- Cracked or loose grinding wheel.
- Loose mounting bolts.
- Worn switch.
- Worn or damaged cords and plugs.
- Any other condition that could hamper the safe operation of this machine.

Grinding Wheels

The grinding wheel should be inspected before every use. Use the ring test method noted in **Wheel Inspection** on **Page 18** to verify the structural integrity. Take care in storing grinding wheels to keep them free from potential damage by being dropped or having other items drop on them.

Replace the wheel when the spark deflector or tool rest has no more adjustment and the gap has exceeded the safe limit.

Wheel Dressing

Depending on the type of grinding you do, the grinding wheel may require periodic dressing.

Several different kinds of wheel dressing devices are available. Dressing restores the abrasive quality of the wheel surface and squares up the wheel edge.

For Model T24464, refer to the instructions that accompany your dressing accessory for complete details on how to properly dress a wheel. For Model T24463, refer to **Page 18** for detailed instructions.

Replacing Light Bulb

Replacement BulbPT24463062

To remove the bulb, gently push the bulb down and turn it counter clockwise.


Insert the new bulb by pressing down gently and turning it clockwise until it stops.



SECTION 7: SERVICE

Review the troubleshooting procedures in this section if a problem develops with your machine. If you need replacement parts or additional help with a procedure, call our Technical Support. **Note:** *Please gather the serial number and manufacture date of your machine before calling.*

Troubleshooting



| Symptom | Possible Cause | Possible Solution |
|---|---|--|
| Motor will not start. | <ol style="list-style-type: none"> 1. Low voltage. 2. Open circuit in motor or loose connections. | <ol style="list-style-type: none"> 1. Check power line for proper voltage. 2. Inspect all lead connections on motor for loose or open connections. |
| Motor will not start; fuses or circuit breakers blow. | <ol style="list-style-type: none"> 1. Short circuit in line cord or plug. 2. Short circuit in motor or loose connections. 3. Incorrect fuses or circuit breakers in power line. | <ol style="list-style-type: none"> 1. Inspect cord or plug for damaged insulation and shorted wires. 2. Inspect all connections on motor for loose or shorted terminals or worn insulation. 3. Install correct fuses or circuit breakers. |
| Motor overheats. | <ol style="list-style-type: none"> 1. Motor overloaded. | <ol style="list-style-type: none"> 1. Reduce load on motor. |
| Motor stalls (resulting in blown fuses or tripped circuit). | <ol style="list-style-type: none"> 1. Short circuit in motor or loose connections. 2. Low voltage. 3. Incorrect fuses or circuit breakers in power line. 4. Motor overloaded. | <ol style="list-style-type: none"> 1. Inspect connections on motor for loose or shorted terminals or worn insulation. 2. Correct the low voltage conditions. 3. Install correct fuses or circuit breakers. 4. Reduce load on motor. |
| Machine slows when operating. | <ol style="list-style-type: none"> 1. Operator is using too much pressure. | <ol style="list-style-type: none"> 1. Use less pressure when grinding. |
| Wavy condition on surface of workpiece. | <ol style="list-style-type: none"> 1. Machine vibrating. 2. Workpiece not being held firmly. 3. Wheel face uneven. 4. Wheel is too hard. | <ol style="list-style-type: none"> 1. Make sure machine is securely mounted on a solid surface. 2. Use a holding device to firmly retain the workpiece. 3. Dress the grinding wheel. 4. Use softer wheel, or reduce the feed rate. |
| Lines on surface of workpiece. | <ol style="list-style-type: none"> 1. Impurity on wheel surface. | <ol style="list-style-type: none"> 1. Dress the grinding wheel. |
| Burning spots or cracks in the workpiece. | <ol style="list-style-type: none"> 1. Improper type of grinding wheel. 2. Improper feed rate. 3. Coolant required. | <ol style="list-style-type: none"> 1. Try a wheel which is softer style or a coarser grit. 2. Slow down the rate of movement of the workpiece into wheel. 3. Introduce coolant by hand. |
| Wheel dulls quickly, grit falls off. | <ol style="list-style-type: none"> 1. Depth of cut too great. 2. Wheel is too soft. 3. Wheel diameter too small. 4. Bad wheel dress. 5. Defective wheel bonding. | <ol style="list-style-type: none"> 1. Slow down the rate of movement of the workpiece into wheel. 2. Wheel too soft for the material being ground, select harder bond. 3. Replace the wheel. 4. Dress the wheel. 5. Consult manufacturer of grinding wheel. |



SECTION 8: WIRING

These pages are current at the time of printing. However, in the spirit of improvement, we may make changes to the electrical systems of future machines. Compare the manufacture date of your machine to the one stated in this manual, and study this section carefully.

If there are differences between your machine and what is shown in this section, call Technical Support at (570) 546-9663 for assistance BEFORE making any changes to the wiring on your machine. An updated wiring diagram may be available. **Note:** Please gather the serial number and manufacture date of your machine before calling. This information can be found on the main machine label.

WARNING

Wiring Safety Instructions

SHOCK HAZARD. Working on wiring that is connected to a power source is extremely dangerous. Touching electrified parts will result in personal injury including but not limited to severe burns, electrocution, or death. Disconnect the power from the machine before servicing electrical components!

MODIFICATIONS. Modifying the wiring beyond what is shown in the diagram may lead to unpredictable results, including serious injury or fire. This includes the installation of unapproved after-market parts.

WIRE CONNECTIONS. All connections must be tight to prevent wires from loosening during machine operation. Double-check all wires disconnected or connected during any wiring task to ensure tight connections.

CIRCUIT REQUIREMENTS. You MUST follow the requirements at the beginning of this manual when connecting your machine to a power source.

WIRE/COMPONENT DAMAGE. Damaged wires or components increase the risk of serious personal injury, fire, or machine damage. If you notice that any wires or components are damaged while performing a wiring task, replace those wires or components.

MOTOR WIRING. The motor wiring shown in these diagrams is current at the time of printing but may not match your machine. If you find this to be the case, use the wiring diagram inside the motor junction box.
















CAPACITORS/INVERTERS. Some capacitors and power inverters store an electrical charge for up to 10 minutes after being disconnected from the power source. To reduce the risk of being shocked, wait at least this long before working on capacitors.

EXPERIENCING DIFFICULTIES. If you are experiencing difficulties understanding the information included in this section, contact our Technical Support at (570) 546-9663.

NOTICE


The photos and diagrams included in this section are best viewed in color. You can view these pages in color at www.grizzly.com.

COLOR KEY


| | | | | | | | |
|-------|---|--------|---|--------------|---|------------|---|
| BLACK |  | BLUE |  | YELLOW |  | LIGHT BLUE |  |
| WHITE |  | BROWN |  | YELLOW GREEN |  | BLUE WHITE |  |
| GREEN |  | GRAY |  | PURPLE |  | TURQUOISE |  |
| RED |  | ORANGE |  | PINK |  | | |



T24463 Wiring




T24464 Wiring



SECTION 9: PARTS

T24463 Breakdown




T24463 Parts List

| REF | PART # | DESCRIPTION |
|-----|------------|--------------------------------------|
| 1 | PS54M | PHLP HD SCR M5-.8 X 45 |
| 2 | PT24463002 | LEFT WHEEL COVER |
| 3 | PN09M | HEX NUT M12-1.75 |
| 4 | PT24463004 | WHEEL FLANGE |
| 5 | PT24463005 | GRINDING WHEEL 6 X 3/4 X 1/2 36-GRIT |
| 6 | PS09M | PHLP HD SCR M5-.8 X 10 |
| 7 | PT24463007 | LEFT GUARD |
| 8 | PT24463008 | SPARK DEFLECTOR |
| 9 | PW02M | FLAT WASHER 5MM |
| 10 | PS05M | PHLP HD SCR M5-.8 X 8 |
| 11 | PT24463011 | LEFT SAFETY SHIELD ARM |
| 12 | PT24463012 | ARM BRACKET |
| 13 | PW01M | FLAT WASHER 8MM |
| 14 | PB84M | HEX BOLT M8-1.25 X 14 |
| 15 | PCB22M | CARRIAGE BOLT M6-1 X 16 |
| 16 | PT24463016 | SAFETY SHIELD BRACKET |
| 17 | PW05M | FLAT WASHER 4MM |
| 18 | PS38M | PHLP HD SCR M4-.7 X 10 |
| 19 | PT24463019 | PHLP HD SCR M5-.8 X 124 |
| 20 | PT24463020 | RIGHT SAFETY SHIELD ARM |
| 21 | PT24463021 | END BELL |
| 22 | PN03M | HEX NUT M8-1.25 |
| 23 | PT24463023 | DISC SPRING |
| 24 | P6202ZZ | BALL BEARING 6202ZZ |
| 25 | PT24463025 | STATOR |
| 26 | PT24463026 | ROTOR |
| 27 | PN06M | HEX NUT M5-.8 |
| 28 | PLW01M | LOCK WASHER 5MM |
| 29 | PT24463029 | LEFT TOOL REST |
| 30 | PT24463030 | MAGNIFYING SAFETY SHIELD |
| 31 | PB82M | HEX BOLT M8-1.25 X 8 |
| 32 | PLW01M | LOCK WASHER 5MM |
| 33 | PW03M | FLAT WASHER 6MM |
| 34 | PN01M | HEX NUT M6-1 |
| 35 | PN16M | HEX NUT M12-1.75 LH |
| 36 | PT24463036 | WIRE WHEEL 6 X 3/4 X 1/2 |

| REF | PART # | DESCRIPTION |
|-----|------------|-------------------------------|
| 37 | PT24463037 | LOCK NUT 16MM |
| 38 | PTLW01M | EXT TOOTH WASHER 4MM |
| 39 | PS07M | PHLP HD SCR M4-.7 X 8 |
| 40 | PT24463040 | RIGHT GUARD |
| 41 | PT24463041 | CORD GROMMET |
| 42 | PT24463042 | R CAPACITOR 8M 300V |
| 43 | PT24463043 | CAPACITOR BRACKET |
| 44 | PLW02M | LOCK WASHER 4MM |
| 45 | PT24463045 | WHEEL DRESSING TOOL |
| 46 | PT24463046 | LAMP NECK |
| 47 | PT24463047 | MAIN HOUSING |
| 48 | PT24463048 | POWER CORD 16G 3W 78" 5-15P |
| 49 | PT24463049 | CORD GRIP |
| 50 | PN02M | HEX NUT M10-1.5 |
| 51 | PTLW08M | EXT TOOTH WASHER 10MM |
| 52 | PT24463052 | SWITCH PLATE |
| 53 | PT24463053 | SWITCH KTL T85 120V |
| 54 | PN04M | HEX NUT M4-.7 |
| 55 | PS56M | PHLP HD SCR M4-.7 X 16 |
| 56 | PW05M | FLAT WASHER 4MM |
| 57 | PT24463057 | RUBBER FOOT |
| 58 | PT24463058 | COOLANT TRAY |
| 59 | PT24463059 | BOTTOM PLATE |
| 60 | PT24463060 | RIGHT TOOL REST |
| 61 | PW05M | FLAT WASHER 4MM |
| 62 | PLW02M | LOCK WASHER 4MM |
| 63 | PT24463063 | LIGHT BULB 120V 10W BAS25 INC |
| 64 | PT24463064 | LAMP ASSEMBLY |
| 65 | PT24463065 | WHEEL DRESSING TOOL BASE |
| 66 | PW04M | FLAT WASHER 10MM |
| 67 | PLW03M | LOCK WASHER 6MM |
| 68 | PS05M | PHLP HD SCR M5-.8 X 8 |
| 69 | PT24463069 | RIGHT WHEEL COVER |
| 70 | PS102M | PHLP HD SCR M5-.8 X 50 |
| 71 | PT24463071 | SAFETY SHIELD |



T24464 Breakdown




T24464 Parts List

| REF | PART # | DESCRIPTION |
|------|--------------|--------------------------------------|
| 1V2 | PT24464001V2 | HEX BOLT M6-1 X 15 |
| 2V2 | PT24464002V2 | FLAT WASHER 6MM |
| 3 | PT24464003 | BRACKET |
| 4 | PT24464004 | LEFT SAFETY SHIELD SUPPORT |
| 5 | PT24464005 | PLATE SAFETY SHIELD ASSY |
| 6 | PT24464006 | STAR KNOB M6-1 6PT |
| 7 | PT24464007 | LEFT TOOL REST |
| 8 | PT24464008 | HEX NUT M5-.8 |
| 9V2 | PT24464009V2 | LEFT WHEEL GUARD V2.12.15 |
| 10 | PT24464010 | CARRIAGE BOLT M6-1 X 14 |
| 11 | PT24464011 | PHLP HD SCR M5-.8 X 10 |
| 12 | PT24464012 | SPARK DEFLECTOR |
| 13 | PT24464013 | PHLP HD SCR M5-.8 X 10 |
| 14 | PT24464014 | WHEEL FLANGE |
| 15 | PT24464015 | GRINDING WHEEL 6 X 3/4 X 1/2 36-GRIT |
| 16 | PT24464016 | HEX NUT M12-1.75 |
| 17 | PT24464017 | LEFT WHEEL COVER |
| 18 | PT24464018 | PHLP HD SCR M5-.8 X 40 |
| 19 | PT24464019 | FLANGE HEX NUT M4-.7 |
| 20V2 | PT24464020V2 | END BELL V2.12.15 |
| 21V2 | PT24464021V2 | DISC SPRING 34.5MM V2.12.15 |
| 22 | PT24464022 | STATOR |
| 23 | PT24464023 | CORD GROMMET |
| 24 | PT24464024 | LOCK WASHER 4MM |

| REF | PART # | DESCRIPTION |
|------|--------------|--------------------------------------|
| 25 | PT24464025 | PHLP HD SCR M4-.7 X 8 |
| 26 | PT24464026 | SWITCH KTL T85 120V |
| 27 | PT24464027 | SWITCH PLATE |
| 28 | PT24464028 | PHLP HD SCR M4-.7 X 8 |
| 29V2 | PT24464029V2 | BOTTOM PLATE V2.12.15 |
| 30 | PT24464030 | PHLP HD SCR M5-.8 X 8 |
| 31 | PT24464031 | RUBBER FOOT |
| 32V2 | PT24464032V2 | R CAPACITOR 8M 300V V2.12.15 |
| 34 | PT24464034 | HEX NUT M12-1.75 |
| 35 | PT24464035 | RIGHT WHEEL COVER |
| 36 | PT24464036 | GRINDING WHEEL 6 X 3/4 X 1/2 60-GRIT |
| 37V2 | PT24464037V2 | RIGHT WHEEL GUARD V2.12.15 |
| 38 | PT24464038 | RIGHT TOOL REST |
| 39 | PT24464039 | PHLP HD SCR M4-.7 X 118 |
| 40V2 | PT24464040V2 | BALL BEARING 6202ZZ |
| 41 | PT24464041 | CORD CLIP |
| 42 | PT24464042 | ROTOR |
| 43 | PT24464043 | MAGNIFIED SAFETY SHIELD ASSY |
| 44 | PT24464044 | RIGHT SAFETY SHIELD SUPPORT |
| 45 | PT24464045 | POWER CORD 16G 3W 78" 5-15 |
| 46 | PT24464046 | BASE |
| 48 | PT24464048 | FLANGE HEX NUT M4-.7 |
| 49 | PT24464049 | FLAT WASHER 5MM |
| 50 | PT24464050 | PHLP HD SCR M4-.7 X 8 |



T24463/T24464 Labels



| REF | PART # | DESCRIPTION |
|-----|------------|------------------------------|
| 101 | PLABEL-14A | ELECTRICITY LABEL |
| 102 | PPAINT-1 | GRIZZLY GREEN TOUCH-UP PAINT |
| 103 | PLABEL-56A | FACE SHIELD/RESPIRATOR LABEL |

| REF | PART # | DESCRIPTION |
|-------|--------------|------------------------------------|
| 104 | PT24463104 | MACHINE ID LABEL (T24463) |
| 104V2 | PT24464104V2 | MACHINE ID LABEL V2.02.16 (T24464) |
| 105 | PLABEL-12C | READ MANUAL LABEL |

WARNING

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this machine **MUST** replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or www.grizzly.com.





WARRANTY CARD

Name _____

Street _____

City _____ State _____ Zip _____

Phone # _____ Email _____

Model # _____ Order # _____ Serial # _____

*The following information is given on a voluntary basis. It will be used for marketing purposes to help us develop better products and services. **Of course, all information is strictly confidential.***

1. How did you learn about us?

_____ Advertisement

_____ Friend

_____ Catalog

_____ Card Deck

_____ Website

_____ Other:

2. Which of the following magazines do you subscribe to?

_____ Cabinetmaker & FDM

_____ Popular Science

_____ Wooden Boat

_____ Family Handyman

_____ Popular Woodworking

_____ Woodshop News

_____ Hand Loader

_____ Precision Shooter

_____ Woodsmith

_____ Handy

_____ Projects in Metal

_____ Woodwork

_____ Home Shop Machinist

_____ RC Modeler

_____ Woodworker West

_____ Journal of Light Cont.

_____ Rifle

_____ Woodworker's Journal

_____ Live Steam

_____ Shop Notes

_____ Other:

_____ Model Airplane News

_____ Shotgun News

_____ Old House Journal

_____ Today's Homeowner

_____ Popular Mechanics

_____ Wood

3. What is your annual household income?

_____ \$20,000-\$29,000

_____ \$30,000-\$39,000

_____ \$40,000-\$49,000

_____ \$50,000-\$59,000

_____ \$60,000-\$69,000

_____ \$70,000+

4. What is your age group?

_____ 20-29

_____ 30-39

_____ 40-49

_____ 50-59

_____ 60-69

_____ 70+

5. How long have you been a woodworker/metalworker?

_____ 0-2 Years

_____ 2-8 Years

_____ 8-20 Years

_____ 20+ Years

6. How many of your machines or tools are Grizzly?

_____ 0-2

_____ 3-5

_____ 6-9

_____ 10+

7. Do you think your machine represents a good value?

_____ Yes

_____ No

8. Would you recommend Grizzly Industrial to a friend?

_____ Yes

_____ No

9. Would you allow us to use your name as a reference for Grizzly customers in your area?

Note: *We never use names more than 3 times.*

_____ Yes

_____ No

10. Comments: _____

CUT ALONG DOTTED LINE

FOLD ALONG DOTTED LINE



Place
Stamp
Here



GRIZZLY INDUSTRIAL, INC.
P.O. BOX 2069
BELLINGHAM, WA 98227-2069



FOLD ALONG DOTTED LINE

Send a Grizzly Catalog to a friend:

| |
|-----------------------------|
| Name_____ |
| Street_____ |
| City_____State_____Zip_____ |

TAPE ALONG EDGES--PLEASE DO NOT STAPLE

WARRANTY & RETURNS

Grizzly Industrial, Inc. warrants every product it sells for a period of **1 year** to the original purchaser from the date of purchase. This warranty does not apply to defects due directly or indirectly to misuse, abuse, negligence, accidents, repairs or alterations or lack of maintenance. This is Grizzly's sole written warranty and any and all warranties that may be implied by law, including any merchantability or fitness, for any particular purpose, are hereby limited to the duration of this written warranty. We do not warrant or represent that the merchandise complies with the provisions of any law or acts unless the manufacturer so warrants. In no event shall Grizzly's liability under this warranty exceed the purchase price paid for the product and any legal actions brought against Grizzly shall be tried in the State of Washington, County of Whatcom.

We shall in no event be liable for death, injuries to persons or property or for incidental, contingent, special, or consequential damages arising from the use of our products.

To take advantage of this warranty, contact us by mail or phone and give us all the details. We will then issue you a "Return Number," which must be clearly posted on the outside as well as the inside of the carton. We will not accept any item back without this number. Proof of purchase must accompany the merchandise.

The manufacturers reserve the right to change specifications at any time because they constantly strive to achieve better quality equipment. We make every effort to ensure that our products meet high quality and durability standards and we hope you never need to use this warranty.

Please feel free to write or call us if you have any questions about the machine or the manual.

Thank you again for your business and continued support. We hope to serve you again soon.



Buy Direct and Save with Grizzly® – Trusted, Proven and a Great Value!
~Since 1983~

*Visit Our Website Today For
Current Specials!*

**ORDER
24 HOURS A DAY!
1-800-523-4777**

