




MODEL G0451 SLIDING TABLE SAW MANUAL UPDATE

Since the original Model G0451 sliding table was first written, we've redesigned the sliding table and the hold down clamp. As a result, the parts breakdown and list in the original manual do not match your machine. This update includes updated parts breakdowns that match your machine. Please keep it with your owner's manual for future reference. *If you have questions, contact Tech Support at (570) 546-9663 or by email at techsupport@grizzly.com.*

Sliding Table Accessories (Since May, 2010)

Replaces Pages 70-71




| REF | PART # | DESCRIPTION |
|--------|--------------|-----------------------------------|
| 608AV3 | P04510608AV3 | SLIDING TABLE ASSY V3.05.10 |
| 609 | P04510609 | HANDLE M12-1.75 |
| 610 | PW06M | FLAT WASHER 12MM |
| 611 | P04510215 | T-NUT M12-1.75 |
| 612A | P04510612A | LOCK HANDLE M10-1.5 X 20 V2.08.07 |
| 613A | PW04M | FLAT WASHER 10MM |
| 614A | P04510614A | EDGE SHOE PLATE V2.08.07 |
| 615A | P04510615A | T-NUT M10-1.5 V2.08.07 |
| 616 | P04510616 | BALL KNOB M8-1.25 |
| 617 | P04510617 | HANDLE SHAFT |
| 618 | P04510618 | CAM |
| 620V2 | P04510620V2 | PIN V2.05.10 |

| REF | PART # | DESCRIPTION |
|-------|-------------|-----------------------------|
| 621V2 | P04510621V2 | DOWN PRESS V2.05.10 |
| 622V2 | PR02M | EXT RETAINING RING 14MM |
| 623V2 | P04510623V2 | COMPRESSION SPRING V2.05.10 |
| 624V2 | P04510624V2 | SHAFT V2.05.10 |
| 625 | PN02 | HEX NUT 5/16-18 |
| 626 | P04510626 | LARGE WASHER |
| 628V3 | P04510628V3 | SHAFT V3.05.10 |
| 629V2 | P04510629V2 | ADJUST HANDLE V2.05.10 |
| 631 | P04510631 | DISC-GASKET |
| 632V3 | P04510632V3 | T-NUT M12-1.75 V3.05.10 |
| 662 | PRP70M | ROLL PIN 5 X 18 |

COPYRIGHT © JULY, 2010 BY GRIZZLY INDUSTRIAL, INC.
**WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE
OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.**
(FOR MACHINES MFG SINCE 5/10) #TR13121 PRINTED IN TAIWAN

Sliding Table Parts (Since May, 2010)

Replaces Pages 72-73



| REF | PART # | DESCRIPTION |
|-------|-------------|-------------------------------|
| 601V3 | P04510601V3 | BASE END COVER V3.05.10 |
| 603V3 | P04510603V3 | TABLE END COVER V3.05.10 |
| 604V3 | P04510604V3 | T-BOLT M12-1.75 X 40 V3.05.10 |
| 605 | PW06M | FLAT WASHER 12MM |
| 606 | PLW05M | LOCK WASHER 12MM |
| 607 | PN09M | HEX NUT M12-1.75 |
| 608V3 | P04510608V3 | TOP BASE 2500MM V3.05.10 |
| 635A | PCAP58M | CAP SCREW M8-1.25 X 12 |
| 636 | P04510636 | HANDLE |
| 639V3 | PBHS09M | BUTTON HD CAP SCR M6-1 X 12 |
| 640V3 | P04510640V3 | RIGHT END PLATE V3.05.10 |
| 643V3 | P04510643V3 | BASE END COVER V3.05.10 |
| 645 | P04510645 | HORIZONTAL LOCATE PLATE |
| 646A | PFH26M | FLAT HD SCR M6-1 X 30 |
| 648V2 | P04510648V2 | TEETH LOCATE PLATE V2.05.10 |

| REF | PART # | DESCRIPTION |
|-------|-------------|-----------------------------|
| 650V3 | P04510650V3 | STEEL RAIL V3.05.10 |
| 651V3 | P04510651V3 | BOTTOM BASE 2500MM V3.05.10 |
| 657A | PHTEK19M | TAP SCREW M5 X 16 |
| 663 | P04510663 | RUBBER BLOCK |
| 664 | P04510664 | LOCATE BLOCK |
| 665V2 | P04510665V2 | LOCATE ROD V2.05.10 |
| 666 | PFH43M | FLAT HD SCR M6-1 X 10 |
| 671V2 | P04510671V2 | LOCATE BLOCK V2.05.10 |
| 672V2 | PFH07M | FLAT HD SCR M5-.8 X 10 |
| 673V2 | PCAP115M | BUTTON HD CAP SCR M6-1 X 16 |
| 675V2 | P04510675V2 | STEEL BALL 16.6MM V2.05.10 |
| 676V2 | P04510676V2 | SLIDING BOTTOM V2.05.10 |
| 677 | P04510677 | COTTON PAD |
| 678V3 | PBHS05M | BUTTON HD CAP SCR M6-1 X 20 |
| 679 | P04510679 | ADHESIVE |





MODEL G0451

14" SLIDING TABLE SAW

OWNER'S MANUAL



COPYRIGHT © APRIL, 2005 BY GRIZZLY INDUSTRIAL, INC., REVISED MAY, 2011 (TS)
**WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE
OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.**
(FOR MODELS MANUFACTURED SINCE 5/10) #EW6937 PRINTED IN TAIWAN



WARNING!

This manual provides critical safety instructions on the proper setup, operation, maintenance, and service of this machine/tool. Save this document, refer to it often, and use it to instruct other operators.

Failure to read, understand and follow the instructions in this manual may result in fire or serious personal injury—including amputation, electrocution, or death.

The owner of this machine/tool is solely responsible for its safe use. This responsibility includes but is not limited to proper installation in a safe environment, personnel training and usage authorization, proper inspection and maintenance, manual availability and comprehension, application of safety devices, cutting/sanding/grinding tool integrity, and the usage of personal protective equipment.

The manufacturer will not be held liable for injury or property damage from negligence, improper training, machine modifications or misuse.



WARNING!

Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

- **Lead from lead-based paints.**
- **Crystalline silica from bricks, cement and other masonry products.**
- **Arsenic and chromium from chemically-treated lumber.**

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: Work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.

Table of Contents

| | | | |
|--|-----------|--|------------|
| INTRODUCTION | 2 | SECTION 6: AFTERMARKET | |
| Manual Accuracy | 2 | ACCESSORIES FROM GRIZZLY | 59 |
| Contact Info..... | 2 | SECTION 7: MAINTENANCE..... | 61 |
| Identification & Basic Controls | 3 | Schedule..... | 61 |
| Glossary Of Terms..... | 6 | Cleaning..... | 61 |
| Machine Data Sheet | 7 | Unpainted Cast Iron..... | 61 |
| Cutting Capacities..... | 10 | Lubrication | 62 |
| SECTION 1: SAFETY | 11 | SECTION 8: SERVICE | 63 |
| Safety Instructions for Machinery | 11 | Troubleshooting | 63 |
| Additional Safety for Table Saws..... | 13 | Belt Service..... | 65 |
| SECTION 2: POWER SUPPLY | 14 | Blade Tilt Calibration..... | 66 |
| Voltage Conversion..... | 16 | Sliding Table Parallel Adjustment..... | 67 |
| SECTION 3: SETUP | 17 | Table Movement Adjustment..... | 68 |
| Needed for Setup..... | 17 | Squaring Crosscut Fence to Blade..... | 69 |
| Unpacking | 17 | Adjusting Riving Knife Mounting Block..... | 70 |
| Hardware Recognition Chart | 18 | SECTION 9: WIRING..... | 71 |
| Inventory | 19 | Wiring Safety Instructions | 71 |
| Cleanup..... | 21 | Wiring Overview | 72 |
| Site Considerations..... | 22 | Electrical Box at 220V Wiring | 73 |
| Moving & Placing Base Unit | 23 | Electrical Box at 440V Wiring | 74 |
| Assembly & Setup | 24 | Control Panel Wiring..... | 75 |
| Power Connection..... | 32 | Main Motor Wiring..... | 76 |
| Test Run | 33 | Scoring Motor Wiring | 77 |
| SECTION 4: OPERATIONS | 35 | SECTION 10: PARTS | 78 |
| Operation Overview | 35 | Electrical Components..... | 78 |
| Workpiece Inspection..... | 36 | Crosscut Fence..... | 79 |
| Non-Through & Through Cuts | 36 | Crosscut Table..... | 80 |
| Blade Guard & Riving Knife..... | 37 | Cabinet Body | 81 |
| Blade Requirements | 39 | Main Blade | 83 |
| Blade Selection..... | 39 | Main Blade Arbor | 85 |
| Changing Main Blade | 41 | Sliding Table | 86 |
| Changing & Adjusting Scoring Blade..... | 42 | Tables | 88 |
| Rip Cutting | 43 | Rip Fence..... | 89 |
| Crosscutting | 45 | Scoring Motor..... | 90 |
| Miter Cutting..... | 47 | Adjustment Wheels | 92 |
| Dado Cutting..... | 48 | Swing Arm..... | 93 |
| Rabbet Cutting..... | 49 | Main Motor Parts | 94 |
| Resawing | 50 | Machine Labels A | 95 |
| SECTION 5: SHOP MADE SAFETY | | Machine Labels B | 96 |
| ACCESSORIES | 52 | WARRANTY & RETURNS | 101 |
| Featherboards..... | 52 | | |
| Push Sticks | 55 | | |
| Push Blocks | 56 | | |
| Narrow-Rip Auxiliary Fence & Push Block .. | 57 | | |


INTRODUCTION

Manual Accuracy

We are proud to offer this manual with your new machine! We've made every effort to be exact with the instructions, specifications, drawings, and photographs of the machine we used when writing this manual. However, sometimes we still make an occasional mistake.

Also, owing to our policy of continuous improvement, **your machine may not exactly match the manual**. If you find this to be the case, and the difference between the manual and machine leaves you in doubt, check our website for the latest manual update or call technical support for help.

Before calling, find the manufacture date of your machine by looking at the date stamped into the machine ID label (see below). This will help us determine if the manual version you received matches the manufacture date of your machine.

| | | | |
|---|---------------|---|--|
|  | | MODEL GXXXX | |
| | | MACHINE NAME | |
| SPECIFICATIONS | | ⚠ WARNING! | |
| Motor: | | Manufacture Date of Your Machine | |
| Specification: | | | |
| Specification: | | | |
| Specification: | | | |
| Weight: | | | |
| | Date | <div>When using this machine: 1. Wear safety glasses and respirator. 2. Read and understand the manual. 3. Make sure the machine is properly set up and maintained. 4. Make sure the motor has stopped and disconnect power before adjustments, maintenance, or service. 5. DO NOT expose to rain or dampness. 6. DO NOT modify this machine in any way. 7. DO NOT remove safety guards. 8. Never leave machine running unattended. 9. DO NOT operate under the influence of drugs or alcohol. 10. Maintain machine carefully to prevent accidents.</div> | |
| | Serial Number | | |
| Manufactured for Grizzly in Taiwan | | | |
| | | | |
| | | | |

For your convenience, we post all available manuals and manual updates for free on our website at **www.grizzly.com**. Any updates to your model of machine will be reflected in these documents as soon as they are complete.

Contact Info

We stand behind our machines. If you have any questions or need help, use the information below to contact us. Before contacting, please get the serial number and manufacture date of your machine. This will help us help you faster.

Grizzly Technical Support
1203 Lycoming Mall Circle
Muncy, PA 17756
Phone: (570) 546-9663
Email: techsupport@grizzly.com

We want your feedback on this manual. What did you like about it? Where could it be improved? Please take a few minutes to give us feedback.

Grizzly Documentation Manager
P.O. Box 2069
Bellingham, WA 98227-2069
Email: manuals@grizzly.com



Identification & Basic Controls





Figure 1. Main view of machine features and controls.

Use **Figures 1–5** and the following descriptions to gain an understanding of the features and basic controls of the table saw. This knowledge will be required to properly set up the machine for the test run.



- A. Flip Stops.** Used for quick crosscutting measurements.
- B. Crosscut Fence.** Used during crosscutting operations. Features a scale and multiple flip-style stop blocks for precise, repeatable crosscutting operations.
- C. Sliding Table**—Conveniently glides the workpiece through the blade with precision and ease.

- D. Blade Guard.** Maintains maximum protection around the saw blade, and a 2½" dust port effectively extracts dust from the cutting operation.
- E. Rip Fence.** Features micro-adjustment knob for precision adjustments. Fence face can be positioned for standard cutting operations, or in the lower position, for blade guard clearance during narrow ripping operations.
- F. Control Panel.** Features push-button controls for operating the many features of the saw.
- G. Blade Angle Handwheel.** Adjusts the angle of the saw blades.
- H. Blade Elevation Handwheel.** Adjusts the height of the main saw blade.
- I. Crosscut Table.** Provides a wide, stable platform for supporting full-size panels during crosscutting operations.






Figure 2. Fence controls.

- J. Fence Assembly Lock Down Lever.** Secures the fence assembly in position along the fence rail.
- K. Rip Fence Scale.** Allows precise measurements for rip cutting operations.
- L. Slide Lock Handle.** Secures the aluminum fence piece on its forward/backward slide track.
- M. Micro-Adjustment Lock Knob.** Secures the fence after it has been adjusted with the micro-adjustment knob.
- N. Micro-Adjustment Knob.** Precisely adjusts the fence.




Figure 3. Blades.

- O. Riving Knife—**Maintains kerf opening during cutting operations. This function is crucial in preventing kickback caused by the kerf closing behind the blade.
- P. Scoring Blade—**Small cutting blade that rotates opposite the main saw blade. The blade scores the workpiece before the actual cutting operation is performed preventing tear-out in laminate materials. The scoring blade is adjustable forward and backward, up and down, and in thickness of kerf.
- Q. Main Blade—**Performs the cutting operations.






Figure 4. Control panel.

- R. Power ON/OFF Switch.** Connects power to all motors in the saw, and can be disabled with the key.
 - S. Power Indicator Light.** Indicates a live power connection to the machine.
 - T. Main Blade OFF Button.** Stops the main saw blade motor.
 - U. Scoring Blade OFF Button.** Stops the scoring blade motor.
 - V. Primary Emergency Stop Button.** Disconnects power to both motors.
 - W. Scoring Blade ON Button.** Starts the scoring blade.
- Note:** *The main saw blade must be **ON** for the scoring blade to start.*
- X. Main Blade ON Button.** Starts the main saw blade.




Figure 5. Side controls.

- Y. Scoring Blade Elevation Knob.** Adjusts the height of the scoring blade.
- Z. Scoring Blade Alignment Knob.** Adjusts the side-to-side alignment of the scoring blade to the main blade.
- AA. Secondary Emergency Stop Button.** Disconnects power to both motors.



Glossary Of Terms

The following is a list of common definitions, terms and phrases used throughout this manual as they relate to this table saw and woodworking in general. Become familiar with these terms for assembling, adjusting or operating this machine. Your safety is **VERY** important to us at Grizzly!

Arbor: Metal shaft extending from the drive mechanism, to which saw blade is mounted.

Bevel Edge Cut: Tilting the arbor and saw blade to an angle between 0° and 45° to cut a beveled edge onto a workpiece.

Blade Guard: Metal or plastic safety device that mounts over the saw blade. Its function is to prevent the operator from coming into contact with the saw blade.

Crosscut: Cutting operation in which the crosscut fence is used to cut across the grain, or across the shortest width of the workpiece.

Dado Blade: Blade or set of blades that are used to cut grooves and rabbets.

Dado Cut: Cutting operation that uses a dado blade to cut a flat bottomed groove into the face of the workpiece.

Featherboard: Safety device used to keep the workpiece against the rip fence and against the table surface.

Kerf: The resulting cut or gap in the workpiece after the saw blade passes through during a cutting operation.

Kickback: An event in which the workpiece is propelled back towards the operator at a high rate of speed.

Parallel: Being an equal distance apart at every point along two given lines or planes. I.e. the rip fence face is parallel to the face of the saw blade.

Non-Through Cut: A sawing operation that requires the removal of the blade guard and riving knife. Dado and rabbet cuts are considered Non-Through Cuts because the blade does not protrude above the top face of the wood stock. Always remember to re-install the blade guard and riving knife after performing a non-through cut.

Perpendicular: Lines or planes that intersect and form right angles. I.e. the blade is perpendicular to the table surface.

Push Stick: Safety device used to push the workpiece through a cutting operation. Used most often when rip cutting thin workpieces.

Rabbet: Cutting operation that creates an L-shaped channel along the edge of the workpiece.

Riving knife: Metal plate located behind the blade. It maintains the kerf opening in the wood when performing a cutting operation.

Straightedge: A tool used to check the flatness, parallelism, or consistency of a surface(s).

Through Cut: A sawing operation in which the workpiece is completely sawn through.

Rip Cut: Cutting operation in which the rip fence is used to cut with the grain, or across the widest width of the workpiece.





MACHINE DATA SHEET

Customer Service #: (570) 546-9663 · To Order Call: (800) 523-4777 · Fax #: (800) 438-5901

MODEL G0451 SLIDING TABLE SAW-10HP

Product Dimensions:

Weight..... 1309 lbs.
Width (side-to-side) x Depth (front-to-back) x Height..... 105-1/2 x 117-1/2 x 49 in.
Footprint (Length x Width)..... 54-1/2 x 39 in.

Shipping Dimensions:

Type..... Wood Slat Crate
Content..... Machine
Weight..... 1680 lbs.
Length x Width x Height..... 103 x 46 x 43 in.

Electrical:

Power Requirement..... 220V or 440V, 3-Phase, 60 Hz
Minimum Circuit Size..... 40A at 220V, 20A at 440V
Switch..... Magnetic with Thermal Overload Protection
Switch Voltage..... 220V
Plug Included..... No
Recommended Plug/Outlet Type..... Hardwire Locking Switch
Voltage Conversion Kit..... Requires Part# G440VG0451
Phase Converter..... G7979

Motors:

Scoring

Type..... TEFC Induction
Horsepower..... 1 HP
Voltage..... 220/440V
Prewired..... 220V
Phase..... 3-Phase
Amps..... 3.6A at 220V, 1.8A at 440V
Speed..... 3450 RPM
Cycle..... 60 Hz
Number of Speeds..... 1
Power Transfer Belt Drive
Bearings..... Shielded and Lubricated

Main

Type..... TEFC Induction
Horsepower..... 10 HP
Voltage..... 220/440V
Prewired..... 220V
Phase..... 3-Phase
Amps..... 26A at 220V, 13A at 440V
Speed..... 3450 RPM
Cycle..... 60 Hz
Number of Speeds..... 1
Power Transfer Belt Drive
Bearings..... Shielded and Lubricated



Main Specifications:

Operation Information

| | |
|-------------------------------|-------------|
| Main Blade Size..... | 14 in. |
| Main Arbor Size..... | 1 in. |
| Scoring Blade Size..... | 120 mm |
| Scoring Blade Arbor Size..... | 22 mm |
| Main Blade Tilt..... | 0 - 45 deg. |
| Main Blade Speed..... | 4200 RPM |
| Scoring Blade Tilt..... | 0 - 45 deg. |
| Scoring Blade Speed..... | 8000 RPM |

Cutting Capacities

| | |
|--|-------------|
| Max Depth of Cut At 90 Deg..... | 4-1/2 in. |
| Max Depth of Cut At 45 Deg..... | 3-1/2 in. |
| Table With Rip Fence Max Cut Width..... | 32-5/8 in. |
| Sliding Table With Cross Fence Max Cut Width..... | 98-3/8 in. |
| Sliding Table With Cross Fence Max Cut Length..... | 126 in. |
| Miter Fence Cut Width At 45 Deg..... | 114-1/2 in. |

Table Information

| | |
|--|------------|
| Floor To Table Height..... | 33-1/2 in. |
| Table Size Length..... | 39-1/4 in. |
| Table Size Width..... | 24 in. |
| Table Size Thickness..... | 2-1/2 in. |
| Table Size With Ext Wings Length..... | 68 in. |
| Table Size With Ext Wings Width..... | 39-3/4 in. |
| Table Size With Ext Wings Thickness..... | 2-1/2 in. |
| Sliding Table Length..... | 98 in. |
| Sliding Table Width..... | 13-3/4 in. |
| Sliding Table Thickness..... | 6 in. |
| Sliding Table T Slot Top Width..... | 5/8 in. |
| Sliding Table T Slot Height..... | 5/8 in. |
| Sliding Table T Slot Bottom Width..... | 1-3/8 in. |

Fence Information

| | |
|------------------------|---|
| Fence Type..... | Single Lever Locking, Extruded Aluminum |
| Fence Size Length..... | 39-3/8 in. |
| Fence Size Width..... | 2-3/8 in. |
| Fence Size Height..... | 3-1/2 in. |
| Fence Stops..... | 2 |

Construction Materials

| | |
|---------------------------|------------------------------|
| Table..... | Cast Iron |
| Sliding Table..... | Aluminum |
| Base..... | Steel |
| Body Assembly..... | Steel |
| Cabinet..... | Steel |
| Trunnions..... | Cast Iron |
| Rollers..... | Steel |
| Fence Assembly..... | Extruded Aluminum |
| Rails..... | Chromed Steel |
| Guard..... | Plastic |
| Spindle Bearing Type..... | Radial Ball Bearing 6206-2RS |
| Paint..... | Powder Coated |

Other Related Information

| | |
|-----------------------|--------------|
| No of Dust Ports..... | 2 |
| Dust Port Size..... | 2-1/2, 5 in. |



Other Specifications:

Country Of Origin Taiwan
Warranty 1 Year
Serial Number Location Grizzly ID Label
Assembly Time 2-1/2 hours

Features:

Blade Guard with 2 1/2" Dust Port
5" Main Dust Port
Adjustable Scoring Knife Kerf
Adjustable Riving Knife
Mirco Adjustable, Single Lever Locking Fence













SLIDING TABLE SAW CAPACITIES

Customer Service #: (570) 546-9663 • To Order Call: (800) 523-4777 • Fax #: (800) 438-5901

MODEL G0451 14" SLIDING TABLE SAW

| | |
|---|--|
|  <p>Ripping Width</p> <p>32-5/8"</p> |  <p>Cross Cut</p> <p>98-3/8"</p> <p>126"</p> |
|  <p>Miter Cut 90° (push cut)</p> <p>33-1/2"</p> <p>126"</p> |  <p>Miter Cut 45° (push cut)</p> <p>126"</p> <p>49"</p> |
|  <p>Miter Cut 45°</p> <p>126"</p> <p>114-1/2"</p> |  <p>Cross Cut (fence not extended)</p> <p>98-3/8"</p> <p>73-1/8"</p> |
|  <p>Miter Cut 45° (push cut, fence not extended)</p> <p>34-1/2"</p> <p>49"</p> |  <p>Miter Cut 45° (fence not extended)</p> <p>73-1/8"</p> <p>114-1/2"</p> |



SECTION 1: SAFETY

WARNING

For Your Own Safety, Read Instruction Manual Before Operating this Machine

The purpose of safety symbols is to attract your attention to possible hazardous conditions. This manual uses a series of symbols and signal words intended to convey the level of importance of the safety messages. The progression of symbols is described below. Remember that safety messages by themselves do not eliminate danger and are not a substitute for proper accident prevention measures.



Indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, **COULD** result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTICE

This symbol is used to alert the user to useful information about proper operation of the machine.

WARNING

Safety Instructions for Machinery

OWNER'S MANUAL. Read and understand this owner's manual **BEFORE** using machine. Untrained users can be seriously hurt.

EYE PROTECTION. Always wear ANSI-approved safety glasses or a face shield when operating or observing machinery to reduce the risk of eye injury or blindness from flying particles. Everyday eyeglasses are not approved safety glasses.

HAZARDOUS DUST. Dust created while using machinery may cause cancer, birth defects, or long-term respiratory damage. Be aware of dust hazards associated with each workpiece material, and always wear a NIOSH-approved respirator to reduce your risk.

WEARING PROPER APPAREL. Do not wear clothing, apparel, or jewelry that can become entangled in moving parts. Always tie back or cover long hair. Wear non-slip footwear to avoid accidental slips which could cause a loss of workpiece control.

HEARING PROTECTION. Always wear hearing protection when operating or observing loud machinery. Extended exposure to this noise without hearing protection can cause permanent hearing loss.

MENTAL ALERTNESS. Be mentally alert when running machinery. Never operate under the influence of drugs or alcohol, when tired, or when distracted.



WARNING

DISCONNECTING POWER SUPPLY. Always disconnect machine from power supply before servicing, adjusting, or changing cutting tools (bits, blades, cutters, etc.). Make sure switch is in OFF position before reconnecting to avoid an unexpected or unintentional start.

APPROVED OPERATION. Untrained operators can be seriously hurt by machinery. Only allow trained or properly supervised people to use machine. When machine is not being used, disconnect power, remove switch keys, or lock-out machine to prevent unauthorized use—especially around children. Make workshop kid proof!

DANGEROUS ENVIRONMENTS. Do not use machinery in wet or rainy locations, cluttered areas, around flammables, or in poorly-lit areas. Keep work area clean, dry, and well-lighted to minimize risk of injury.

ONLY USE AS INTENDED. Only use machine for its intended purpose. Never modify or alter machine for a purpose not intended by the manufacturer or serious injury may result!

USE RECOMMENDED ACCESSORIES. Consult this owner's manual or the manufacturer for recommended accessories. Using improper accessories will increase the risk of serious injury.

CHILDREN & BYSTANDERS. Keep children and bystanders a safe distance away from work area. Stop using machine if children or bystanders become a distraction.

REMOVE ADJUSTING TOOLS. Never leave adjustment tools, chuck keys, wrenches, etc. in or on machine—especially near moving parts. Verify removal before starting!

SECURING WORKPIECE. When required, use clamps or vises to secure workpiece. A secured workpiece protects hands and frees both of them to operate the machine.

FEED DIRECTION. Unless otherwise noted, feed work against the rotation of blades or cutters. Feeding in the same direction of rotation may pull your hand into the cut.

FORCING MACHINERY. Do not force machine. It will do the job safer and better at the rate for which it was designed.

GUARDS & COVERS. Guards and covers can protect you from accidental contact with moving parts or flying debris. Make sure they are properly installed, undamaged, and working correctly before using machine.

NEVER STAND ON MACHINE. Serious injury or accidental contact with cutting tool may occur if machine is tipped. Machine may be damaged.

STABLE MACHINE. Unexpected movement during operations greatly increases the risk of injury and loss of control. Verify machines are stable/secure and mobile bases (if used) are locked before starting.

AWKWARD POSITIONS. Keep proper footing and balance at all times when operating machine. Do not overreach! Avoid awkward hand positions that make workpiece control difficult or increase the risk of accidental injury.

UNATTENDED OPERATION. Never leave machine running while unattended. Turn machine **OFF** and ensure all moving parts completely stop before walking away.

MAINTAIN WITH CARE. Follow all maintenance instructions and lubrication schedules to keep machine in good working condition. An improperly maintained machine may increase the risk of serious injury.

CHECK DAMAGED PARTS. Regularly inspect machine for damaged parts, loose bolts, mis-adjusted or mis-aligned parts, binding, or any other conditions that may affect safe operation. Always repair or replace damaged or mis-adjusted parts before operating machine.

EXPERIENCING DIFFICULTIES. If at any time you are experiencing difficulties performing the intended operation, stop using the machine! Contact our Technical Support Department at (570) 546-9663.



Additional Safety for Table Saws

WARNING

HAND POSITIONING. Never purposely touch a saw blade during operation. Always keep hands/fingers out of the blade path; place them where they cannot slip into the blade accidentally. Never reach around, behind, or over the blade. Touching a spinning saw blade will cause serious laceration or amputation injuries.

BLADE GUARD. Use the blade guard for all “through cuts” for which it can be used. (A through cut is an operation where the blade cuts completely through the top of the workpiece.) Make sure the blade guard is installed and adjusted correctly; promptly repair or replace it if damaged. Always re-install blade guard immediately after operations that require its removal. Operating saw with the blade guard removed greatly increases the risk of severe laceration or amputation injuries from accidental blade contact.

RIVING KNIFE. Use the riving knife for all “non-through cuts” for which it can be used. (A non-through cut is an operation where the blade does not cut through the top of the workpiece.) Make sure the riving knife is aligned and positioned correctly; and promptly repair or replace it if damaged. Using the riving knife incorrectly will increase the risk of kickback or accidental blade contact.

KICKBACK. Kickback occurs when the saw blade ejects the workpiece back toward the operator. Know how to reduce the risk of kickback, and learn how to protect yourself if it does occur.

FEEDING WORKPIECE. Feeding the workpiece incorrectly will increase risk of kickback. Never start the saw with a workpiece touching the blade; allow the blade to reach full speed before cutting. Only feed the workpiece against the direction of blade rotation. Always use some type of guide (fence, miter gauge, sliding table or sled, etc.) to feed the workpiece in a straight line. Never back a workpiece out of a cut or try to move it backwards or sideways after starting a cut. Feed cuts all the way through to completion. Never perform any operation “freehand” (making a cut without using a fence, miter gauge, or other guide).

FENCE. Make sure the fence remains properly adjusted and parallel with the blade. Always lock the fence in place before using. Using or adjusting the fence incorrectly will increase risk of kickback.

PUSH STICKS/BLOCKS. Use push sticks or push blocks whenever possible to keep your hands farther away from the blade while cutting; in the event of an accident these devices will often take damage that would have happened to hands/fingers.

CUT-OFF PIECES. Never use your hands to move cut-offs away from the blade while the saw is running. If a cut-off becomes trapped between the blade and table insert, turn the saw **OFF** and allow the blade to completely stop before removing it.

BLADE ADJUSTMENTS. Adjusting the blade height or tilt during operation increases the risk of crashing the blade and sending metal fragments flying with deadly force at the operator or bystanders. Only adjust the blade height and tilt when the blade is completely stopped and the saw is **OFF**.

CHANGING BLADES. Always disconnect power before changing blades. Changing blades while the saw is connected to power greatly increases the injury risk if saw is accidentally powered up.

DAMAGED SAW BLADES. Never use blades that have been dropped or otherwise damaged. Damaged blades can fly apart and strike the operator with shards of metal.

DADO AND RABBET OPERATIONS. DO NOT attempt dado or rabbeting operations without first reading those sections in this manual. Dado and rabbeting operations require special attention because they must be performed with the blade guard removed.


CUTTING CORRECT MATERIAL. Never cut materials not intended for this saw; only cut natural and man-made wood products, laminate covered wood products, and some plastics. Cutting metal, glass, stone, tile, etc. increases the risk of operator injury due to kickback or flying particles.



SECTION 2: POWER SUPPLY

Availability

Before installing the machine, consider the availability and proximity of the required power supply circuit. If an existing circuit does not meet the requirements for this machine, a new circuit must be installed. To minimize the risk of electrocution, fire, or equipment damage, installation work and electrical wiring must be done by a qualified electrician in accordance with all applicable codes and standards.



Full-Load Current Rating

The full-load current rating is the amperage a machine draws at 100% of the rated output power. On machines with multiple motors, this is the amperage drawn by the largest motor or sum of all motors and electrical devices that might operate at one time during normal operations.

Full-Load Current Rating at 220V .. 29.6 Amps
Full-Load Current Rating at 440V .. 14.8 Amps

The full-load current is not the maximum amount of amps that the machine will draw. If the machine is overloaded, it will draw additional amps beyond the full-load rating.

If the machine is overloaded for a sufficient length of time, damage, overheating, or fire may result—especially if connected to an undersized circuit. To reduce the risk of these hazards, avoid overloading the machine during operation and make sure it is connected to a power supply circuit that meets the requirements in the following section.

Circuit Information

A power supply circuit includes all electrical equipment between the breaker box or fuse panel in the building and the machine. The power supply circuit used for this machine must be sized to safely handle the full-load current drawn from the machine for an extended period of time. (If this machine is connected to a circuit protected by fuses, use a time delay fuse marked D.)

CAUTION

For your own safety and protection of property, consult a qualified electrician if you are unsure about wiring practices or electrical codes in your area.

Note: *The circuit requirements listed in this manual apply to a dedicated circuit—where only one machine will be running at a time. If this machine will be connected to a shared circuit where multiple machines will be running at the same time, consult a qualified electrician to ensure that the circuit is properly sized for safe operation.*

Circuit Requirements for 220V

This machine is prewired to operate on a 220V power supply circuit that has a verified ground and meets the following requirements:

Nominal Voltage 220V/240V
Cycle 60 Hz
Phase 3-Phase
Power Supply Circuit 40 Amps

Circuit Requirements for 440V

This machine can be converted to operate on a 440V power supply (refer to **Voltage Conversion** instructions) that has a verified ground and meets the following requirements:

Nominal Voltage 440V/480V
Cycle 60 Hz
Phase 3-Phase
Power Supply Circuit 20 Amps



Connection Type

A power cord is not included, because this machine must be permanently connected to the power supply. A disconnecting means, such as a locking switch (see **Figure** below), must be provided to allow the machine to be disconnected (isolated) from the power supply when required. This installation must be performed by a qualified electrician in accordance with all applicable electrical codes and ordinances.




Figure 6. Typical setup of a permanently connected machine.

Grounding Instructions

In the event of a malfunction or breakdown, grounding provides a path of least resistance for electrical current to reduce the risk of electric shock. A permanently connected machine must be connected to a grounded metal permanent wiring system; or to a system having an equipment-grounding conductor. All grounds must be verified and rated for the electrical requirements of the machine. Improper grounding can increase the risk of electric shock!

WARNING

Serious injury could occur if you connect the machine to power before completing the setup process. **DO NOT** connect to power until instructed later in this manual.

Extension Cords

Since this machine must be permanently connected to the power supply, an extension cord cannot be used.



Voltage Conversion

The Model G0451 can be rewired for 440V operation. The necessary parts for this procedure can be purchased by calling our customer service at (800) 523-4777 and ordering part #P04510016.

This rewiring job must be inspected by an electrician or qualified service personnel before the saw is connected to the power source. Also, the motors can be accessed easier for rewiring if the blade is moved to 0° (90° to table) before beginning.

To rewire the machine for 440V operation:

1. DISCONNECT SAW FROM POWER!
2. Open the electrical panel and locate the voltage transformer shown in **Figure 7**.




Figure 7. Inside view of the control panel.

3. Pull the fuse that is in the “220” slot and push it into the “440” slot (see **Figure 8**).




Figure 8. Fuse installed at the 220V location.

4. Remove the main motor overload relay (see **Figure 9**) and replace it with the overload relay from the 440V conversion kit. Turn the dial on the main motor overload relay to 9A.




Figure 9. Motor overload relays.

5. On the scoring motor overload relay, change the dial setting to 2.6A.
6. Open the motor cabinet door and remove the motor wiring covers from the main motor and the scoring motor (see **Figure 10**).





Figure 10. Motor locations.

7. Re-wire the motors as shown on the diagrams that are placed on the inside of the motor wiring covers.




SECTION 3: SETUP




!WARNING

This machine presents serious injury hazards to untrained users. Read through this entire manual to become familiar with the controls and operations before starting the machine!




!WARNING

Wear safety glasses during the entire setup process!



!WARNING

The Model G0451 is a heavy machine that weighs over 1300 lbs. Serious personal injury may occur if safe moving methods are not followed. To be safe, you will need assistance and power equipment when moving the shipping crate and machine.



!WARNING

SUFFOCATION HAZARD!

Keep children and pets away from plastic bags or packing materials unpacked with this machine. Discard immediately.

Needed for Setup

The following are needed to complete the setup process, but are not included with your machine.

Description

Qty

- Another Person 1
- Safety Glasses 1 for Each Person
- Cleaner/Degreaser As Needed
- Disposable Shop Rags..... As Needed
- Power Lifting Equipment
(Rated for at least 1500 lbs) 1
- Lifting Straps
(Rated for at least 1500 lbs. each) 2
- Straightedge 4' (or longer) 1
- Main Blade 12" or 14" 1
- Phillips Screwdriver #2 1
- Hex Wrenches 3, 4, 6, & 8mm 1 Each
- Wrenches or Sockets 16 & 18mm..... 1 Each
- Dust Collection System 1
- 5" Dust Hose (length as needed) 1
- 5" Hose Clamp 2
- 2½" Dust Hose (length as needed) 1
- Power Cord (length as needed) 1
- Power Disconnect Box w/Locking Switch ... 1

Unpacking

Your machine was carefully packaged for safe transportation. Remove the packaging materials from around your machine and inspect it. If you discover any damage, *please call us immediately at (570) 546-9663 for advice.*

Save the containers and all packing materials for possible inspection by the carrier or its agent. *Otherwise, filing a freight claim can be difficult.*

When you are completely satisfied with the condition of your shipment, inventory the contents.



Inventory

The following is a description of the main components shipped with your machine. Lay the components out to inventory them.

If any non-proprietary parts are missing (e.g. a nut or a washer), we will gladly replace them; or for the sake of expediency, replacements can be obtained at your local hardware store.

| Box 1: (Figure 11) | Qty |
|--------------------------------|-----|
| A. Large Extension Table | 1 |
| B. Support Brace | 1 |
| C. Small Extension Table..... | 1 |




Figure 11. Box 1 contents.

| Box 2 & 3: (Figure 12) | Qty |
|-------------------------------|-----|
| D. Crosscut Fence | 1 |
| E. Rip Fence Round Rail | 1 |
| F. Crosscut Table Brace | 1 |
| G. Rip Fence Scale | 1 |
| H. Rip Fence | 1 |




Figure 12. Box 2 & 3 contents.

Model G0451 (Mfg. Since 5/10)

| Box 4: (Figure 13) | Qty |
|-------------------------|-----|
| I. Crosscut Table | 1 |




Figure 13. Box 4 contents.

| Box 5 & 6: (Figure 14) | Qty |
|-----------------------------------|-----|
| J. Edge Shoe..... | 1 |
| K. Sliding Table Lock Plate | 1 |
| L. Flip Stops | 2 |
| M. Hold Down..... | 1 |
| N. Sliding Table End Handle..... | 1 |




Figure 14. Box 5 & 6 contents.

NOTICE

If you cannot find an item on this list, check the mounting location on the machine or the packaging materials. Sometimes parts are pre-installed for shipping, or they become hidden by packaging materials.



| Box 7: (Figures 15– 16) | | Qty |
|--------------------------------|-----------------------------------|------------|
| O. | Rip Fence Body..... | 1 |
| Q. | Blade Guard/Dust Hood..... | 1 |
| P. | Push Stick | 1 |
| R. | Dust Collection Hose Support..... | 1 |
| S. | Toolbox | 1 |
| | —Flat Belt 15 x 880mm..... | 1 |
| | —Riving Knife | 1 |
| | —Arbor Wrench 30mm | 1 |
| | —Hose Clamps 2½" | 2 |
| | —Feet M16-2 x 100..... | 4 |
| | —Arbor Wrench 8mm | 1 |




Figure 15. Box 7 contents.



Figure 16. Box 7 contents continued.

| Component Hardware (Not Shown) | | Qty |
|---------------------------------------|---|------------|
| • | Push Handle M12-1.75 x 12 (Sliding Table) . | 1 |
| • | Flat Washer 12mm (Push Handle) | 1 |
| • | T-Nut M12-1.75 (Push Handle)..... | 1 |
| • | Set Screw M6-1.0 x 12 (Small Table) | 2 |
| • | Cap Screw M10-1.5 x 20 (Small Table) | 2 |
| • | Lock Washer 10mm (Small Table) | 2 |
| • | Flat Washer 10mm (Small Table) | 2 |
| • | Cap Screw M10-1.5 x 20 (Large Table)..... | 4 |
| • | Lock Washer 10mm (Large Table) | 4 |
| • | Flat Washer 10mm (Large Table)..... | 4 |
| • | Set Screw M6-1.0 x 12 (Large Table) | 4 |
| • | Cap Screw M10-1.5 x 30 (Support Brace)... | 4 |
| • | Flat Washer 10mm (Support Brace)..... | 4 |
| • | Lock Washer 10mm (Support Brace) | 4 |
| • | Hex Nut M10-1.5 (Support Brace) | 2 |
| • | Hex Bolts M6-1 x 25 (Scale Bar)..... | 3 |
| • | Flat Washers 6mm (Scale Bar) | 3 |
| • | Lock Washers 6mm (Scale Bar) | 3 |
| • | Hex Nuts M6-1 (Scale Bar) | 3 |
| • | Lock Handles M10-1.5 x 12 (Rip Fence) | 2 |
| • | Knob M10-1.5 x 70 (Rip Fence)..... | 1 |
| • | Adjustable Ring w/Set Screw (Rip Rail) | 1 |
| • | End Washer 8mm (Rip Rail)..... | 1 |
| • | Lock Washer 8mm (Rip Rail) | 1 |
| • | Cap Screw M8-1.25 x 16 (R Rail)..... | 1 |
| • | Adjustable Handle M12-1.75 x 55 (Crosscut Table) | 1 |
| • | Flat Washer 12mm (Crosscut Table)..... | 1 |
| • | T-Nut M12-1.75 (Crosscut Table) | 1 |
| • | T-Nut M8-1.25 (Crosscut Brace)..... | 2 |
| • | Knob M8-1.25 x 50 (Crosscut Brace, Fence)..... | 3 |
| • | Flat Washer 8mm (Crosscut Brace) | 2 |
| • | Center Stud M8-1.25 x 10 (Crosscut Fence) | 1 |
| • | Fiber Washer 8mm (Crosscut Fence) | 1 |
| • | T-Bolt M8-1.25 x 60 (Crosscut Fence)..... | 1 |
| • | T-Nut M8-1.25 (Crosscut Fence) | 2 |
| • | Knob M8-1.25 (Crosscut Fence)..... | 1 |
| • | Knob M8-1.25 x 25 (Crosscut Fence)..... | 1 |
| • | Flat Washer 8mm (Crosscut Fence)..... | 1 |
| • | Block (Crosscut Fence) | 1 |
| • | Cap Screw M8-1.25 x 35 (Crosscut Fence) | 1 |
| • | Lock Washer 8mm (Crosscut Fence)..... | 1 |
| • | Button Hd Cap Screw M8-1.25 x 40 (Guard) | 1 |
| • | Flat Washer 8mm (Guard)..... | 1 |



Cleanup

The unpainted surfaces of your machine are coated with a heavy-duty rust preventative that prevents corrosion during shipment and storage. This rust preventative works extremely well, but it will take a little time to clean.

Be patient and do a thorough job cleaning your machine. The time you spend doing this now will give you a better appreciation for the proper care of your machine's unpainted surfaces.


There are many ways to remove this rust preventative, but the following steps work well in a wide variety of situations. Always follow the manufacturer's instructions with any cleaning product you use and make sure you work in a well-ventilated area to minimize exposure to toxic fumes.


Before cleaning, gather the following:

- Disposable Rags
- Cleaner/degreaser (WD-40 works well)
- Safety glasses & disposable gloves
- Plastic paint scraper (optional)

Basic steps for removing rust preventative:

1. Put on safety glasses.
2. Coat the rust preventative with a liberal amount of cleaner/degreaser, then let it soak for 5–10 minutes.
3. Wipe off the surfaces. If your cleaner/degreaser is effective, the rust preventative will wipe off easily. If you have a plastic paint scraper, scrape off as much as you can first, then wipe off the rest with the rag.
4. Repeat **Steps 2–3** as necessary until clean, then coat all unpainted surfaces with a quality metal protectant to prevent rust.

| | |
|--|---|
|  | <p>! WARNING</p> <p>Gasoline or products with low flash points can explode or cause fire if used to clean machinery. Avoid cleaning with these products.</p> |
|--|---|

| | |
|--|---|
|  | <p>! CAUTION</p> <p>Many cleaning solvents are toxic if concentrated amounts are inhaled. Only work in a well-ventilated area.</p> |
|--|---|

| |
|---|
| <p>NOTICE</p> <p>Avoid chlorine-based solvents, such as acetone or brake parts cleaner, that may damage painted surfaces. Test all cleaners in an inconspicuous area before using to make sure they will not damage paint.</p> |
|---|




Site Considerations

Weight Load

Refer to the **Machine Data Sheet** for the weight of your machine. Make sure that the surface upon which the machine is placed will bear the weight of the machine, additional equipment that may be installed on the machine, and the heaviest workpiece that will be used. Additionally, consider the weight of the operator and any dynamic loading that may occur when operating the machine.

Space Allocation

Consider the largest size of workpiece that will be processed through this machine and provide enough space around the machine for adequate operator material handling or the installation of auxiliary equipment. With permanent installations, leave enough space around the machine to open or remove doors/covers as required by the maintenance and service described in this manual. **See below for required space allocation.**



Physical Environment

The physical environment where your machine is operated is important for safe operation and the longevity of its components. For best results, operate this machine in a dry environment that is free from excessive moisture, hazardous chemicals, airborne abrasives, or extreme conditions. Extreme conditions for this type of machinery are generally those where the ambient temperature range exceeds 41°–104°F; the relative humidity range exceeds 20–95% (non-condensing); or the environment is subject to vibration, shocks, or bumps.

Electrical Installation

Place this machine near an existing power source. Make sure all power cords are protected from traffic, material handling, moisture, chemicals, or other hazards. Make sure to leave access to a means of disconnecting the power source or engaging a lockout/tagout device.

Lighting

Lighting around the machine must be adequate enough that operations can be performed safely. Shadows, glare, or strobe effects that may distract or impede the operator must be eliminated.






Figure 17. Minimum working clearances.



Moving & Placing Base Unit



To remove the saw base unit from the crate pallet:

1. Remove the top of the crate and position the forklift forks together and directly above the saw.
2. Place two lifting straps over the forks and attach the ends to the lifting bolts, as shown in **Figure 18**.



Figure 18. Lifting the saw base unit.

WARNING

DO NOT lift the table saw any higher than necessary to clear the floor. Serious personal injury and damage to the machine may occur if safe moving methods are not followed.

3. Lift the saw base unit and move it to your predetermined location.
4. Before lowering the saw into position, place safety blocks under the frame and thread the four foot studs into the frame at least half of their length.
5. Remove the safety blocks and lower the saw onto the feet as shown in **Figure 19** and remove the forklift straps.



Figure 19. Foot studs placed in base feet.

6. Place a level on the saw table and adjust foot studs so the saw table is level from left-to-right and from front-to-back. This will allow the table to slide smoothly.
7. Lock the foot studs in position by tightening their jam nuts against the machine body.



Assembly & Setup

Before shipping, the sliding table was set at the factory to be even with the main table and parallel with the blade.

To assemble the sliding table saw:

1. Install the end handle, as shown in **Figure 20**.




Figure 20. Sliding table end handle.

2. Rotate the table lock to unlock the sliding table. The sliding table is locked in place when the table lock is in the position shown in **Figure 20**.
3. Install the push handle into the table, as shown in **Figure 21**, with a 12mm flat washer and M12-1.75 T-nut.




Figure 21. Sliding table push handle installed.

4. Thread two M6-1 x 12 set screws into the small holes in the small extension table. Make sure the set screws do not stick out from the mating surface.
5. Loosely attach the small extension table with two M10-1.5 x 20 cap screws, two 10mm lock washers, and two 10mm flat washers as shown in **Figure 22**.

Note: The cap screws will be tightened during a later step.




Figure 22. Small extension table attached.

6. Loosely attach the large extension table with four M10-1.5 x 20 cap screws, four 10mm lock washers, and four 10mm flat washers, as shown in **Figure 23**, and thread in four M6-1 x 12 set screws.

Note: The cap screws will be tightened during a later step.



Figure 23. Large extension table attached.



7. Attach the support brace and dust collection hose support to the table with four M10-1.5 x 30 cap screws, four 10mm lock washers, four 10mm flat washers, and two M10-1.5 hex nuts, as shown in **Figure 24**.




Figure 24. Support brace and dust collection hose support installation.

8. Use a straightedge, as shown in **Figure 25**, to make sure the extension table is even with the cast iron table. Use the set screws under the extension tables to level the top surfaces, then tighten all the mounting cap screws.



Figure 25. Checking with a straightedge.

9. Thread an M10-1.5 hex nut all the way onto two M10-1.5 x 20 cap screws, then install the cap screws where shown in **Figure 26** to hold the small extension table level. Tighten the hex nuts against the table support to lock the cap screws in place.




Figure 26. Small extension table support cap screws (table removed for photo clarity).

10. Mount the scale bar to the cast iron table and large extension table, making sure it is even with the top of the tables. Use the three M6-1 x 25 hex bolts, three 6mm flat washers, three 6mm lock washers, and three M6-1 hex nuts, as shown in **Figure 27**, to mount it. (The top of the hex bolts slide into the scale bar.)




Figure 27. Attaching the scale bar.



11. Make sure each of the four rail studs are pre-assembled with a 12mm flat washer and two M12-1.75 hex nuts, then thread them into the round rail, as shown in **Figure 28**.




Figure 28. Installing studs with hardware into the round rail.

12. Insert the studs into the tables as shown in **Figure 29**. Put a 12mm flat washer, 12mm lock washer and a M12-1.75 hex nut on the end of each stud to hold the round rail on the tables. Do not tighten the hex nuts at this time.




Figure 29. Installing the round rail.

13. Slide the rip fence body onto the round rail. Thread the lock handles M10-1.5 x 12 and knob M10-1.5 x 70 into the rip fence body, where shown in **Figure 30**.




Figure 30. Rip fence handles.

14. Slide the aluminum rip fence onto the clamping plate as shown in **Figure 31**, and lock it with the fence lock handle.




Figure 31. Installing the rip fence.

15. Open the motor compartment and remove the red shipping braces from both motors, then re-install the shipping brace fasteners back into the holes from which they came.
16. Move the blade arbor tilt to 0° and raise it as far as it will go.



17. Install the flat belt on the scoring motor and arbor pulley as shown in **Figure 32**.

Note: The scoring motor adjusts by lifting it up. The weight of the scoring motor dictates the correct belt tension.




Figure 32. Flat belt installed on scoring motor and arbor pulley (table removed for clarity).

18. Slide the table all the way forward to access the blade arbor and pull open the blade guard (see **Figure 33**).




Figure 33. Main blade arbor components.

19. Use the arbor wrench to remove the arbor nut and arbor flange.

Note: The arbor nut has left hand threads and loosens by turning clockwise.

! CAUTION

Before proceeding with the next steps, wear leather gloves to protect your hands when handling and installing the blade.

20. Slide the blade over the arbor with the teeth facing the right side of the saw, and re-install the arbor flange and the arbor nut. The main blade arbor nut has left-hand threads and tightens counterclockwise. Hold the arbor with one arbor wrench and tighten the nut with the other arbor wrench as shown in **Figure 34**.




Figure 34. Installing the main blade.

21. Slide the rip fence over until it just touches the blade.
22. Adjust the mounting position of the round rail until the rip fence evenly touches the entire width of the blade from front to back.

Note: To adjust the mounting position of the round rail, use the hex nuts (on the round rail studs) that are on both sides of the tables.



23. Check if the metal part of the rip fence rests on the surface of the table.

Note: The rip fence body will scratch the table surface if the ride height is not adjusted correctly. Only the roller should touch the table surface.

—If the rip fence body **does not** rest on the table, then the fence is correctly adjusted.

—If the rip fence body **does** rest on the table, remove the rip fence and turn it upside down. Loosen the set screw shown in **Figure 35** and rotate the hex bolt to raise the roller. Tighten the set screw to lock the ride height and recheck how the rip fence rests on the table.




Figure 35. Rip fence height adjustment.

24. Check the height of the rip fence rail by sliding the rip fence along the rail and comparing the gap between the rip fence body and the tables.
25. Adjust the height of the rip fence rail, then tighten all of the hex nuts to secure the round rail in place.

26. Loosen the riving knife center bolt, slide the riving knife over the bolt as shown in **Figure 36**, and slightly tighten.



Figure 36. Installing the riving knife.

27. Position the riving knife about 3mm or 1/8" away from the nearest carbide tooth on the main blade.

Note: For a quick gauge, use the 3mm hex wrench to find the correct spacing between the blade and the riving knife, as shown in **Figure 37**.



Figure 37. Adjusting the riving knife.

28. Tighten the center bolt to secure the riving knife in position.



29. Use both arbor wrenches, as shown in **Figure 38**, to verify that the scoring blade arbor nut is tight. (The scoring blade arbor nut has right-hand threads and tightens clockwise.)

Note: If the scoring blade is not pre-installed, install it now, making sure to place the arbor flange between the arbor nut and blade during installation.




Figure 38. Removing the scoring blade.

30. Move the scoring blade tilt to 0° (blade 90° to table), then raise it up, using the vertical adjustment knob (**Figure 39**), until enough of the wedge shaped teeth are exposed from the table surface to equal the same width as the main blade teeth.




Figure 39. Scoring blade adjustment controls.

31. Move the rip fence against the main blade (or scoring blade) as shown in **Figure 40**.




Figure 40. Fence used to align blades.

32. Adjust the scoring blade, using the horizontal adjustment controls, until the rip fence evenly touches both blades.
33. Move the rip fence against the blades again. Loosen the screws securing the scale bar, line up the 0" mark on the scale with the left edge of the rip fence, then tighten the scale bar mounting screws.
34. Set the rip fence to 1/8", slide the adjustable ring with set screw on the round rail against the fence housing. Without moving the ring, move the fence housing out of the way, and secure the set screw on the ring, as shown in **Figure 41**. When installed correctly, this ring will prevent the fence from contacting the blade.




Figure 41. Securing the adjustable ring.



35. Move the blade guard back to its original position, and move the sliding table back to center.
36. Place the end washer (**Figure 42**) on the end of the round rail and secure it with the M8-1.25 x 16 cap screw and 8mm lock washer.




Figure 42. End washer on round rail.

37. Thread the M12-1.75 x 55 adjustable handle, with a 12mm flat washer, through the crosscut table and into a M12-1.75 T-nut, as shown in **Figure 43**.



Figure 43. Installing the adjustable handle.

38. With the help of an assistant, place the crosscut table on the pivot pin of the swing arm and slide the T-nut into the T-slot in the sliding table (see **Figure 44**).




Figure 44. Installing the crosscut table.

39. Slide two M8-1.25 T-nuts into the crosscut table brace. Align the T-nuts in the crosscut table brace with the holes in the crosscut table, and thread the two M8-1.25 x 50 knobs, with two 8mm flat washers, into the T-nuts as shown in **Figure 45**.




Figure 45. Installing the crosscut table brace.



40. Install the components shown in **Figure 46** on the crosscut fence.




Figure 46. Crosscut fence assembly.

41. Position the center stud and the T-bolt over the placement holes shown in **Figure 47**, then tighten the center stud.




Figure 47. Crosscut fence placement.

42. Thread the M8-1.25 knob with an 8mm flat washer onto the T-bolt to secure the crosscut fence.
43. Slide the blade guard/dust hood over the riving knife, and attach it with an M8-1.25 x 40 button head cap screw and an 8mm flat washer.
44. (Optional) If needed, slide the edge shoe and hold down clamp into the table T-slot, and tighten the respective knob/handle. Position where necessary. (The front cover picture shows these items installed.)

! CAUTION

DO NOT operate the Model G0451 without an adequate dust collection system. This saw creates substantial amounts of wood dust while operating. Failure to use a dust collection system can result in short and long-term respiratory illness.

Required CFM at 5" Dust Port: 625 CFM
Required CFM at 2½" Dust Port: 150 CFM

Do not confuse this CFM recommendation with the rating of the dust collector. To determine the CFM at the dust port, you must consider these variables: (1) CFM rating of the dust collector, (2) hose type and length between the dust collector and the machine, (3) number of branches or wyes, and (4) amount of other open lines throughout the system. Explaining how to calculate these variables is beyond the scope of this manual. Consult an expert or purchase a good dust collection "how-to" book.

45. Secure a 5" dust hose to the dust port located under the saw table (**Figure 48**).




Figure 48. 5" dust port location.



46. Attach the blade guard/dust hood to the riveting knife with the M8-1.25 x 40 button head cap screw and 8mm flat washer. (The blade guard/dust hood **MUST** be installed.)
47. Attach a 2½" dust hose to the dust port, as shown in **Figure 49**.



Figure 49. 2½" Dust port location.

48. Run the 2½" hose over the hose support, as shown in **Figure 50**.




Figure 50. Dust hose support in use.

49. Run ground wires through the dust hoses and attach the wires to the machine to protect against static electricity.

Power Connection

Before connecting the saw to power, read through **SECTION 2: POWER SUPPLY** to check that your setup follows the safety and circuit requirements for this machine.

To connect the saw to the power source:

1. Open the power connection box shown in **Figure 51**.




Figure 51. Power connection box.

2. Connect the power wires to the terminals shown in **Figure 52**, tighten the strain relief so the wires can't be pulled from the terminals, then close the power connection box.

Note: When using a phase converter, connect the manufactured power leg to the *S* terminal to prevent damage.




Figure 52. Main terminal box.



Test Run

After the machine has been connected to the power source, the machine **MUST** be test run to make sure all the controls are working properly.

The test run includes verifying that the safety disabling components on the machine work correctly.

Before beginning the test run, review the controls shown in **Figures 53 & 54**.




Figure 53. Main power controls.



Figure 54. Emergency stop switch #2.

WARNING

If the machine does not operate as stated in this section, review the troubleshooting section in this manual. If you need additional help, call Tech Support at (570) 546-9663. DO NOT place a machine into regular operation if you suspect that it is malfunctioning or serious injury could occur.

To test run the saw:

1. Put on safety glasses, make sure any bystanders are out of the way, and that all tools have been removed from the saw.
2. Insert the key into the power switch and turn it clockwise.
3. Push in, then rotate both emergency stop switches clockwise until they pop out. This resets the emergency stop switches so the machine can operate.
4. One at a time, press the blade ON buttons. The blades should startup and run smoothly without any problems.

—If any problems occur, press the nearest emergency stop switch.
5. One at a time, press the blade OFF buttons. The blades should stop running. As the main blade comes to a stop, watch the direction that it is spinning.

—If the main blade is rotating counterclockwise, disconnect the saw from power and exchange wires R & T in the power connection box.
6. Depress the #1 emergency stop switch.



7. Press the blade ON buttons. Nothing should happen.

—If the stop switch is working correctly, reset the switch.

8. Repeat **Steps 6–7** with the #2 emergency stop switch.
9. Make sure both emergency stop buttons are reset before continuing.
10. Open the cabinet door at the rear of the machine. This opens the limit switch at the door.
11. Press the blade ON buttons. Nothing should happen.
12. Close and latch the cabinet door.

13. Turn the key switch **OFF** and DISCONNECT SAW FROM POWER!

14. Move the sliding table all the way forward, then open the orange blade guard. This opens the blade guard limit switch.

15. Connect the saw to the power source and turn the power switch key ON.


16. (During this step, be prepared to immediately press the #1 emergency stop switch if the blades start operating.) Press the blade ON buttons. Nothing should happen.

17. Turn the key switch **OFF** and DISCONNECT SAW FROM POWER!

18. Close the orange blade guard and move the sliding table back to the center of the machine.



SECTION 4: OPERATIONS




!WARNING

To reduce the risk of serious injury when using this machine, read and understand this entire manual before beginning any operations.

!WARNING

Damage to your eyes, lungs, and hearing could result from using this machine without proper protective gear. Always wear safety glasses, a respirator, and hearing protection when operating this machine.



!WARNING

For Your Own Safety Read Instruction Manual Before Operating Saw

- Wear eye protection.
- Use saw-blade guard and riving knife for every operation for which it can be used, including all through sawing.
- Keep hands out of the line of saw blade.
- Use a push-stick when required.
- Pay particular attention to instructions on reducing risk of kickback.
- Do not perform any operation freehand.
- Never reach around or over saw blade.

NOTICE

If you have never used this type of machine or equipment before, seek training from an experienced machine operator or read "how to" books before beginning any projects. Regardless of the content in this section, Grizzly Industrial will not be held liable for accidents caused by lack of training.

Operation Overview

The purpose of this overview is to provide the novice machine operator with a basic understanding of how the machine is used during a typical operation, so the controls/components discussed later in this manual are easier to understand.

Due to the generic nature of this overview, it is not intended to be an instructional guide. To learn more about specific operations, read this entire manual, read "how to" books, and seek additional training from experienced machine operators.

To complete a typical operation, the operator does the following:

- Examines the workpiece to make sure it is suitable for cutting.
- Adjusts the blade tilt, if necessary, to the correct angle of the desired cut.
- Adjusts the blade height approximately $\frac{1}{4}$ " higher than the thickness of the workpiece.
- Adjusts the fence to the desired width of cut then locks it in place.
- Checks the outfeed side of the machine for proper support and to make sure the workpiece can safely pass all the way through the blade without interference.
- Puts on safety glasses and a respirator, and locates push sticks if needed.
- Starts the saw.
- Feeds the workpiece all the way through the blade while maintaining firm pressure on the workpiece against the table and fence, and keeping hands and fingers out of the blade path and away from the blade.
- Stops the machine immediately after the cut is complete.



Workpiece Inspection

Some workpieces are not safe to cut on this machine or may need to be modified before they can be safely cut. **Before cutting, inspect all workpieces for the following:**

- **Material Type:** This machine is intended for cutting natural and man-made wood products, laminate covered wood products, and some plastics. Cutting drywall or cementitious backer board creates extremely fine dust and may reduce the life of the motor bearings. This machine is NOT designed to cut metal, glass, stone, tile, etc.; cutting these materials with a table saw greatly increases the risk of injury and damage to the saw or blade.
- **Foreign Objects:** Nails, staples, dirt, rocks and other foreign objects are often embedded in wood. While cutting, these objects can become dislodged and hit the operator, cause kickback, or break the blade, which might then fly apart. Always visually inspect your workpiece for these items. If they can't be removed, DO NOT cut the workpiece.
- **Large/Loose Knots:** Loose knots can become dislodged during the cutting operation. Large knots can cause kickback and machine damage. Choose workpieces that do not have large/loose knots or plan ahead to avoid cutting through them.
- **Wet or "Green" Stock:** Cutting wood with a moisture content over 20% causes unnecessary wear on the blades, increases the risk of kickback, and yields poor results.
- **Excessive Warping:** Workpieces with excessive cupping, bowing, or twisting are dangerous to cut because they are unstable and may move unpredictably when being cut.
- **Minor Warping:** Slightly cupped workpieces can be safely supported with cupped side facing the table or fence; however, workpieces supported on the bowed side will rock during the cut, which could cause kickback.

Non-Through & Through Cuts

Non-Through Cuts

A non-through cut is a sawing operation where the blade does not protrude above the top face of the wood stock, as shown in the **Figure** below.




Figure 55. Example of a non-through cut.

Examples of non-through cuts include dados and rabbets. Non-through cuts have a higher risk of injury from kickback because the blade guard must be removed. However, the riving knife **MUST** be installed because it still provides some protection.

Note: A dado blade can NOT be used with this table saw.

Through Cuts

A through cut is a sawing operation in which the workpiece is completely sawn through, as shown in the **Figure** below. Examples of through cuts are rip cuts, cross cuts, miter cuts, and beveled cuts. The blade guard assembly **MUST** be used when performing through cuts.




Figure 56. Example of a through cut (blade guard not shown for illustrative clarity).



Blade Guard & Riving Knife

The term "blade guard" refers to the assembly that consists of the guard and spreader assembly (see **Figure 57** below). Each of these components have important safety functions.




Figure 57. Blade guard assembly components.

Understanding Blade Guard

The guard encloses the top of the blade to reduce the risk of accidental blade contact and contain flying chips or dust.

The guard is designed to lift as the workpiece is pushed into the blade, remain in contact with the workpiece during the cut, then return to a resting position against the table when the cut is complete. When installed and properly maintained, the guard is an excellent tool for reducing the risk of injury when operating the table saw.

To ensure that the guard does its job effectively, it **MUST** be installed and adjusted so that it moves up and down properly to accommodate workpieces and maintain coverage over the blade.

Understanding Spreader & Riving Knife

The spreader and riving knife are metal plates that prevent the freshly cut workpiece from pinching the backside of the blade and causing a kick-back. These items also act as a barrier to shield hands from being pulled into the blade if a kick-back occurs and the operator is reaching behind the blade. (Reaching behind the blade is a major safety risk and should not be done).

The spreader is used with the blade guard for through cuts. The riving knife is used without the blade guard for non-through cuts.

WARNING

To ensure that the spreader or riving knife works correctly, it must be correctly aligned and adjusted to the blade.

When to Use the Blade Guard

The blade guard **MUST** be installed on the saw for all normal through cuts (defined on **Page 36**).

Sometimes the blade guard or its components can get in the way when cutting very narrow workpieces or other specialized cuts. Because the blade guard is provided to decrease your risk of injury, it should not be used if it gets in the way of making a safe cut. Use good judgment!

In general, the blade guard **MUST** remain installed on the saw—unless a specific operation requires its removal. If the blade guard is removed for specific operations, always immediately replace it after those operations are complete.

When to Use the Riving Knife Only

Use the riving knife without the blade guard for any non-through cuts (defined on **Page 36**) or narrow/specialized cuts in which the blade guard gets in the way of a safe cut.

Always immediately replace the blade guard when these cuts are complete!



Blade Guard Spreader & Riving Knife Installation & Adjustment

The blade guard spreader and riving knife must be correctly installed, adjusted, and aligned in order to provide the maximum safety benefit. Aside from the height setting, the blade guard spreader should be installed and adjusted in the same manner as described for the riving knife.

The spreader/riving knife attaches to the mounting block, as shown in **Figure 58**.




Figure 58. Installing spreader/riving knife on the mounting block.

Secure the riving knife so that the top of it is 1–5mm below the top level of the blade, as shown in **Figure 59**.




Figure 59. Riving knife height setting below blade.

The height difference between the riving knife and the blade allows the workpiece to pass over the blade during non-through cuts (those in which the blade does not cut all the way through the thickness of the workpiece).

The spreader/riving knife prevents the freshly cut workpiece from pinching the blade and causing kickback. For maximum effectiveness, the spreader/riving knife must be positioned 3–8mm from the blade, as shown in **Figure 60**.




Figure 60. Allowable top and bottom distances between spreader/riving knife and blade.

Once the spreader/riving knife is properly positioned behind the blade, verify that it is also aligned with the blade by placing a straightedge along the top and bottom locations shown in **Figure 61**.




Figure 61. Checking spreader/riving knife alignment with blade at the top and bottom.

The spreader/riving knife should be parallel with the blade along its length at both positions and should be in the "Alignment Zone" shown in **Figure 62**.




Figure 62. Verifying that spreader/riving knife is in the alignment zone behind the blade.

If the spreader/riving knife is not aligned or parallel with the blade, refer to **Adjusting Mounting Block** on **Page 70**.



Guard Installation & Removal

The guard may need to be removed from the spreader in order to make room to properly adjust the position of the spreader. The guard is secured in place with a mounting screw (see **Figure 63**). Remove the mounting screw to pull the guard off of the spreader.




Figure 63. Blade guard mounted to spreader.

When re-installing the guard, the mounting screw must be left loose enough that the guard can freely pivot up and down, but not so loose that there is side-to-side play when pivoting.

Testing Guard for Correct Operation

After installing the blade guard, you must verify that it functions correctly before making a cut. To test the blade guard operation, lift up the front end about 4" then release it.

- If the blade guard freely drops down against the table surface, then it is functioning correctly and is ready for operation.
- If the blade guard remains in the position where you released it, or it does not drop down against the surface of the table, then the mounting screw is too tight. Loosen it a little and repeat this test until the guard functions correctly.
- If the blade guard feels loose and easily moves back and forth as you raise it, then the mounting screw is too loose. Tighten it a little and repeat this test until the guard functions correctly.

Blade Requirements

The riving knife included with this machine is 0.1" (2.5mm) thick and is only designed for 14" diameter blades.

When choosing a main blade, make sure the blade size meets the requirements listed below. The thickness of the blade body and teeth can be measured with calipers or any precision measuring device.

Blade Size Requirements:

- Body Thickness: 0.09"–0.1" (2.3mm–2.5mm)
- Kerf (Tooth) Thickness: 0.102"–0.128" (2.6mm–3.2mm)

Blade Selection

This section on blade selection is by no means comprehensive. Always follow the saw blade manufacturer's recommendations to ensure safe and efficient operation of your table saw.

Ripping Blade Features:

- Best for cutting with the grain
- 20-40 teeth
- Flat-top ground tooth profile
- Large gullets for large chip removal




Figure 64. Ripping blade.



Crosscut blade features:

- Best for cutting across the grain
- 60-80 teeth
- Alternate top bevel tooth profile
- Small hook angle and a shallow gullet




Figure 65. Crosscutting blade.

Laminate blade features:

- Best for cutting plywood or veneer
- 40-80 teeth
- Triple chip tooth profile
- Very shallow gullet




Figure 67. Laminate blade.

Combination blade features:

- Designed to cut both with and across grain
- 40-50 teeth
- Alternate top bevel and flat, or alternate top bevel and raker tooth profile
- Teeth are arranged in groups
- Gullets are small and shallow (similar to a cross-cut blade), then large and deep (similar to a ripping blade)




Figure 66. Combination blade.

Thin Kerf Blade: A blade with thinner kerf than a standard blade. Since the spreader/riving knife included with this table saw is sized for standard blades, thin kerf blades cannot be used on this saw unless they meet the **Blade Requirements** specified in this manual; otherwise, they will increase the risk of kickback.



Changing Main Blade

The Model G0451 performs best when using high quality, sharp blades. Whenever the main blade starts to get dull, sharpen or replace it with a new blade.

Any time you change blade size, adjust the riving knife to appropriately to the blade (see **Page 38**).

To change the main blade:

1. DISCONNECT SAW FROM POWER!
2. Move the blade tilt to 0° (blade 90° to table) and raise the main blade as far as it will go.
3. Move the sliding table all the way forward to expose the internal blade cover, as shown in **Figure 68**.




Figure 68. Internal blade cover exposed.

4. Pull the blade cover away from the blades to expose the mounting assembly. (The internal blade cover is held in place with a magnet.)

CAUTION

Before proceeding with the next step, wear gloves to protect your hands while handling and installing the blade.

5. Use the arbor wrenches, as shown in **Figure 69**, to remove the arbor nut and arbor flange, then pull the old blade off the arbor. *The arbor nut has left hand threads and loosens by turning clockwise.*




Figure 69. Replacing the main blade.

6. Install the blade as shown in **Figure 70**, making sure the teeth face toward the scoring blade. DO NOT overtighten the arbor nut.




Figure 70. Main blade installation and order of assembly.

- If you changed the diameter of the blade during this procedure, adjust the riving knife the blade.
7. Move the blade cover back into its original position next to the blades, then center the sliding table.



Changing & Adjusting Scoring Blade

The scoring blade included with the Model G0451 has wedge shaped teeth. With this style of scoring blade, the kerf thickness is adjusted by changing the height of the scoring blade. Raising the scoring blade higher increases the kerf thickness.

Changing Scoring Blade

1. DISCONNECT SAW FROM POWER!
2. Move the blade tilt to 0° (blade 90° to table), and raise the scoring blade all the way up.
3. Move the sliding table all the way forward to expose the internal blade cover that covers the blades and riving knife.
4. Pull the blade guard away from the riving knife to expose the mounting assembly. (The internal blade cover is held in place with a magnet.)
5. To remove the scoring blade, use the arbor wrenches to remove the arbor nut and arbor flange (see **Figure 71**). **Note:** The arbor nut has right-hand threads and loosens by turning counterclockwise.



Figure 71. Removing the scoring blade.

6. Adjust the width of the scoring blade to equal the kerf thickness of the main blade.

The scoring blade included with the sliding table saw has wedge shaped teeth. The kerf thickness is adjusted by changing the height of the scoring blade until enough of the tooth is exposed to equal the main blade kerf. If you are re-installing this style of blade, adjust the kerf after **Step 7** with the scoring blade vertical adjustment controls.

7. Install the new scoring blade, re-install the arbor flange and the arbor nut, and tighten them against the blade set.
8. Move the blade cover back into its original position next to the blades, then center the sliding table.

Adjusting Scoring Blade

1. DISCONNECT SAW FROM POWER!
2. Place a straightedge across the body of the main blade (not the teeth) and align the body of the scoring blade to the main blade, by turning the horizontal adjustment control shown in **Figure 72**.




Figure 72. Scoring blade adjustment controls.

2. Adjust the height of the scoring blade, by turning the vertical adjustment control (see **Figure 72**), until the exposed portion equals the kerf thickness of the main blade.
3. Move the blade cover back into its original position, then center the sliding table.
4. Perform a test cut and check for chip-out. If there is chip-out, re-adjust the scoring blade and repeat the test/adjustment until correct.



Rip Cutting

The Model G0451 has the capability of rip cutting full size panels (**Figure 73**). The sliding table removes the burden of sliding a large and heavy panel over a stationary table surface.




Figure 73. Rip cutting with the sliding table.

This saw also has the capability of rip cutting smaller boards, using the machine as a traditional table saw (**Figure 74**). Smaller, lighter boards are easier to slide across the stationary cast iron table surface to the right of the saw blade.



Figure 74. Traditional rip cutting.

Determine which cutting operation will be best suited for the workpiece to be ripped.

—To use the sliding table, read the instructions titled “Rip Cutting w/Sliding Table.”

—To use the machine as a traditional table saw, skip ahead to “Rip Cutting w/Rip Fence.”

Rip Cutting with Sliding Table

1. Drop the crosscut fence into the center stud hole and rotate it until the block shown in **Figure 75** touches the 90° stop bolt.
2. Check to make sure the fence is at 90° and adjust it as described in **Squaring Crosscut Fence to Blade** on **Page 69** if necessary.




Figure 75. Crosscut fence mounting locations.

3. Slide the protection block next to the blade teeth to calibrate the scale, then tighten the lock knob.

Note: The scale will not be accurate if the protection block is cut.

4. Set a flip stop to the desired width-of-cut.
5. Position the blade guard to the correct height for your workpiece.
6. Load the workpiece onto the table saw. The set up should look similar to **Figure 73**.
7. Take all the necessary safety precautions, then perform the cutting operation.



Rip Cutting with Rip Fence

1. Slide the crosscut table out of the way.
2. Lock the sliding table into a stationary position (see **Figure 76**).




Figure 76. Sliding table lock.

3. Place the fence in the vertical position for larger workpieces, or in the horizontal position for angled cuts and for small workpieces (see **Figure 77**).




Figure 77. Rip fence positions.

4. Slide the leading end of the rip fence so it is even with the center of the main saw blade as shown in **Figure 78**.

Note: This technique allows the finished cut-off piece to “fall” away from the blade when the cutting operation is complete; reducing the possibility of kickback.




Figure 78. Rip fence even with center of blade (guard removed from spreader for clarity).

5. Lift the lock lever and position the rip fence to approximately the desired width-of-cut.
6. Tighten down the micro-adjust lock knob (**Figure 79**) and turn the micro-adjust knob to zero in on the desired width-of-cut.




Figure 79. Rip fence micro-adjusting controls.

7. Push down the lock lever, then perform the cutting operation.



Crosscutting

The Model G0451 can crosscut full size panels with the fence in the forward or rear position, although it is easier to load full size panels with the crosscut fence mounted in the forward position (see **Figure 80**).




Figure 80. Crosscutting full size panel.

Mounting the crosscut fence in the rear position (**Figure 81**) gives greater stability for crosscutting smaller panels.




Figure 81. Crosscutting smaller panels.

Lastly, this machine has the capability of crosscutting workpieces while using the rip fence as a cut-off gauge (**Figure 82**).




Figure 82. Crosscutting workpieces using the rip fence as a cut-off gauge.

Determine which cutting operation will be best suited for the workpiece to be crosscut.

- If you will be crosscutting full size panels, then skip ahead to “Crosscutting Full Size Panels.”
- If you will be crosscutting smaller panels, then skip ahead to “Crosscutting Smaller Panels.”
- If you will be crosscutting workpieces using the rip fence as a cut-off gauge, then skip ahead to “Crosscutting Using Rip Fence as a Cut-Off Gauge.”



Crosscutting Full Size Panels

1. Install the crosscut fence in the forward mounting location shown in **Figure 83** and lock it in place.
2. Check to make sure the fence is at 90° and adjust it as described in "Squaring Crosscut Fence to Blade" on **Page 69** if necessary.




Figure 83. Crosscut fence mounting points.

3. Set either flip stop to the desired width-of-cut. **Note:** *Extend the crosscut fence slide if the workpiece is more than 74".*
4. Load the workpiece onto the table saw. The set up should look similar to **Figure 80**.
5. Once all the necessary safety precautions have been taken, perform the cutting operation.

Crosscutting Smaller Panels

1. Install the crosscut fence in the rear mounting points shown in **Figure 83** and lock it in place.
2. Check to make sure the fence is at 90° and adjust it as described in "Squaring Crosscut Fence to Blade" on **Page 69** if necessary.
3. Set either flip stop to the desired width-of-cut. **Note:** *Extend the crosscut fence slide if the workpiece is more than 74".*

4. Load the workpiece onto the table saw. The set up should look similar to **Figure 81**.
5. Once all the necessary safety precautions have been taken, perform the cutting operation.

Crosscutting Using Rip Fence as a Cut-Off Gauge

1. Install the crosscut fence in the rear mounting points shown in **Figure 83** and lock it in place.
2. Check to make sure the fence is at 90° and adjust it as described in **Squaring Crosscut Fence to Blade** on **Page 69** if necessary.
3. Position the rip fence for the desired width.
4. Load the workpiece onto the table saw. The setup should look similar to **Figure 82**.
5. Slide the leading end of the rip fence behind the front edge of the blade as shown in **Figure 84**. (**This step is critical to reduce the risk of blade binding and kickback.**)




Figure 84. Correct rip fence position when using it as a cut-off gauge.

6. Take all the necessary safety precautions, then perform the cutting operation.



Miter Cutting

The crosscut fence allows miter cuts from 0° through 135°. The table mounted miter scale has a resolution of 1°.

To perform a miter cut:

1. Slide the crosscut table to the front edge of the sliding table and lock it in place.
2. Place the crosscut fence center stud in the center stud hole of the crosscut table. The fence can be installed as shown in **Figure 85** for 90° to 135° cuts, or as shown in **Figure 86** for 0° to 90° cuts.



Figure 85. Fence set-up for 90° to 135° cuts.

3. Rotate the fence to the desired angle and use the lock knob to lock the fence in place.
4. Position the flip stop according to the length of the workpiece you want to cut off to the left of the blade.
5. Load the workpiece onto the table saw. The set up should look similar to **Figure 86**.



Figure 86. Example of miter cutting operation.

6. Once all the necessary safety precautions have been taken, perform the cutting operation.



Dado Cutting

Commonly used in furniture joinery, a dado is a straight channel cut in the face of the workpiece. Typically, dados can be cut using either a dedicated dado blade or a standard saw blade. **Figure 87** shows a cutaway view of a dado cut being made with a dado blade.




Figure 87. Example of a dado cut with a dado blade.

IMPORTANT: A dado blade cannot be used with this machine; therefore, all dados cut with this machine must be done with a standard blade.

Cutting Dados with Standard Blade

A ripping blade (described on **Page 39**) is typically the best blade to use for cutting dados when using a standard blade, because it removes sawdust very efficiently.

To use a standard saw blade to cut dados:

1. DISCONNECT SAW FROM POWER!
2. Ensure that the riving knife is installed and properly adjusted.
3. Mark the width of the dado cut on the workpiece. Include marks on the edge of the workpiece so the cut path can be aligned when the workpiece is lying on the table.
4. Raise the blade up to the desired depth of cut (depth of dado channel desired).
5. Set up the saw for the type of cut you need to make, depending on if it is a rip cut.
6. Align the blade to cut one of the dado sides, as shown in **Figure 88**.




Figure 88. First cut for a single-blade dado.

7. Reconnect the saw to the power source and turn the saw **ON**. Allow the blade to reach full speed, then perform the cutting operation.
8. Repeat the cutting operation on the other side of the dado channel, as shown in **Figure 89**.




Figure 89. Second cut for a single blade dado.

9. Make additional cuts (see **Figure 90**) in the center of the dado to clear out the necessary material. The dado is complete when the channel is completely cleared out.




Figure 90. Additional single blade dado cuts.



Rabbet Cutting

Commonly used in furniture joinery, a rabbet is an L-shaped groove cut in the edge of the workpiece. Typically, rabbets can be cut with either a dado blade or a standard saw blade; however, because the Model G0453 cannot accept dado blades, rabbets must be cut with a standard saw blade only.

⚠ CAUTION

Always use push sticks, featherboards, push paddles and other safety accessories whenever possible to increase safety and control during operations which require that the blade guard be removed from the saw. **ALWAYS** replace the blade guard after the operation is complete.

Cutting Rabbets with a Standard Blade

A ripping blade is typically the best blade to use for cutting rabbets when using a standard blade because it removes sawdust very efficiently. (See **Page 39** for blade details.) Also, a sacrificial fence is not required when cutting rabbets with a standard blade.

To cut rabbets with the standard blade:

1. DISCONNECT SAW FROM POWER!
2. Ensure that the riving knife and standard table insert are installed.
3. Mark the width of the rabbet cut on the edge of the workpiece, so you can clearly identify the intended cut while it is laying flat on the saw table.
4. Raise the blade up to the desired depth of cut (depth of rabbet channel desired).
5. Stand the workpiece on edge, as shown in **Figure 91**, then adjust the fence so the blade is aligned with the inside of your rabbet channel.





Figure 91. Rabbet cutting with a standard blade.

⚠ WARNING



DO NOT place a tall board on edge when cutting a rabbet. Overly tall workpieces cannot be properly supported with the fence and can easily shift during operation, causing kickback or loss of control. Instead, use another tool to cut these types of rabbets.

6. Reconnect the saw to the power source, then perform the cut.
7. Lay the workpiece flat on the table, as shown in **Figure 92**, adjust the saw blade height to intersect with the first cut, then perform the second cut to complete the rabbet.




Figure 92. Second cut to create a rabbet.



Resawing

WARNING

Resawing operations require proper procedures to avoid serious injury. Extra care must be taken to prevent kickback when resawing. Any tilting or movement of the workpiece away from the fence will cause kickback. Be certain that stock is flat and straight. Failure to follow these warnings could result in serious personal injury.

Resawing is the process of cutting a thick piece of stock into one or more thinner pieces. Although resawing can be done with a table saw, we strongly recommend that you use a bandsaw instead.

A bandsaw is the ideal machine for resawing, and resawing with one is fairly easy and safe. A table saw is not intended for resawing, and resawing with one is difficult and dangerous due to the increased risk of kickback from binding and deep cuts, and the increased risk of injury from having to remove the guard.

If you insist on resawing with a table saw, DO NOT do so without using a resaw barrier and wearing a full face shield. The following instructions describe how to build a resaw barrier.

IMPORTANT: This table saw can only resaw wood that is less than 8" tall, and the rip fence must be used (rather than the sliding table).

Making Resaw Barrier

The resaw barrier acts in tandem with the rip fence when resawing to provide tall support for the workpiece to minimize the probability of it binding against the blade and causing kickback.

Tools Needed:

Qty

| | |
|----------------------------|-------------|
| Table Saw | 1 |
| Jointer and Planer | Recommended |
| Clamps | 2 Minimum |
| Drill and Drill Bits | 1 |

Components Needed for Resaw Barrier:

| | |
|--|-----------|
| Wood* $\frac{3}{4}$ " x $7\frac{1}{2}$ " x (Length of Fence) | 1 |
| Wood* $\frac{3}{4}$ " x 3" x (Length of Fence) | 1 |
| Wood Screws #8 x 2" | 4 |
| Wood Glue | As Needed |

* Only use furniture grade plywood, kiln dried hardwood, or HDPE plastic to prevent warping.

To build the resaw barrier:

1. Cut your wood pieces to the size specified above. If you are using hardwood, cut the pieces oversize, then joint and plane them to the correct size to make sure they are square and flat.
2. Pre-drill and countersink four holes approximately $\frac{3}{8}$ " from the bottom of the $7\frac{1}{2}$ " tall wood piece.
3. Glue the end of the 3" board, then clamp the boards at a 90° angle with the larger board in the vertical position, as shown in **Figure 93**, then fasten together with the wood screws.




Figure 93. Resaw barrier.



Resawing Operations

The table saw motor is pushed to its limits when resawing. If the motor starts to bog down, slow down your feed rate. Motor overloading and blade wear can be reduced by using a ripping blade. Ripping blades are designed to clear the sawdust quickly.

Components Needed for Resawing:

| | |
|-------------------------------|---|
| Ripping Blade | 1 |
| Clamps | 2 |
| Shop Made Resaw Barrier | 1 |

WARNING

You may experience kickback during this procedure. Stand to the side of the blade path and wear safety glasses or a face shield to prevent injury.

To perform resawing operations:

1. DISCONNECT SAW FROM POWER!
2. Install the rip fence in the vertical position, and remove the blade guard so only the riving knife will be used during the cut.
3. Place the workpiece against the rip fence and slide the resaw barrier against the workpiece. Now clamp the resaw barrier to the top of the table saw (see **Figure 94**).




Figure 94. Resaw setup.

4. Lower the blade completely below the table, and slide the workpiece over the blade to make sure it moves smoothly and fits between the resaw barrier and fence.

5. Raise the blade approximately an inch, or close to half the height of the workpiece, whichever is less.

WARNING

Operations requiring the blade guard to be removed increase the risk of accidental contact with the blade. To reduce this risk, use push sticks/paddles and featherboards to keep your hands at a safe distance from the blade throughout the entire cut. Always replace guard after completing the cut!

6. Plug in the table saw, turn it **ON**, and use a push stick to feed the workpiece through the blade using a slow, steady feed rate.
7. Flip the workpiece end for end, keeping the same side against the fence, and run the workpiece through the blade.
8. Repeat **Steps 4–6** until the blade is close to half of the height of the board to be resawn. The ideal completed resaw cut will leave a $\frac{1}{8}$ " connection when the resawing is complete as shown in **Figure 94**. Leaving a $\frac{1}{8}$ " connection will reduce the risk of kickback.




Figure 95. Resaw cut completed.

9. Turn **OFF** the table saw, then separate the parts of the workpiece and hand plane the remaining ridge.
10. When finished resawing, remove the resaw barrier and re-install the blade guard.



SECTION 5: SHOP MADE SAFETY ACCESSORIES

Featherboards

Easily made from scrap stock, featherboards provide an added degree of protection against kickback, especially when used together with push sticks. They also maintain pressure on the workpiece to keep it against the fence or table while cutting, which makes the operation easier and safer because the cut can be completed without the operator's hands getting near the blade. The angled ends and flexibility of the fingers allow the workpiece to move in only one direction.

Making a Featherboard

This sub-section covers the two basic types of featherboards: 1) Those secured by clamps to the table or fence, or 2) those secured by a wood runner that mounts in the table saw miter slot.

Material Needed for Featherboard Mounted with Clamps

Hardwood $\frac{3}{4}$ " x 3" x 10" (Minimum)
Hardwood $\frac{3}{4}$ " x 6" x 28" (Maximum) 1

Material Needed for Featherboard Mounted in Miter Slot

Hardwood $\frac{3}{4}$ " x 3" x 10" (Minimum)
Hardwood $\frac{3}{4}$ " x 6" x 28" (Maximum) 1
Hardwood $\frac{3}{8}$ " x (Miter Slot Width) x 5"L 1
Wing Nut $\frac{1}{4}$ "-20 1
Flat Head Screw $\frac{1}{4}$ "-20 x 2" 1
Flat Washer $\frac{1}{4}$ "-20 1

To make a featherboard:

1. Cut a hardwood board approximately $\frac{3}{4}$ " thick to size. The length and width of the board can vary according to your design. Most featherboards are 10"–28" long and 3"–6" wide. Make sure the wood grain runs parallel with the length of the featherboard, so the fingers you will create in **Step 3** will bend without breaking.

2. Cut a 30° angle at one end of the board.
3. Make a series of end cuts with the grain $\frac{3}{8}$ "– $\frac{1}{4}$ " apart and 2"–3" long, as shown in **Figure 96 (A)**. Alternatively, start cuts at 2"–3" deep, then make them progressively deeper, as shown in **Figure 96 (B)**. Cuts made across the grain will result in weak fingers that will easily break.




Figure 96. Patterns for featherboards (top view shown).

When complete, the fingers should flex when pushed with moderate pressure. If the fingers do not flex, they are too thick.

Note: We recommend using a bandsaw for making fingers because it tends to be safer. A table saw can be used, but it will over-cut the underside of the ends, produce a thicker kerf, and require you to stop the blade half-way through the cut, which can be dangerous.

If you are securing the featherboard with clamps, no further steps are necessary. Your featherboard is complete! If you are making a featherboard that mounts in the miter slot, continue with **Step 4**.



4. Rout a $\frac{1}{4}$ "- $\frac{3}{8}$ " wide slot 4"-5" long in the workpiece and 1"-2" from the short end of the featherboard (see **Figure 97**).




Figure 97. Slot routed in featherboard.

5. Cut a miter bar that will fit in the table miter slot approximately 5" long, as shown in **Figure 98**.

Tip: Consider making the miter bar longer for larger featherboards—approximately half the length of the total featherboard—to support the force applied to the featherboard during use.




Figure 98. Miter bar pattern.

6. Drill a $\frac{1}{4}$ " hole in the center of the bar, then countersink the bottom to fit a $\frac{1}{4}$ "-20 flat head screw.
7. Mark a 4" line through the center of the countersunk hole in the center, then use a jig saw with a narrow blade to cut it out.
8. Assemble the miter bar and featherboard with a $\frac{1}{4}$ "-20 x flat head screw, flat washer, and a wing nut (see **Figure 99**). Congratulations! Your featherboard is complete.




Figure 99. Assembling miter slot featherboard components.

Tip: The length of the flat head screw depends on the thickness of the featherboard—though $1\frac{1}{2}$ " to 2" lengths usually work.

Now, proceed to **Mounting Featherboard in Miter Slot** on **Page 54**.



Mounting Featherboards w/Clamps

1. Lower the saw blade, then adjust the fence to the desired width and secure it.
2. Place the workpiece against the fence, making sure it is 1" in front of the blade.
3. Place a featherboard on the table away from the blade so all fingers point forward and contact the workpiece (see **Figure 100**).




Figure 100. Example of featherboards secured with clamps.

4. Secure the featherboard to the table with a clamp.
5. Check the featherboard by pushing it with your thumb to ensure it is secure.
—If the featherboard moves, tighten the clamp more.
6. Mount a second featherboard to the fence with another clamp (see **Figure 100**), then repeat **Step 5** to ensure it is secure.

Mounting Featherboard in Miter Slot

1. Lower the saw blade, then adjust the fence to the desired width and secure it.
2. Place the workpiece evenly against the fence, making sure it is 1" in front of the blade.
3. Slide the featherboard miter bar into the miter slot, making sure the fingers slant toward the blade, as shown in **Figure 101**.




Figure 101. Featherboard installed in miter slot and supporting workpiece for ripping cut.

4. Position the fingered edge of the featherboard against the edge of the workpiece, so that all of the fingers contact the workpiece. Slide the featherboard toward the blade until the first finger is nearly even with the end of the workpiece, which should be 1" away from the blade.
5. Double check the workpiece and the featherboard to ensure they are properly positioned as described in **Step 4**. Then secure the featherboard to the table. Check the featherboard by hand to make sure it is tight.

Note: The featherboard should be placed firmly enough against the workpiece to keep it against the fence but not so tight that it is difficult to feed the workpiece.



Push Sticks

When used correctly, push sticks reduce the risk of injury by keeping hands away from the blade while cutting. In the event of an accident, a push stick can also absorb damage that would have otherwise happened to hands or fingers.

Using a Push Stick

Use push sticks whenever your hands will get within 12" of the blade. To maintain control when cutting large workpieces, start the cut by feeding with your hands then use push sticks to finish the cut, so your hands are not on the end of the workpiece as it passes through the blade.

Feeding: Place the notched end of the push stick against the end of the workpiece (see inset **Figure** below), and move the workpiece into the blade with steady downward and forward pressure.

Supporting: A second push stick can be used to keep the workpiece firmly against the fence while cutting. When using a push stick in this manner, only apply pressure before the blade; otherwise, pushing the workpiece against or behind the blade will increase the risk of kickback (see "Push Stick Prohibition Zone" in the **Figure** below).




Figure 102. Using push sticks to rip narrow stock.




Figure 104. Template for a basic shop-made push stick (not shown at actual size).



Push Blocks

When used correctly, a push block reduces the risk of injury by keeping hands away from the blade while cutting. In the event of an accident, a push block often takes the damage that would have otherwise happened to hands or fingers.

Using a Push Block

A push block can be used in place of or in addition to a push stick for feeding workpieces into the blade. Due to their design, push blocks allow the operator to apply firm downward pressure on the workpiece that could not otherwise be achieved with a push stick.

The push block design on this page can be used in two different ways (see inset **Figure** below). Typically, the bottom of the push block is used until the end of the workpiece reaches the blade.

The notched end of the push block is then used to push the workpiece the rest of the way through the cut, keeping the operator's hands at a safe distance from the blade. A push stick is often used at the same time in the other hand to support the workpiece during the cut (see "Using a Push Stick" on previous page).




Figure 106. Using a push block and push stick to make a rip cut.




Figure 107. Template for a shop-made push block (shown at 50% of full size).



Narrow-Rip Auxiliary Fence & Push Block

There are designs for hundreds of specialty jigs that can be found in books, trade magazines, and on the internet. These types of jigs can greatly improve the safety and consistency of cuts. They are particularly useful during production runs when dozens or hundreds of the same type of cut need to be made.

The narrow-rip auxiliary fence and push block system shown in this section is an example of a specialty jig that can be made to increase the safety of very narrow rip cuts.

Material Needed for Narrow Rip Auxiliary Fence & Push Block

Hardwood $\frac{3}{4}$ " x 3" x Length of Fence 1
 Plywood $\frac{3}{4}$ " x $5\frac{1}{4}$ " x Length of Fence 1
 Wood Screws #8 x $1\frac{1}{2}$ " 8

Material Needed for Push Block

Hardwood or Plywood $\frac{3}{4}$ " x 15" x $5\frac{5}{8}$ " 1
 Hardwood or Plywood $\frac{3}{4}$ " x 10" x 5"–9" 1
 Cyanoacrylate Wood Glue Varies
 Wood Screws #8 x $1\frac{1}{2}$ " As Needed

Making a Narrow-Rip Push Block for an Auxiliary Fence

1. Cut a piece of $\frac{3}{4}$ " thick plywood $5\frac{1}{4}$ " wide and as long as your table saw fence; cut a piece of $\frac{3}{4}$ " thick hardwood 3" wide and as long as your table saw fence, as shown in **Figure 108**.




Figure 108. Auxiliary fence dimensions.

Note: We recommend cutting the hardwood board oversize, then jointing and planing it to the correct size to make sure the board is square and flat. Only use furniture grade plywood or kiln dried hardwood to prevent warping.

2. Pre-drill and countersink eight pilot holes $\frac{3}{8}$ " from the bottom of the 3" wide board, then secure the boards together with eight #8 x $1\frac{1}{2}$ " wood screws, as shown in **Figure 109**.




Figure 109. Location of pilot holes.

3. Using the $\frac{3}{4}$ " material you used in the previous steps, cut out pieces for the push block per the dimensions shown in **Figure 110**; for the handle, cut a piece 10" long by 5"–9" high and shape it as desired to fit your hand.




Figure 110. Push block dimensions and construction.

4. Attach the handle to the base with #8 x $1\frac{1}{2}$ " wood screws, and attach the lip to the base with cyanoacrylate type wood glue.



Using the Auxiliary Fence and Push Block

1. Place the auxiliary fence on the table and clamp it to the fence at both ends, then adjust the distance between the auxiliary fence and the blade—this determines how wide the workpiece will be ripped (see **Figure 111**).





Figure 111. Adjusting ripping distance between blade and auxiliary fence.

2. Install the blade guard.



3. Place the workpiece 1" behind the blade and evenly against the table and the auxiliary fence.




Figure 112. Push block in position to push workpiece through blade.

4. Turn the saw **ON**, then begin ripping the workpiece using a push stick for side support.

As the workpiece nears the end of the cut, place the push block on the auxiliary fence with the lip directly behind the workpiece, then release the push stick just before it is even with the blade (see **Figure 113**).

Guide the workpiece the rest of the way through the cut with the push block.




Figure 113. Ripping with push block.

! WARNING

Turn the saw **OFF** and allow the blade to come to a complete stop before removing the cut-off piece. Failure to follow this warning could result in serious personal injury.



SECTION 6: AFTERMARKET ACCESSORIES FROM GRIZZLY

⚠ WARNING

Some aftermarket accessories can be installed on this machine that could cause it to function improperly, increasing the risk of serious personal injury. To minimize this risk, only install accessories recommended for this machine by Grizzly.

NOTICE

Refer to the newest copy of the Grizzly Catalog for other accessories available for this machine.

Call 1-800-523-4777 To Order

H7833—Fully Enclosed Blade Guard

This fully enclosed blade guard was specially designed for the Model G0451, and dramatically improves dust collection over the standard dust hood. This is important if the saw will be used for cutting a lot of OSB, MDF, or other engineered sheet goods that contain formaldehyde or other VOC's, which can result in more toxic dust than natural wood alone. Proper collection of this dust is especially important in workplace settings where exposure occurs daily. Includes a sturdy mounting arm constructed from steel tube and 2.5" dust port for superb dust collection.



Figure 114. H7833 fully enclosed blade guard for Model G0451.

H3388—14" Carbide Tipped Saw Blade, 80T

H3389—14" Carbide Tipped Saw Blade, 100T

These blades are designed especially for sliding table saws and manufactured for heavy-duty use.




Figure 115. Carbide-tipped saw blade.

H4935—Stackable Scoring Blade Set

The scoring blade set consists of an inner and outer blade and four internal shims. Two shims are 0.008" thick and two are 0.004". The shims are provided so the scoring blade set can match the kerf thickness of the main blade.




Figure 116. H4935 Scoring Blade Set.



G5562—SLIPIT® 1 Qt. Gel
 G5563—SLIPIT® 12 oz Spray
 G2871—Boeshield® T-9 12 oz Spray
 G2870—Boeshield® T-9 4 oz Spray
 H3788—G96® Gun Treatment 12 oz Spray
 H3789—G96® Gun Treatment 4.5 oz Spray



Figure 117. Recommended products for protecting unpainted cast iron/steel part on machinery.

H2499—Small Half-Mask Respirator
 H3631—Medium Half-Mask Respirator
 H3632—Large Half-Mask Respirator
 H3635—Disposable Cartridge Filter Pair P100
 Wood dust is now considered a known carcinogen and has been linked to nasal cancer and severe respiratory illnesses. If you work around dust everyday, a half-mask respirator can be a lifesaver. Also compatible with safety glasses!



Figure 118. Half-mask respirator and disposable cartridge filters.

T20501—Face Shield Crown Protector 4"
 T20502—Face Shield Crown Protector 7"
 T20503—Face Shield Window
 T20452—"Kirova" Anti-Reflective S. Glasses
 T20451—"Kirova" Clear Safety Glasses
 H0736—Shop Fox® Safety Glasses
 H7194—Bifocal Safety Glasses 1.5
 H7195—Bifocal Safety Glasses 2.0
 H7196—Bifocal Safety Glasses 2.5



Figure 119. Eye protection assortment.


H8003—Hydraulic Lifting Table - 450 lbs.
 This rugged and affordable lifting table allows you to lift stacks of sheet goods right up to the table saw table with minimal effort. Features 39³/₈" x 19³/₄" table, 39¹/₂" maximum table height, 8" fixed and swivel casters with brakes.



Figure 120. Model H8003 Hydraulic Lifting Table.



SECTION 7: MAINTENANCE



Schedule

The frequency of maintenance necessary for any machine will always depend on the operating conditions and environment. The schedule below is a basic guideline for keeping your machine in proper operating condition. Always repair any adverse conditions immediately upon discovery.

Daily (Ongoing)

- Loose mounting bolts.
- Worn or damaged saw blades.
- Worn or damaged switches or wires.
- Any other unsafe condition.

Weekly

- Clean sliding table surface and grooves.
- Lubricate sliding table ways (**Figure 121**).
- Clean the cast iron saw table.
- Clean the sliding table roller guideways.
- Clean the rip fence.
- Clean the rip fence bracket and rail.

Monthly

- Clean/vacuum dust buildup from inside cabinet and off motor.
- Check V-belt tension, damage, or wear.

Every 6–12 Months

- Lubricate the trunnions (**Page 62**).
- Lubricate the elevation and tilt leadscrews (**Page 62**).

Note: To ensure optimum power transmission from the motor to the blades, the V-belts must be in good condition (free from cracks, fraying and wear) and operate under proper tension.

Cleaning

Cleaning the Model G0451 is relatively easy. Vacuum excess wood chips and sawdust, and wipe off the remaining dust with a dry cloth. Use compressed air to blow dust from between the two sections of the sliding table. If any resin has built up, use a resin dissolving cleaner to remove it. Treat all unpainted cast iron and steel with a non-staining lubricant after cleaning.

Unpainted Cast Iron

Protect the unpainted cast iron surfaces on the table by wiping the table clean after every use—this ensures moisture from wood dust does not remain on bare metal surfaces. DO NOT clean cast iron with water or it will rust!

Keep tables rust-free with regular applications of products like G96® Gun Treatment, SLIPIT®, or Boeshield® T-9 (see **SECTION 5: ACCESSORIES** for more details).



Lubrication

The bearings are sealed and pre-lubricated and require no lubrication during their usable life. However, your saw components will operate at their best if the bearing surfaces are kept clean—this is especially important for the trunnion bearings. ALWAYS DISCONNECT POWER BEFORE DOING MAINTENANCE!

Lubricate the areas indicated below with general purpose grease every 6–12 months, depending on frequency of use (see Figure 122):

- Blade Angling Trunnions (can be accessed from front of machine)
- Bevel Gears and Leadscrew
- Blade Height Trunnion

Sliding Table Ways: Spray or wipe on a light machine oil (such as those shown on **Page 60**) the entire length of the steel rods (see **Figure 121**).




Figure 121. Sliding table ways.




Figure 122. Lubrication locations (table removed for clarity).




SECTION 8: SERVICE

Review the troubleshooting and procedures in this section if a problem develops with your machine. If you need replacement parts or additional help with a procedure, call our Technical Support at (570) 546-9663.

Note: Please gather the serial number and manufacture date of your machine before calling.

Troubleshooting



Motor & Electrical

| Symptom | Possible Cause | Possible Solution |
|--|---|---|
| Machine does not start or a breaker trips. | <ol style="list-style-type: none"> 1. Switch disabling key is removed. 2. Emergency stop push-button is engaged/faulty. 3. Power supply switched OFF or is at fault. 4. Blade guard limit switch engaged/at fault. 5. Electrical box door is open/door safety switch is at fault. 6. Motor connection wired incorrectly. 7. Thermal overload relay has tripped. 8. Wall fuse/circuit breaker is blown/tripped. 9. Contactor not getting energized/has burnt contacts. 10. Wiring is open/has high resistance. 11. Motor ON button or ON/OFF switch is at fault. 12. Start delay module is at fault. 13. Motor is at fault. | <ol style="list-style-type: none"> 1. Install switch disabling key. 2. Rotate clockwise slightly until it pops out/replace it. 3. Ensure power supply is switch on; ensure power supply has the correct voltage. 4. Move blade guard to the working position; replace faulty limit switch. 5. Close door/replace faulty safety switch. 6. Correct motor wiring connections. 7. Turn cut-out dial to increase working amps and push the reset pin. Replace if tripped multiple times (weak relay). 8. Ensure circuit size is suitable for this machine; replace weak breaker. 9. Test for power on all legs and contactor operation. Replace unit if faulty. 10. Check for broken wires or disconnected/corroded connections, and repair/replace as necessary. 11. Replace faulty ON button or ON/OFF switch. 12. Adjust to correct delay; replace module. 13. Test/repair/replace. |
| Machine stalls or is underpowered. | <ol style="list-style-type: none"> 1. Feed rate/cutting speed too fast for task. 2. Workpiece material is not suitable for this machine. 3. Belt(s) slipping. 4. Motor connection is wired incorrectly. 5. Motor bearings are at fault. 6. Start delay module is at fault. 7. Motor is at fault. | <ol style="list-style-type: none"> 1. Decrease feed rate/cutting speed. 2. Only cut wood products; make sure moisture content is below 20% and there are no foreign materials in the workpiece. 3. Replace bad belt(s) as a matched set, align pulleys, and re-tension. 4. Correct motor wiring connections. 5. Test by rotating shaft; rotational grinding/loose shaft requires bearing replacement. 6. Adjust to correct delay; replace module. 7. Test/repair/replace. |



| Symptom | Possible Cause | Possible Solution |
|---|--|---|
| Machine has vibration or noisy operation. | <ol style="list-style-type: none"> 1. Motor or component is loose. 2. Blade is at fault. 3. V-belt(s) worn or loose. 4. Pulley is loose. 5. Motor mount loose/broken. 6. Machine is incorrectly mounted or sits unevenly. 7. Arbor pulley is loose. 8. Motor fan is rubbing on fan cover. 9. Arbor bearings are at fault. 10. Motor bearings are at fault. | <ol style="list-style-type: none"> 1. Inspect/replace stripped or damaged bolts/nuts, and re-tighten with thread locking fluid. 2. Replace warped, bent, or twisted blade; resharpen dull blade. 3. Inspect/replace belts with a new matched set (refer to Page 65). 4. Realign/replace shaft, pulley, setscrew, and key as required. 5. Tighten/replace. 6. Tighten/replace anchor studs in floor; relocate/shim machine. 7. Retighten/replace arbor pulley with shaft and thread locking liquid. 8. Replace dented fan cover; replace loose/damaged fan. 9. Replace arbor housing bearings; replace arbor. 10. Test by rotating shaft; rotational grinding/loose shaft requires bearing replacement. |
| Main blade runs backwards. | <ol style="list-style-type: none"> 1. Two of the power wires are reversed. | <ol style="list-style-type: none"> 1. Exchange wires R & T in the terminal box. |

Operation

| Symptom | Possible Cause | Possible Solution |
|--|---|--|
| Workpiece has burned edges, binds, or kicks back. | <ol style="list-style-type: none"> 1. Sliding table is not parallel to blade. 2. Riving knife is not aligned with the blade. 3. Blade is warped. | <ol style="list-style-type: none"> 1. Make sliding table parallel to the blade (Page 67). 2. Shim the riving knife to align it with the main blade. 3. Replace the blade. |
| Workpiece has chip out on the bottom edge. | <ol style="list-style-type: none"> 1. Scoring blade height is incorrect. 2. Scoring blade is not aligned with the main blade. 3. Scoring blade kerf does not match the main blade. | <ol style="list-style-type: none"> 1. Adjust the height of the scoring blade. 2. Align the scoring blade (Page 42). 3. Adjust the scoring blade kerf (Page 42). |
| Sliding table saw does not cut square. | <ol style="list-style-type: none"> 1. Sliding table is not parallel to blade. 2. Rip fence is not parallel to blade. 3. Crosscut fence is not perpendicular to the blade. | <ol style="list-style-type: none"> 1. Adjust the sliding table (Page 67). 2. Adjust the rip fence parallel to blade. 3. Adjust the crosscut fence perpendicular to the blade (Page 69). |
| Fence hits table top when sliding across table. | <ol style="list-style-type: none"> 1. Front rail is too low. 2. Rip fence roller is too low. | <ol style="list-style-type: none"> 1. Raise the front rail. 2. Adjust the rip fence roller. |
| Blade does not reach 90°, or blade does not reach 45°. | <ol style="list-style-type: none"> 1. Blade stop bolts are out of adjustment. | <ol style="list-style-type: none"> 1. Adjust the stop bolts (Page 66). |
| The rip fence scale is not accurate. | <ol style="list-style-type: none"> 1. The rip fence scale is out of calibration or was not set up correctly. | <ol style="list-style-type: none"> 1. Adjust the rip fence scale. |
| Tilt or blade height handwheels difficult to turn. | <ol style="list-style-type: none"> 1. Lock knob is tight. 2. Gears caked with dust. | <ol style="list-style-type: none"> 1. Release the lock knob. 2. Clean out dust and grease the gears. |



Belt Service

Main Belt Replacement/Tension

1. DISCONNECT SAW FROM POWER!
2. Move the blade tilt to 0° (blade 90° to table), and raise the main blade and scoring blade up as far as they will go.
3. Open the motor cabinet door.
4. Loosen the lock handle (**Figure 123**), rotate the pivot handle down 180°, then tighten the lock handle.




Figure 123. Main blade belt tension controls.

5. Remove the old V-belts and replace them with new belts. *Always replace all of the belts as a matched set.*
6. Loosen the lock handle, rotate the pivot handle up 180°, then tighten the lock handle.
7. Check the belt tension by pushing on belt in the center, as shown in **Figure 124**, and noting the amount of deflection.




Figure 124. Checking belt deflection.

The correct range of belt deflection for this machine is $\frac{1}{4}$ "– $\frac{1}{2}$ ".

—If the belt deflection is correct, continue to **Step 8**.

—If the belt deflection is incorrect, use the tension bolt to adjust the belt to the proper range of tension. Turning the bolt clockwise loosens the tension; turning the bolt counterclockwise increases the tension. After adjusting, tighten the jam nut on the tension bolt against the motor plate to secure it in position. Repeat **Step 7**.

8. Close the motor cabinet door.

Scoring Belt Replacement/Tension

1. DISCONNECT SAW FROM POWER!
2. Move the blade tilt to 0° (blade 90° to table), and raise the main blade and scoring blade set up as far as they will go.
3. Open the motor cabinet door.
4. Push the scoring blade motor up and remove the flat belt.
5. Place the flat belt on the scoring blade arbor as shown in **Figure 125**, lift the scoring motor, and slide the flat belt over the scoring motor pulley.




Figure 125. Replacing the scoring motor belt.

6. Close and secure the motor cabinet door.



Blade Tilt Calibration

The blade tilt is calibrated at the factory, but can be calibrated if it changes during the life of the machine.

90° Stop

1. DISCONNECT SAW FROM POWER!
2. Move the blade tilt to 90° according to the gauge, and raise the main blade as far as it will go.
3. Use a machinist's square to inspect if the blade is square to the table.

—If the blade is not square to the table, loosen the two set screws that secure the 90° tilt stop nut shown in **Figure 126**.




Figure 126. Blade tilt stop nut (90°).

4. Adjust the stop nut and recheck the blade tilt as many times as necessary until the blade is 90° to the table.
5. Tighten the two set screws in the stop nut.
6. Check the blade tilt pointer mechanism to ensure that it points to 90°.

—If the blade tilt pointer shows an incorrect tilt, adjust it by loosening the mounting screws, rotating the pointer until it points to 90°, then tightening the mounting screws.

45° Stop

1. DISCONNECT SAW FROM POWER!
2. Adjust the blade angle until you hit the 45° positive stop and check the blade angle with a 45° square.

—If the blade is not 45° to the table, loosen the two set screws that secure the 45° tilt stop nut shown in **Figure 127**. (This nut can also be accessed from the front of the saw by moving the sliding table all the way forward.)




Figure 127. 45° Blade tilt stop nut.

3. Adjust the stop nut and recheck the blade tilt as many times as necessary until the blade is 45° to the table.
4. Tighten the two set screws in the stop nut.



Sliding Table Parallel Adjustment

The table is calibrated at the factory, but can be adjusted slightly if it is not parallel to the blade.

| Tools Needed: | Qty |
|-----------------------------|-----|
| Felt Tip Pen..... | 1 |
| 90° Square | 1 |
| Precise Measuring Tool..... | 1 |
| Wrench 17mm | 1 |
| Hex Wrench 5mm..... | 1 |

To adjust the sliding table parallel with the main blade:

1. DISCONNECT SAW FROM POWER!
2. Move the blade tilt to 0° (blade 90° to table), and raise the main blade up to the maximum height.
3. Mark one of the blade teeth with a felt tip pen. This will be your reference point when taking measuring points, so you take them in the same location each time.
4. Move the sliding table all the way back, and measure the distance "A" in **Figure 128**, between the marked tooth and the edge of the miter slot.




Figure 128. Measuring distance between table and blade.

5. Rotate the blade 180°, move the sliding table all the way forward, and measure the distance between "B" in **Figure 128**.

6. Note the difference between the two positions.

—If the gap is the same on both sides or the difference is 0.004" or less, no adjustments to the table parallelism need to be made.

—If the difference is greater than 0.004", then the sliding table parallelism must be adjusted. Proceed to **Step 7**.

7. Loosen the nuts on T-bolts that are used to mount the sliding table to the base.

8. Loosen the hex nut on the parallel adjustment screw (see **Figure 129**), then adjust the screw as necessary to move the table. If you move the adjustment screw away from the table, then push the table against the screw before proceeding.




Figure 129. Table parallelism adjustment screw.

9. Tighten the hex nut on the parallel adjustment screw to secure it in place, then tighten the table mounting nuts. Repeat **Steps 4–6** as necessary until the sliding table is parallel with the blade.



Table Movement Adjustment

The sliding table features an adjustment bar with bolts that control how easily the sliding table moves across the base (see **Figure 130**). These adjustment bolts are factory set. They can only be accessed by removing the end covers from both ends of the sliding table base and sliding the thin plate out of the way.




Figure 130. Adjustment bolt access location.

If the adjustment bolts do require adjustments, turning them counterclockwise increases and clockwise decreases pressure against the steel rails. Increasing pressure against the rails reduces table movement slop, which increases accuracy, but makes it harder to slide the table. Decreasing pressure against the rails makes it easier to slide the table, but increases table movement slop, which reduces accuracy.

Adjusting this part of the sliding table correctly is a matter of trial-and-error by making adjustments, moving the sliding table, then making additional adjustments and repeating the process until the sliding table moves as desired. Ideally, the table will move easily but without any slop.



Squaring Crosscut Fence to Blade

Squaring the crosscut fence to the blade ensures that cuts made with the crosscut fence will be square. This procedure can be done by using a piece of scrap plywood as a test piece and making five test cuts, then adjusting the fence as necessary.

To square the crosscut fence with the blade:

1. Make sure the blade is parallel with the sliding table and that the block on the crosscut fence is resting against the 90° stop bolt (see **Figure 132** for locations).
2. Prepare the scrap test piece by cutting it to 32" x 32", then number all four sides of the test piece.
3. Use the crosscut fence to cut $\frac{1}{2}$ " off of each side of the test piece, then cut side 1 again (make five cuts total).
4. Measure the test piece diagonally from corner-to-corner as shown in **Figure 131**.

—If both measurements are not within $\frac{1}{16}$ ", then the crosscut fence needs to be adjusted. Proceed to **Steps 5–8**.

—If both measurements are within $\frac{1}{16}$ " then you are finished with this procedure.




Figure 131. Fence adjustment test piece.

5. Loosen the knob on the crosscut fence to allow it to pivot (make sure the block remains against the 90° stop bolt during adjustments).
6. Loosen the hex nut on the 90° stop bolt shown in **Figure 132**, and rotate the 90° stop bolt to square the crosscut fence.




Figure 132. Crosscut fence adjustment cam.

7. Tighten the hex nut on the 90° stop bolt, then tighten the crosscut fence knob, making sure the block is touching the 90° stop bolt.
8. Repeat **Steps 3-4**.



Adjusting Riving Knife Mounting Block

The spreader/riving knife must be aligned with the blade when installed. If the spreader/riving knife is not aligned with the blade, then the workpiece will be forced sideways during the cut, which will increase the risk of kickback.

The spreader/riving knife mounts to a block that can be repositioned to correctly align the spreader/riving knife to the blade.

The mounting block adjusts by turning the set screws in each corner of the block. **Figure 133** shows the set screws associated with controlling the mounting block position. Have patience when adjusting the mounting block, because it requires trial-and-error to perform with accuracy.




Figure 133. Riving knife mounting block adjustment controls.

All adjustment and alignment positions for the riving knife are covered on **Page 38** in the subsection **Riving Knife Installation & Removal**; the mounting block should not be adjusted unless you have been unable to mount the riving knife as instructed by these procedures.

| Tools Needed | Qty |
|---------------------|-----|
| Straightedge | 1 |
| Wrench 17mm..... | 1 |
| Hex Wrench 4mm..... | 1 |

To adjust the mounting block:

1. DISCONNECT SAW FROM POWER!
2. Raise the blade all the way up, move the sliding table to the side, and open the lower blade cover to gain access to the mounting block.
3. Loosen the lock nut that secures the spreader/riving knife to the mounting block, and remove the spreader/riving knife.
4. Adjust the each pair of set screws that controls the direction required to move the mounting block so the spreader/riving knife can be aligned with the blade. Make sure to move both set screws in even increments.
5. Reinstall the spreader/riving knife and check the alignment with the blade. Repeat **Step 4** as necessary until the spreader/riving knife is properly aligned to the blade.

Note: If you discover that the spreader/riving knife is bent and cannot be properly aligned with the blade, it is possible to bend it into alignment, but make sure that the final result is precisely aligned so the risk of kickback is not increased. If the spreader/riving knife is bent, and you cannot easily bend it back into alignment, we recommend replacing it with a new one.

6. Properly re-install the spreader/riving knife as described on **Page 38**, close the blade cover, and move the sliding table back to the center position.



SECTION 9: WIRING

These pages are current at the time of printing. However, in the spirit of improvement, we may make changes to the electrical systems of future machines. Compare the manufacture date of your machine to the one stated in this manual, and study this section carefully.

If there are differences between your machine and what is shown in this section, call Technical Support at (570) 546-9663 for assistance BEFORE making any changes to the wiring on your machine. An updated wiring diagram may be available. **Note:** Please gather the serial number and manufacture date of your machine before calling. This information can be found on the main machine label.

WARNING

Wiring Safety Instructions

SHOCK HAZARD. Working on wiring that is connected to a power source is extremely dangerous. Touching electrified parts will result in personal injury including but not limited to severe burns, electrocution, or death. Disconnect the power from the machine before servicing electrical components!

MODIFICATIONS. Modifying the wiring beyond what is shown in the diagram may lead to unpredictable results, including serious injury or fire. This includes the installation of unapproved after-market parts.

WIRE CONNECTIONS. All connections must be tight to prevent wires from loosening during machine operation. Double-check all wires disconnected or connected during any wiring task to ensure tight connections.

CIRCUIT REQUIREMENTS. You MUST follow the requirements at the beginning of this manual when connecting your machine to a power source.

WIRE/COMPONENT DAMAGE. Damaged wires or components increase the risk of serious personal injury, fire, or machine damage. If you notice that any wires or components are damaged while performing a wiring task, replace those wires or components.

MOTOR WIRING. The motor wiring shown in these diagrams is current at the time of printing but may not match your machine. If you find this to be the case, use the wiring diagram inside the motor junction box.
















CAPACITORS/INVERTERS. Some capacitors and power inverters store an electrical charge for up to 10 minutes after being disconnected from the power source. To reduce the risk of being shocked, wait at least this long before working on capacitors.

EXPERIENCING DIFFICULTIES. If you are experiencing difficulties understanding the information included in this section, contact our Technical Support at (570) 546-9663.

NOTICE


The photos and diagrams included in this section are best viewed in color. You can view these pages in color at www.grizzly.com.

COLOR KEY


| | | | | | | | |
|-------|---|--------|---|--------------|---|------------|---|
| BLACK |  | BLUE |  | YELLOW |  | LIGHT BLUE |  |
| WHITE |  | BROWN |  | YELLOW GREEN |  | BLUE WHITE |  |
| GREEN |  | GRAY |  | PURPLE |  | TURQUOISE |  |
| RED |  | ORANGE |  | PINK |  | | |




Wiring Overview





Electrical Box at 220V Wiring



Electrical Box at 440V Wiring




Control Panel Wiring




Main Motor Wiring

220V

440V




Scoring Motor Wiring



SECTION 10: PARTS

Electrical Components




| REF | PART # | DESCRIPTION |
|-----|------------|------------------------------|
| 1 | P04510001 | KEY SWITCH |
| 2 | P04510002 | POWER LAMP |
| 3 | P04510003 | ON BUTTON |
| 4 | P04510004 | OFF BUTTON |
| 5 | P04510005 | EMERGENCY STOP BUTTON |
| 6 | P04510006 | TERMINAL BAR 3P |
| 7 | P04510007 | TERMINAL BAR 7P |
| 8 | P04510008 | FUSE BASE |
| 9 | P04510009 | FUSE 250V 10A |
| 10A | P04510010A | TRANSFORMER V2.03.07 |
| 11A | P04510011A | MAGNETIC CONTACTOR MA-18 24V |

| REF | PART # | DESCRIPTION |
|-----|------------|-------------------------------------|
| 12A | P04510012A | OL RELAY SDE RA-20 12-18A |
| 13 | P04510013 | CONTACTOR SDE MA-09 24V |
| 14 | P04510014 | OL RELAY SDE RA-20E 2.6-4.4A |
| 15 | P04510015 | LIMIT SWITCH |
| 16 | P04510016 | CONVERSION KIT 440V OLR RA-20 8-12A |
| 17 | P04510017 | STAR DELTA TIMER 24V |
| 18 | P04510018 | TERMINAL 6 CIRCUIT 25A |
| 19 | P04510019 | CONTROL PANEL ASSY |
| 20 | P04510020 | ELECTRICAL BOX ASSY |
| 21 | P04510021 | MAGNETIC CONTACTOR MA-15 24V |
| 22 | P04510022 | MAGNETIC CONTACTOR MA-18 24V |



Crosscut Fence




| REF | PART # | DESCRIPTION |
|------|------------|--------------------------------|
| 101 | P04510101 | T-NUT M8-1.25 |
| 102 | P04510102 | STOP BRACKET |
| 103 | P04510103 | KNOB M8-1.25 X 40 |
| 104A | P04510104A | STUD-FT M10-1.5 X 70 V2.06.07 |
| 105A | P04510105A | FLIP STOP V2.06.07 |
| 106 | PSS01M | SET SCREW M6-1 X 10 |
| 107 | PLN05M | LOCK NUT M10-1.5 |
| 108 | P04510108 | SQUARE TUBE |
| 109 | P04510109 | FENCE EXTENSION |
| 110 | P04510110 | COVER |
| 111 | PHTEK7 | TAP SCREW #8 X 3/8" |
| 112 | PBHS03M | BUTTON HD CAP SCR M8-1.25 X 16 |

| REF | PART # | DESCRIPTION |
|-----|-----------|--------------------------|
| 113 | PLW04M | LOCK WASHER 8MM |
| 114 | P04510114 | LOCATE PLATE |
| 115 | P04510115 | KNOB SCREW M8-1.25 X 25 |
| 116 | P04510116 | SQUARE FENCE |
| 117 | P04510117 | CENTER BOLT M8-1.25 X 10 |
| 118 | P04510118 | FIBER WASHER 10 X 18 |
| 119 | P04510101 | T-NUT M8-1.25 |
| 120 | P04510120 | ROTATE BLOCK |
| 121 | PS38M | PHLP HD SCR M4-.7 X 10 |
| 122 | PS25M | PHLP HD SCR M4-.7 X 35 |
| 123 | P04510118 | FIBER WASHER 10 X 18 |



Crosscut Table



REF PART # DESCRIPTION


| | | |
|------|------------|------------------------------|
| 201A | P04930103 | ROLLER V2.06.06 |
| 204 | P04510204 | PLUG 80 X 40MM |
| 205A | P04930105 | SUPPORT FRAME V2.06.06 |
| 206 | P04510101 | T-NUT M8-1.25 |
| 207 | P04510207 | KNOB W/M8-1.25 X 25 SHOULDER |
| 208 | PWF08M | FENDER WASHER 8MM |
| 209 | P04510209 | PLUG 38 X 38MM |
| 210 | P04510210 | PLUG 40 X 20MM |
| 211 | P04510211 | T-BOLT M8-1.25 X 60 |
| 212 | PHTEK7 | TAP SCREW #8 X 3/8" |
| 213 | P04510213 | COVER |
| 214 | P04510214 | SQUARE BRACE |
| 215A | P04930115A | T-NUT M12-1.75 V2.06.06 |
| 216 | P04510216 | LOCK HANDLE M12-1.75 X 55 |
| 217A | P04930117A | T-NUT M8-1.25 V2.06.06 |
| 218 | PCAP115M | BUTTON HD CAP SCR M6-1 X 16 |
| 219 | PLW03M | LOCK WASHER 6MM |

REF PART # DESCRIPTION

| | | |
|-----|-----------|--------------------------------|
| 220 | P04510220 | PAD |
| 221 | PWF12M | FENDER WASHER 12MM |
| 222 | PWF08M | FENDER WASHER 8MM |
| 223 | P04510223 | KNOB SCREW M8-1.25 X 50 |
| 227 | PW03M | FLAT WASHER 6MM |
| 234 | P6201ZZ | BALL BEARING 6201ZZ |
| 235 | P04510235 | BUSHING |
| 236 | PR29M | INT RETAINING RING 32MM |
| 237 | PBHS23M | BUTTON HD CAP SCR M8-1.25 X 25 |
| 238 | PW18M | FLAT WASHER 18MM |
| 239 | P04510239 | EYE BOLT M8-1.25 X 40 |
| 240 | PLW04M | LOCK WASHER 8MM |
| 241 | PN03M | HEX NUT M8-1.25 |
| 242 | P04510242 | PLUG |
| 243 | P04510223 | KNOB SCREW M8-1.25 X 50 |
| 244 | PN03M | HEX NUT M8-1.25 |
| 245 | PB26M | HEX BOLT M8-1.25 X 30 |



Cabinet Body




Cabinet Body Parts List

| REF | PART # | DESCRIPTION |
|------|------------|-------------------------------|
| 301 | PCAP50M | CAP SCREW M5-.8 X 10 |
| 302 | PWF05M | FENDER WASHER 5MM |
| 303 | PS09M | PHLP HD SCR M5-.8 X 10 |
| 304 | P04510304 | POINTER |
| 305 | P04510305 | FIX PLATE |
| 306 | PW03M | FLAT WASHER 6MM |
| 307 | P04510307 | STEEL CABLE |
| 308 | PSS05M | SET SCREW M5-.8 X 10 |
| 309 | P04510309 | INDICATOR BLOCK |
| 310 | PCAP26M | CAP SCREW M6-1 X 12 |
| 311 | PLW03M | LOCK WASHER 6MM |
| 312 | P04510312 | SHAFT |
| 313 | PW03M | FLAT WASHER 6MM |
| 314 | P04510314 | COMPRESSION SPRING 13.6 X 300 |
| 320 | P04510320 | CONTROL PANEL FACE |
| 321A | PHTEK14M | TAP SCREW M4 X 6 |
| 322 | P04510322 | CORD FOR GUARD LIMIT SWITCH |
| 323 | P04510323 | CORD FOR DOOR LIMIT SWITCH |
| 324 | P04510324 | SHAFT |
| 325 | PSS10M | SET SCREW M10-1.5 X 20 |
| 326 | PN02M | HEX NUT M10-1.5 |
| 327 | P04510327 | ADJUST FOOT M16 X 100 |
| 328A | PHTEK8M | TAP SCREW M4 X 20 |
| 329 | P04510329 | TILT SCALE |
| 330 | P04510330 | PLUG |
| 331 | P04510331 | CONTROL PANEL POWER CORD |
| 333 | P04510333 | POWER CORD |
| 334 | P04510334 | ELECTRIC PANEL |
| 335 | PFN02M | FLANGE NUT M6-1 |
| 336 | PSS04M | SET SCREW M6-1 X 12 |
| 337 | P04510337 | MACHINE BODY |
| 338 | P04510338 | LOCATE BLOCK |
| 339 | PCAP11M | CAP SCREW M8-1.25 X 16 |
| 340A | PFS04M | FLANGE SCREW M4-.7 X 6 |
| 341 | PN02M | HEX NUT M10-1.5 |
| 342 | PSS84M | SET SCREW M10-1.5 X 35 |
| 343 | PN09M | HEX NUT M12-1.75 |
| 344 | PB33M | HEX BOLT M12-1.75 X 50 |
| 345 | PN03M | HEX NUT M8-1.25 |
| 346 | PB26M | HEX BOLT M8-1.25 X 30 |
| 347 | PWF14M | FENDER WASHER 14MM |
| 348A | P04510348A | STUD-FT M14-2 X 110 V2.06.07 |
| 349 | PN32M | HEX NUT M14-2 |
| 352 | P04510352 | WIRE CONNECTOR |
| 353 | P04510353 | CORD FOR STOP BUTTON |

| REF | PART # | DESCRIPTION |
|-------|-------------|------------------------------|
| 354 | P04510005 | EMERGENCY STOP BUTTON |
| 355 | P04510355 | HANGER |
| 356 | PFS08M | FLANGE SCREW M5-.8 X 16 |
| 357 | P04510357 | POWER CORD |
| 358 | PBHS05M | BUTTON HD CAP SCR M6-1 X 20 |
| 359 | P04510359 | POWER BOX |
| 359-1 | P04510359-1 | STRAIN RELIEF |
| 360 | P04510360 | TERMINAL 4C |
| 361 | PS05M | PHLP HD SCR M5-.8 X 8 |
| 362 | PBHS06M | BUTTON HD CAP SCR M5-.8 X 12 |
| 363 | P04510363 | STRAIN RELIEF M20 |
| 366 | P04510366 | PUSH STICK |
| 367 | PLN03M | LOCK NUT M6-1 |
| 368 | PCAP02M | CAP SCREW M6-1 X 20 |
| 369 | PSS39M | SET SCREW M10-1.5 X 50 |
| 370 | PN02M | HEX NUT M10-1.5 |
| 373 | P04510373 | STUD-FT M12-1.75 X 720 |
| 374 | PN09M | HEX NUT M12-1.75 |
| 375 | PW06M | FLAT WASHER 12MM |
| 376 | P04510376 | LOCATE BLOCK |
| 377 | P04510377 | PLATE |
| 378 | PW05M | FLAT WASHER 4MM |
| 379 | PN04M | HEX NUT M4-.7 |
| 380A | P04510380A | PLATE V2.03.08 |
| 381 | P04510381 | BLOCK |
| 382 | P04510382 | ARBOR WRENCH 30MM |
| 383 | P04510383 | ARBOR WRENCH 8 X 45 X 205 |
| 384 | P04510384 | CUSHION |
| 385A | P04510385A | ACCESS PLATE V2.03.08 |
| 386 | P04510386 | SWITCH BOX |
| 386-1 | P04510386-1 | STRAIN RELIEF |
| 387 | P04510387 | PAD |
| 388 | PS06M | PHLP HD SCR M5-.8 X 20 |
| 389 | PS25M | PHLP HD SCR M4-.7 X 35 |
| 390 | P04510390 | PLATE |
| 391 | P04510391 | DOOR KNOB |
| 392 | PW03M | FLAT WASHER 6MM |
| 393 | PLW03M | LOCK WASHER 6MM |
| 394 | PCAP04M | CAP SCREW M6-1 X 10 |
| 395 | PN04M | HEX NUT M4-.7 |
| 396 | PW05M | FLAT WASHER 4MM |
| 397 | P04510397 | SAFETY SWITCH BRACKET |
| 398 | P04510398 | DOOR SAFETY SWITCH |
| 399 | PS02M | PHLP HD SCR M4-.7 X 12 |
| 399-1 | PLW02M | LOCK WASHER 4MM |



Main Blade




Main Blade Parts List

| REF | PART # | DESCRIPTION |
|-----|-----------|------------------------|
| 401 | PW04M | FLAT WASHER 10MM |
| 402 | PRP58M | ROLL PIN 6 X 45 |
| 403 | PLW06M | LOCK WASHER 10MM |
| 404 | PCAP84M | CAP SCREW M10-1.5 X 35 |
| 405 | P04510405 | TRUNNION BRACKET LEFT |
| 406 | P04510406 | LOCATE PLATE |
| 407 | PCAP26M | CAP SCREW M6-1 X 12 |
| 408 | PW01M | FLAT WASHER 8MM |
| 409 | PLW03M | LOCK WASHER 6MM |
| 410 | PW03M | FLAT WASHER 6MM |
| 411 | PLW03M | LOCK WASHER 6MM |
| 412 | PCAP04M | CAP SCREW M6-1 X 10 |
| 413 | P04510413 | SAFETY SWITCH BRACKET |
| 414 | P04510414 | DOOR SAFETY SWITCH |
| 415 | PS25M | PHLP HD SCR M4-.7 X 35 |
| 417 | PN04M | HEX NUT M4-.7 |
| 418 | PW05M | FLAT WASHER 4MM |
| 419 | P04510419 | STRAIN RELIEF PG11 |
| 421 | PCAP97M | CAP SCREW M5-.8 X 6 |
| 422 | PLW01M | LOCK WASHER 5MM |
| 423 | PW02M | FLAT WASHER 5MM |
| 424 | P04510424 | HINGE |
| 425 | PN03M | HEX NUT M8-1.25 |
| 426 | PLW04M | LOCK WASHER 8MM |
| 427 | P04510427 | COVER |
| 428 | P04510428 | LATCH BOLT |
| 429 | PCAP50M | CAP SCREW M5-.8 X 10 |
| 430 | P04510430 | CATCH |
| 431 | PCAP50M | CAP SCREW M5-.8 X 10 |

| REF | PART # | DESCRIPTION |
|-----|-----------|------------------------|
| 432 | PLW01M | LOCK WASHER 5MM |
| 433 | PW02M | FLAT WASHER 5MM |
| 434 | P04510434 | FIX BLOCK |
| 435 | PWF08M | FENDER WASHER 8MM |
| 436 | PLW04M | LOCK WASHER 8MM |
| 437 | PCAP31M | CAP SCREW M8-1.25 X 25 |
| 438 | PW04M | FLAT WASHER 10MM |
| 439 | PLW06M | LOCK WASHER 10MM |
| 440 | PCAP84M | CAP SCREW M10-1.5 X 35 |
| 441 | PCAP72M | CAP SCREW M10-1.5 X 30 |
| 442 | P04510442 | TRUNNION |
| 443 | PLW04M | LOCK WASHER 8MM |
| 444 | PN03M | HEX NUT M8-1.25 |
| 445 | PB26M | HEX BOLT M8-1.25 X 30 |
| 446 | PCAP14M | CAP SCREW M8-1.25 X 20 |
| 447 | P04510447 | LOCATE BLOCK |
| 448 | P04510448 | TRUNNION BRACKET RIGHT |
| 449 | PRP58M | ROLL PIN 6 X 45 |
| 450 | PCAP12M | CAP SCREW M8-1.25 X 40 |
| 451 | PW01M | FLAT WASHER 8MM |
| 452 | PCAP07M | CAP SCREW M6-1 X 30 |
| 453 | PLW03M | LOCK WASHER 6MM |
| 454 | PN03M | HEX NUT M8-1.25 |
| 455 | P04510455 | LOCATE BLOCK |
| 456 | PB28M | HEX BOLT M8-1.25 X 60 |
| 457 | PSS06M | SET SCREW M8-1.25 X 16 |
| 458 | PCAP33M | CAP SCREW M5-.8 X 12 |
| 459 | PSS75M | SET SCREW M10-1.5 X 16 |
| 460 | P04510460 | TRUNNION BASE |



Main Blade Arbor




| REF | PART # | DESCRIPTION |
|------|------------|--------------------------------|
| 501 | P04510501 | BLADE GUARD |
| 502 | PWF08M | FENDER WASHER 8MM |
| 503 | PBHS07M | BUTTON HD CAP SCR M8-1.25 X 40 |
| 504 | PB35M | HEX BOLT M12-1.75 X 40 |
| 505 | P04510505 | ARBOR BRACKET |
| 506 | P04510506 | RIVING KNIFE |
| 507 | P04510507 | RIVING KNIFE FLAT WASHER 12MM |
| 508 | PLW05M | LOCK WASHER 12MM |
| 509 | PN09M | HEX NUT M12-1.75 |
| 510 | P04510510 | LOCATING PIN |
| 511 | P04510511 | FIX BLOCK |
| 512 | PBHS23M | BUTTON HD CAP SCR M8-1.25 X 25 |
| 513 | PN21M | HEX NUT M16-2 LH |
| 514A | P04510514A | ARBOR FLANGE V2.06.07 |
| 515 | PWF08M | FENDER WASHER 8MM |
| 516 | P04510516 | BUSHING |
| 517 | P04510517 | HOSE CLAMP 2-1/2" |
| 519 | PBHS23M | BUTTON HD CAP SCR M8-1.25 X 25 |
| 520 | PWF08M | FENDER WASHER 8MM |
| 521 | P04510521 | BUSHING |

| REF | PART # | DESCRIPTION |
|------|------------|--------------------------------|
| 522 | P04510522 | LINK PLATE |
| 523 | P4185072 | KEY 8 X 7 X 35 |
| 524A | P04510524A | MAIN ARBOR 1" V2.06.07 |
| 525 | P6206-2RS | BALL BEARING 6206 2RS |
| 526A | P04510526A | MAIN HOUSING V2.06.07 |
| 527 | PSS06M | SET SCREW M8-1.25 X 16 |
| 528A | P04510528A | BUSHING V2.06.07 |
| 529 | P6206-2RS | BALL BEARING 6206 2RS |
| 530 | P04510530 | LOCATE RING |
| 531A | P04510531A | ARBOR PULLEY V2.06.07 |
| 532 | PWF08M | FENDER WASHER 8MM |
| 533 | PLW04M | LOCK WASHER 8MM |
| 534 | PCAP31M | CAP SCREW M8-1.25 X 25 |
| 535 | PSS11M | SET SCREW M6-1 X 16 |
| 536 | PBHS08M | BUTTON HD CAP SCR M10-1.5 X 35 |
| 537 | PLW06M | LOCK WASHER 10MM |
| 538 | P04510538 | COVER |
| 539 | PCAP164M | CAP SCREW M3-.5 X 12 |
| 540 | P04510540 | PLATE |



Sliding Table




Sliding Table Parts List

| REF | PART # | DESCRIPTION |
|--------|--------------|-----------------------------------|
| 601V3 | P04510601V3 | BASE END COVER V3.05.10 |
| 603V3 | P04510603V3 | TABLE END COVER V3.05.10 |
| 604V3 | P04510604V3 | T-BOLT M12-1.75 X 40 V3.05.10 |
| 605 | PW06M | FLAT WASHER 12MM |
| 606 | PLW05M | LOCK WASHER 12MM |
| 607 | PN09M | HEX NUT M12-1.75 |
| 608AV3 | P04510608AV3 | SLIDING TABLE ASSY V3.05.10 |
| 608V3 | P04510608V3 | TOP BASE 2500MM V3.05.10 |
| 609 | P04510609 | HANDLE M12-1.75 |
| 610 | PW06M | FLAT WASHER 12MM |
| 611 | P04510215 | T-NUT M12-1.75 |
| 612A | P04510612A | LOCK HANDLE M10-1.5 X 20 V2.08.07 |
| 613A | PW04M | FLAT WASHER 10MM |
| 614A | P04510614A | EDGE SHOE PLATE V2.08.07 |
| 615A | P04510615A | T-NUT M10-1.5 V2.08.07 |
| 616 | P04510616 | BALL KNOB M8-1.25 |
| 617 | P04510617 | HANDLE SHAFT |
| 618 | P04510618 | CAM |
| 620V2 | P04510620V2 | PIN V2.05.10 |
| 621V2 | P04510621V2 | ELBOW BLOCK V2.05.10 |
| 622V2 | PR02M | EXT RETAINING RING 14MM |
| 623V2 | P04510623V2 | COMPRESSION SPRING V2.05.10 |
| 624V2 | P04510624V2 | SHAFT V2.05.10 |
| 625 | PN02 | HEX NUT 5/16-18 |
| 626 | P04510626 | CLAMP FOOT |
| 628V3 | P04510628V3 | SHAFT V3.05.10 |
| 629V2 | P04510629V2 | ADJUST HANDLE V2.05.10 |

| REF | PART # | DESCRIPTION |
|-------|-------------|-----------------------------|
| 631 | P04510631 | SHAFT WASHER |
| 632V3 | P04510632V3 | T-NUT M12-1.75 V3.05.10 |
| 635A | PCAP58M | CAP SCREW M8-1.25 X 12 |
| 636 | P04510636 | HANDLE |
| 639V3 | PBHS09M | BUTTON HD CAP SCR M6-1 X 12 |
| 640V3 | P04510640V3 | RIGHT END PLATE V3.05.10 |
| 643V3 | P04510643V3 | BASE END COVER V3.05.10 |
| 645 | P04510645 | HORIZONTAL LOCATE PLATE |
| 646A | PFH26M | FLAT HD SCR M6-1 X 30 |
| 648V2 | P04510648V2 | TEETH LOCATE PLATE V2.05.10 |
| 650V3 | P04510650V3 | STEEL RAIL V3.05.10 |
| 651V3 | P04510651V3 | BOTTOM BASE 2500MM V3.05.10 |
| 657A | PHTEK19M | TAP SCREW M5 X 16 |
| 662 | PRP70M | ROLL PIN 5 X 18 |
| 663 | P04510663 | RUBBER BLOCK |
| 664 | P04510664 | LOCATE BLOCK |
| 665V2 | P04510665V2 | LOCATE ROD V2.05.10 |
| 666 | PFH43M | FLAT HD SCR M6-1 X 10 |
| 671V2 | P04510671V2 | LOCATE BLOCK V2.05.10 |
| 672V2 | PFH07M | FLAT HD SCR M5-.8 X 10 |
| 673V2 | PCAP115M | BUTTON HD CAP SCR M6-1 X 16 |
| 675V2 | P04510675V2 | STEEL BALL 16.6MM V2.05.10 |
| 676V2 | P04510676V2 | SLIDING BOTTOM V2.05.10 |
| 677 | P04510677 | COTTON PAD |
| 678V3 | PBHS05M | BUTTON HD CAP SCR M6-1 X 20 |
| 679 | P04510679 | ADHESIVE |



Tables




| REF | PART # | DESCRIPTION |
|------|------------|-------------------------|
| 701 | P04510701 | SUPPORT BRACE |
| 702 | PN03M | HEX NUT M8-1.25 |
| 703 | PCAP14M | CAP SCREW M8-1.25 X 20 |
| 704 | PCAP14M | CAP SCREW M8-1.25 X 20 |
| 705 | PLW04M | LOCK WASHER 8MM |
| 706 | PWF08M | FENDER WASHER 8MM |
| 707 | PB56M | CAP SCREW M10-1.5 X 20 |
| 708 | PLW06M | LOCK WASHER 10MM |
| 709 | PSS04M | SET SCREW M6-1 X 12 |
| 710 | P04510710 | OUTFEED EXTENSION TABLE |
| 711A | P04510711A | TABLE V2.09.05 |
| 712 | P04510712 | SUPPORT PLATE LEFT |
| 713 | P04510713 | EXTENSION TABLE |
| 714 | PLW06M | LOCK WASHER 10MM |
| 715 | PCAP72M | CAP SCREW M10-1.5 X 30 |
| 716 | P04510716 | HOSE SUPPORT PLATE |
| 717 | PN02M | HEX NUT M10-1.5 |
| 718 | PB56M | CAP SCREW M10-1.5 X 20 |
| 719 | PLW06M | LOCK WASHER 10MM |
| 720 | PW04M | FLAT WASHER 10MM |

| REF | PART # | DESCRIPTION |
|------|------------|------------------------|
| 721 | PSS04M | SET SCREW M6-1 X 12 |
| 722A | PN01M | HEX NUT M6-1 |
| 723A | P04510723A | SCALE BAR V2.09.05 |
| 724A | PLW03M | LOCK WASHER 6MM |
| 725A | PB10M | HEX BOLT M6-1 X 25 |
| 726 | P04510726 | STUD-FT M12-1.75 X 115 |
| 727 | PN09M | HEX NUT M12-1.75 |
| 728 | PCAP11M | CAP SCREW M8-1.25 X 16 |
| 729 | PLW04M | LOCK WASHER 8MM |
| 730 | P04510730 | END WASHER |
| 731 | P04510731 | ROUND RAIL |
| 732 | P04510732 | RING STOP |
| 733 | PSS01M | SET SCREW M6-1 X 10 |
| 734A | PW03M | FLAT WASHER 6MM |
| 735 | PW06M | FLAT WASHER 12MM |
| 736 | PLW05M | LOCK WASHER 12MM |
| 737 | PN09M | HEX NUT M12-1.75 |
| 738 | P04510738 | TABLE INSERT |
| 739 | PCAP38M | CAP SCREW M5-.8 X 25 |



Rip Fence




| REF | PART # | DESCRIPTION |
|-----|-----------|-------------------------|
| 801 | P04510801 | ROTATE SHAFT |
| 802 | P04510802 | HANDLE M10-1.5 X 12 |
| 803 | P04510803 | RIP FENCE HOUSING |
| 804 | P04510804 | KNOB M10-1.5 X 70 |
| 805 | PN03M | HEX NUT M8-1.25 |
| 806 | P04510806 | LOCATE PLATE |
| 807 | P04510807 | MICRO ADJUSTING KNOB |
| 808 | PLW04M | LOCK WASHER 8MM |
| 809 | PN03M | HEX NUT M8-1.25 |
| 810 | P04510810 | LOCATE BLOCK |
| 811 | PLN05M | LOCK NUT M10-1.5 |
| 812 | P04510802 | HANDLE M10-1.5 X 12 |
| 813 | P04510813 | CAM |
| 814 | P04510814 | WAVE WASHER 10 X 15 |
| 815 | PFS12M | FLANGE SCREW M5-.8 X 12 |
| 816 | P04510816 | SPRING PIECE |
| 817 | P04510817 | PIN |

| REF | PART # | DESCRIPTION |
|-----|-----------|-----------------------------|
| 818 | PCAP115M | BUTTON HD CAP SCR M6-1 X 16 |
| 819 | PBHS09M | BUTTON HD CAP SCR M6-1 X 12 |
| 820 | PW03M | FLAT WASHER 6MM |
| 821 | P04510821 | PLATE |
| 822 | P04510822 | COMPRESSION SPRING |
| 823 | P04510823 | CAM |
| 824 | PCAP11M | CAP SCREW M8-1.25 X 16 |
| 825 | PSS05M | SET SCREW M5-.8 X 10 |
| 826 | P04510826 | CLAMP PLATE |
| 827 | P04510827 | FENCE PLATE |
| 828 | P04510828 | BEARING PAD |
| 829 | P04510829 | ECCENTRIC SHAFT |
| 830 | P04510830 | PLASTIC ROLLER |
| 831 | PW03M | FLAT WASHER 6MM |
| 832 | PCAP01M | CAP SCREW M6-1 X 16 |
| 833 | P04510833 | STUD-FT M8-1.25 X 110 |



Scoring Motor




Scoring Motor Parts List

| REF | PART # | DESCRIPTION |
|--------|--------------|-------------------------------|
| 901A | PN13M | HEX NUT M16-2 |
| 902A | P04510902A | OUTER SCORING FLANGE V2.08.07 |
| 903 | P04510903 | SCORING BLADE 22MM |
| 904A | P04510904A | SCORING ARBOR 22MM V2.08.07 |
| 904A-1 | P04510904A-1 | INNER SCORING FLANGE |
| 905 | PLN04M | LOCK NUT M8-1.25 |
| 906 | P04510906 | FIX PLATE |
| 907 | P04510907 | BUSHING |
| 908 | P04510908 | FIX PLATE |
| 909 | PCAP12M | CAP SCREW M8-1.25 X 40 |
| 910 | PSS01M | SET SCREW M6-1 X 10 |
| 911A | P04510911A | FLAT BELT 15 X 800 V2.08.07 |
| 912 | P04510912 | SHAFT |
| 913 | P04510913 | COLLAR |
| 914 | PCAP04M | CAP SCREW M6-1 X 10 |
| 915 | PLW04M | LOCK WASHER 8MM |
| 916 | PB07M | HEX BOLT M8-1.25 X 25 |
| 917 | P04510917 | SHAFT |
| 918 | PSS01M | SET SCREW M6-1 X 10 |
| 919 | P04510919 | LOCATE PLATE |
| 920 | PCAP130M | CAP SCREW M10-1.5 X 16 |
| 921 | P04510921 | MOTOR PLATE |
| 922 | P04510922 | SCORING ARBOR PULLEY |
| 923 | PR09M | EXT RETAINING RING 20MM |
| 924 | P04510924 | SCORING HOUSING |
| 925 | P6204ZZ | BALL BEARING 6204ZZ |
| 926 | P04510926 | COLLAR |
| 927 | PSS02M | SET SCREW M6-1 X 6 |
| 928 | P04510928 | FIX BLOCK |
| 929 | PLN04M | LOCK NUT M8-1.25 |
| 930 | P04510930 | FIX PLATE |
| 931 | PN32M | HEX NUT M14-2 |
| 932 | PLN03M | LOCK NUT M6-1 |
| 933 | P04510933 | ADJUST SHAFT |
| 934 | P04510934 | FIX BLOCK |
| 935 | P04510935 | GEAR 15T |
| 936 | PCAP01M | CAP SCREW M6-1 X 16 |
| 937 | PB100M | HEX BOLT M14-2 X 100 |
| 938 | PCAP37M | CAP SCREW M6-1 X 50 |
| 939 | P04510939 | FIX PLATE |

| REF | PART # | DESCRIPTION |
|-------|-------------|--------------------------------|
| 940 | PCAP60M | CAP SCREW M8-1.25 X 55 |
| 941A | P04510941A | ADJUST KNOB V2.08.07 |
| 942 | PCAP01M | CAP SCREW M6-1 X 16 |
| 943 | PLN03M | LOCK NUT M6-1 |
| 944 | P04510944 | ADJUST SHAFT |
| 945 | P04510945 | FIX BRACKET |
| 946 | P04510946 | SLEEVE |
| 947 | PB45M | HEX BOLT M8-1.25 X 100 |
| 948A | P04510948A | KNOB M6-1 X 40 V2.08.07 |
| 949 | PLN04M | LOCK NUT M8-1.25 |
| 950 | PN03M | HEX NUT M8-1.25 |
| 951 | P04510951 | FIX PLATE |
| 952 | P04510952 | BUSHING |
| 953 | P04510953 | LEADSCREW 5/8-16 X 4" |
| 954 | P04510935 | GEAR 15T |
| 955 | P04510955 | FIX PLATE |
| 956 | PCAP29M | CAP SCREW M6-1 X 40 |
| 957 | P04510957 | MOTOR PULLEY |
| 958 | PSS01M | SET SCREW M6-1 X 10 |
| 959 | PK23M | KEY 5 X 5 X 25 |
| 960 | P04510960 | SCORING MOTOR 1HP 220/440V 3PH |
| 960-1 | P04510960-1 | FAN COVER |
| 960-2 | P04510960-2 | MOTOR FAN |
| 960-3 | P04510960-3 | MOTOR WIRING BOX |
| 961 | P04510961 | SCORING MOTOR CORD |
| 962 | PN03M | HEX NUT M8-1.25 |
| 963 | PWF08M | FENDER WASHER 8MM |
| 964 | PB01M | HEX BOLT M10-1.5 X 30 |
| 965 | PLW06M | LOCK WASHER 10MM |
| 966 | PW04M | FLAT WASHER 10MM |
| 967 | P04510967 | FIX PLATE |
| 968 | PN02M | HEX NUT M10-1.5 |
| 971 | P04510971 | COMPRESSION SPRING |
| 972 | PSS04M | SET SCREW M6-1 X 12 |
| 973 | P04510973 | WAVY WASHER 34 X 47 |
| 974 | PCAP04M | CAP SCREW M6-1 X 10 |
| 976 | PSS05M | SET SCREW M5-.8 X 10 |
| 977 | PSS02M | SET SCREW M6-1 X 6 |
| 978 | P04510978 | LOCK COLLAR |
| 979 | P04510979 | LONG SLEEVE |



Adjustment Wheels




| REF | PART # | DESCRIPTION |
|-------|------------|--------------------------|
| 1001 | PCAP26M | CAP SCREW M6-1 X 12 |
| 1002 | P04511002 | UNIVERSAL JOINT |
| 1003 | PCAP04M | CAP SCREW M6-1 X 10 |
| 1004 | PR05M | EXT RETAINING RING 15MM |
| 1005 | PCAP11M | CAP SCREW M8-1.25 X 16 |
| 1006 | PLW04M | LOCK WASHER 8MM |
| 1007A | P04511007A | LOCATE RING V2.04.06 |
| 1008A | P04511008A | HANDWHEEL SHAFT V2.03.07 |
| 1009 | PK25M | KEY 7 X 7 X 20 |
| 1010 | P04511010 | HANDWHEEL 8" |
| 1011 | PW04M | FLAT WASHER 10MM |
| 1012 | P04511012 | KNOB M10-1.5 |
| 1013 | PCAP40M | CAP SCREW M8-1.25 X 35 |
| 1014 | PLW04M | LOCK WASHER 8MM |
| 1015 | PWF08M | FENDER WASHER 8MM |
| 1016 | PLN04M | LOCK NUT M8-1.25 |
| 1017 | P04511017 | LONG SHAFT |
| 1018 | PCAP58M | CAP SCREW M8-1.25 X 12 |
| 1019 | PLW04M | LOCK WASHER 8MM |
| 1020 | P04511020 | LOCATE PLATE |
| 1021 | P04511021 | BEARING SET |
| 1022A | P04511022A | GEAR 24T V2.07.05 |
| 1022B | P04511022B | GEAR 36T V2.07.05 |
| 1023 | PSS01M | SET SCREW M6-1 X 10 |
| 1024 | P04511024 | UNIVERSAL JOINT BRACKET |
| 1025 | PCAP14M | CAP SCREW M8-1.25 X 20 |

| REF | PART # | DESCRIPTION |
|-------|-----------|-------------------------|
| 1026 | PLW04M | LOCK WASHER 8MM |
| 1027 | PWF08M | FENDER WASHER 8MM |
| 1028 | PR05M | EXT RETAINING RING 15MM |
| 1029 | PCAP50M | CAP SCREW M5-.8 X 10 |
| 1030 | P04511030 | CONNECTING ROD ASSEMBLY |
| 1031 | PCAP04M | CAP SCREW M6-1 X 10 |
| 1032 | P04511032 | SHAFT |
| 1034 | PW03M | FLAT WASHER 6MM |
| 1033A | PCAP02M | CAP SCREW M6-1 X 20 |
| 1035 | P04511035 | SUPPORT PLATE |
| 1036 | P04511036 | LOCK COLLAR |
| 1037 | P04511037 | THRUST BEARING LFW-2015 |
| 1038 | P04511038 | LOCATE BLOCK |
| 1039 | P04511039 | BUSHING |
| 1040 | P51104 | THRUST BEARING 51104 |
| 1041 | P04511041 | WORM SHAFT |
| 1042 | PK25M | KEY 7 X 7 X 20 |
| 1043 | PCAP84M | CAP SCREW M10-1.5 X 35 |
| 1044 | PSS01M | SET SCREW M6-1 X 10 |
| 1045 | P04511045 | BUSHING |
| 1046 | P6902ZZ | BALL BEARING 6902 ZZ |
| 1051 | P04511051 | EXPANSION JOINT |
| 1054 | PR24M | INT RETAINING RING 42MM |
| 1055 | P6004ZZ | BALL BEARING 6004 ZZ |
| 1056 | PR20M | INT RETAINING RING 28MM |



Swing Arm




| REF | PART # | DESCRIPTION |
|---------|--------------|--------------------------------|
| 1101 | P04511101 | NYLON WASHER M10 X 25 |
| 1102A | P04511102A | SUPPORT SHAFT V2.01.08 |
| 1103A | PN28M | HEX NUT M20-2.5 |
| 1104A | P04511104A | PLUG 40 X 120 V2.06.07 |
| 1105A | PBHS03M | BUTTON HD CAP SCR M8-1.25 X 16 |
| 1106A | P04511106A | MAGNETIC BRACKET V2.04.07 |
| 1106A-1 | P04511106A-1 | MAGNET V2.06.07 |
| 1107A | P04511107A | SLIDING TUBE V2.06.07 |
| 1108A | PCAP11M | CAP SCREW M8-1.25 X 16 |
| 1109 | PN03M | HEX NUT M8-1.25 |
| 1110A | PFS04M | FLANGE SCREW M4-.7 X 6 |
| 1111A | P04511111A | COVER V2.06.07 |
| 1112 | PW01M | FLAT WASHER 8MM |
| 1113A | P04511113A | SHAFT V2.06.06 |
| 1115 | PN03M | HEX NUT M8-1.25 |
| 1117A | P04511117A | ROLLER V2.11.06 |
| 1118 | P6202ZZ | BALL BEARING 6202ZZ |

| REF | PART # | DESCRIPTION |
|-------|------------|-------------------------|
| 1119A | PSS21M | SET SCREW M8-1.25 X 25 |
| 1120A | PR05M | EXT RETAINING RING 15MM |
| 1121A | P04511121A | SWING ARM V2.10.06 |
| 1122 | P51102 | THRUST BEARING 51102 |
| 1123 | PB82M | HEX BOLT M8-1.25 X 80 |
| 1124 | PW01M | FLAT WASHER 8MM |
| 1125 | PLN04M | LOCK NUT M8-1.25 |
| 1126 | P6202ZZ | BALL BEARING 6202ZZ |
| 1127 | P04511127 | BRUSH |
| 1128 | PW03M | FLAT WASHER 6MM |
| 1129 | PCAP02M | CAP SCREW M6-1 X 20 |
| 1134 | PLW04M | LOCK WASHER 8MM |
| 1145 | P04511145 | RING |
| 1146 | P04511146 | SHAFT |
| 1148 | P04511148 | PLATE |
| 1149 | PW08M | FLAT WASHER 16MM |



Main Motor Parts




| REF | PART # | DESCRIPTION |
|--------|-------------|--------------------------------|
| 1201 | P04511201 | DUST PORT |
| 1202 | PCAP52M | CAP SCREW M8-1.25 X 10 |
| 1203 | PLW04M | LOCK WASHER 8MM |
| 1204 | P04511204 | ROTATE PLATE |
| 1205 | PSS01M | SET SCREW M6-1 X 10 |
| 1206 | P04511206 | SHAFT |
| 1207 | P04511207 | LOCATE PLATE |
| 1208 | PN09M | HEX NUT M12-1.75 |
| 1209 | PB33M | HEX BOLT M12-1.75 X 50 |
| 1210 | PN02M | HEX NUT M10-1.5 |
| 1211 | P04511211 | SUPPORT PLATE |
| 1212 | P04511212 | SPACER |
| 1213 | PLW06M | LOCK WASHER 10MM |
| 1214 | PCAP134M | CAP SCREW M10-1.5 X 65 |
| 1215 | P04511215 | SPACER |
| 1216A | P04511216A | GIB PLATE V2.10.05 |
| 1217 | PBHS10M | BUTTON HD CAP SCR M10-1.5 X 25 |
| 1218 | P04511218 | LOCATE PLATE |
| 1219 | PLW04M | LOCK WASHER 8MM |
| 1220 | PCAP11M | CAP SCREW M8-1.25 X 16 |
| 1221 | PCAP130M | CAP SCREW M10-1.5 X 16 |
| 1222 | PLW06M | LOCK WASHER 10MM |
| 1223 | P04511223 | LOCK COLLAR |
| 1224 | P04511224 | MAIN MOTOR PLATE |
| 1225 | PB31M | HEX BOLT M10-1.5 X 40 |
| 1226 | PLW06M | LOCK WASHER 10MM |
| 1227 | PW04M | FLAT WASHER 10MM |
| 1228 | P04511228 | MAIN MOTOR 10HP 220/440V 3PH |
| 1228-1 | P04511228-1 | FAN COVER |
| 1228-2 | P04511228-2 | MOTOR FAN |
| 1228-3 | P04511228-3 | MOTOR WIRING BOX |

| REF | PART # | DESCRIPTION |
|-------|------------|-----------------------------|
| 1229 | PN02M | HEX NUT M10-1.5 |
| 1230 | P04511230 | MAIN MOTOR CORD |
| 1231 | P04511231 | LOCK COLLAR |
| 1232 | P04511232 | ELEVATION SCREW M16-2 X 335 |
| 1233 | P51200 | THRUST BEARING 51200 |
| 1234 | P6200ZZ | BALL BEARING 6200ZZ |
| 1235 | PR01M | EXT RETAINING RING 10MM |
| 1236 | P04511236 | FIX BLOCK |
| 1237 | PLW06M | LOCK WASHER 10MM |
| 1238A | PCAP84M | CAP SCREW M10-1.5 X 35 |
| 1239A | P04511239A | BELT 3R-5MS-670 V2.06.07 |
| 1240A | P04511240A | MAIN MOTOR PULLEY V2.06.07 |
| 1241 | PSS01M | SET SCREW M6-1 X 10 |
| 1242 | PK118M | KEY 8 X 7 X 50 |
| 1243 | PB01M | HEX BOLT M10-1.5 X 30 |
| 1244 | PLW06M | LOCK WASHER 10MM |
| 1245 | PW04M | FLAT WASHER 10MM |
| 1246 | P04511246 | FIX PLATE |
| 1247 | PN02M | HEX NUT M10-1.5 |
| 1248 | P04511248 | SPONGE |
| 1250 | PW03M | FLAT WASHER 6MM |
| 1251 | PLW03M | LOCK WASHER 6MM |
| 1252 | PCAP02M | CAP SCREW M6-1 X 20 |
| 1254 | PLN02M | LOCK NUT M5-.8 |
| 1255 | P04511255 | FIX PLATE |
| 1256 | P04511256 | BUSHING |
| 1257 | P04511257 | PLATE |
| 1258 | P04511258 | FIX PLATE |
| 1259 | PW02M | FLAT WASHER 5MM |
| 1260 | PCAP38M | CAP SCREW M5-.8 X 25 |



Machine Labels A



| REF | PART # | DESCRIPTION |
|------|------------|---------------------------|
| 1301 | PLABEL-40 | BLADE GUARD LABEL |
| 1302 | PLABEL-11A | SAFETY GLASSES LABEL VL |
| 1303 | P04511303 | QUALIFIED PERSONNEL LABEL |
| 1304 | PLABEL-12A | READ MANUAL LABEL VL |
| 1305 | PLABEL-14A | ELECTRICITY LABEL |
| 1306 | PLABEL-53 | DISCONNECT LABEL VL |



| REF | PART # | DESCRIPTION |
|------|-----------|------------------------------|
| 1307 | P04511307 | TILT DIRECTION LABEL |
| 1308 | P04511308 | ELEVATION DIRECTION LABEL |
| 1309 | P04511309 | MACHINE ID LABEL |
| 1310 | PPAINT-1 | GRIZZLY GREEN TOUCH-UP PAINT |
| 1311 | PPAINT-11 | GRIZZLY PUTTY TOUCH-UP PAINT |

⚠ WARNING

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this machine **MUST** replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or www.grizzly.com.



Machine Labels B



| REF | PART # | DESCRIPTION |
|------|-----------|--------------------------------|
| 1312 | P04511312 | DO NOT REMOVE GUARD LABEL |
| 1313 | P04511313 | BLADE ROTATION DIRECTION LABEL |
| 1314 | P04511314 | SCORING BLADE ELEVATION LABEL |
| 1315 | P04511315 | SCORING BLADE ALIGNMENT LABEL |

| REF | PART # | DESCRIPTION |
|------|-----------|------------------------|
| 1316 | P04511316 | 220V LABEL |
| 1317 | P04511317 | FENCE LOCK DIRECTION |
| 1318 | P04511318 | KICKBACK WARNING LABEL |





WARRANTY CARD

Name _____

Street _____

City _____ State _____ Zip _____

Phone # _____ Email _____ Invoice # _____

Model # _____ Order # _____ Serial # _____

The following information is given on a voluntary basis. It will be used for marketing purposes to help us develop better products and services. **Of course, all information is strictly confidential.**

1. How did you learn about us?

_____ Advertisement

_____ Friend

_____ Catalog

_____ Card Deck

_____ Website

_____ Other:

2. Which of the following magazines do you subscribe to?

_____ Cabinetmaker & FDM

_____ Popular Science

_____ Wooden Boat

_____ Family Handyman

_____ Popular Woodworking

_____ Woodshop News

_____ Hand Loader

_____ Precision Shooter

_____ Woodsmith

_____ Handy

_____ Projects in Metal

_____ Woodwork

_____ Home Shop Machinist

_____ RC Modeler

_____ Woodworker West

_____ Journal of Light Cont.

_____ Rifle

_____ Woodworker's Journal

_____ Live Steam

_____ Shop Notes

_____ Other:

_____ Model Airplane News

_____ Shotgun News

_____ Old House Journal

_____ Today's Homeowner

_____ Popular Mechanics

_____ Wood

3. What is your annual household income?

_____ \$20,000-\$29,000

_____ \$30,000-\$39,000

_____ \$40,000-\$49,000

_____ \$50,000-\$59,000

_____ \$60,000-\$69,000

_____ \$70,000+

4. What is your age group?

_____ 20-29

_____ 30-39

_____ 40-49

_____ 50-59

_____ 60-69

_____ 70+

5. How long have you been a woodworker/metalworker?

_____ 0-2 Years

_____ 2-8 Years

_____ 8-20 Years

_____ 20+ Years

6. How many of your machines or tools are Grizzly?

_____ 0-2

_____ 3-5

_____ 6-9

_____ 10+

7. Do you think your machine represents a good value?

_____ Yes

_____ No

8. Would you recommend Grizzly Industrial to a friend?

_____ Yes

_____ No

9. Would you allow us to use your name as a reference for Grizzly customers in your area?

Note: We never use names more than 3 times.

_____ Yes

_____ No

10. Comments: _____

CUT ALONG DOTTED LINE

FOLD ALONG DOTTED LINE



Place
Stamp
Here



GRIZZLY INDUSTRIAL, INC.
P.O. BOX 2069
BELLINGHAM, WA 98227-2069



FOLD ALONG DOTTED LINE

Send a Grizzly Catalog to a friend:

| |
|-----------------------------|
| Name_____ |
| Street_____ |
| City_____State_____Zip_____ |

TAPE ALONG EDGES--PLEASE DO NOT STAPLE

WARRANTY & RETURNS

Grizzly Industrial, Inc. warrants every product it sells for a period of **1 year** to the original purchaser from the date of purchase. This warranty does not apply to defects due directly or indirectly to misuse, abuse, negligence, accidents, repairs or alterations or lack of maintenance. This is Grizzly's sole written warranty and any and all warranties that may be implied by law, including any merchantability or fitness, for any particular purpose, are hereby limited to the duration of this written warranty. We do not warrant or represent that the merchandise complies with the provisions of any law or acts unless the manufacturer so warrants. In no event shall Grizzly's liability under this warranty exceed the purchase price paid for the product and any legal actions brought against Grizzly shall be tried in the State of Washington, County of Whatcom.

We shall in no event be liable for death, injuries to persons or property or for incidental, contingent, special, or consequential damages arising from the use of our products.

To take advantage of this warranty, contact us by mail or phone and give us all the details. We will then issue you a "Return Number," which must be clearly posted on the outside as well as the inside of the carton. We will not accept any item back without this number. Proof of purchase must accompany the merchandise.

The manufacturers reserve the right to change specifications at any time because they constantly strive to achieve better quality equipment. We make every effort to ensure that our products meet high quality and durability standards and we hope you never need to use this warranty.

Please feel free to write or call us if you have any questions about the machine or the manual.

Thank you again for your business and continued support. We hope to serve you again soon.

grizzly.com®

TOOL WEBSITE

Buy Direct and Save with Grizzly® – Trusted, Proven and a Great Value!
~Since 1983~

***Visit Our Website Today For
Current Specials!***

**ORDER
24 HOURS A DAY!
1-800-523-4777**

