




MODEL H5380 1 HP ELECTRIC MOTOR INSTRUCTION SHEET

Model H5380 Specifications


Power 1 HP
 Cycle.....60Hz
 Voltage110/220V
 Prewired 110V
 Amps 12.6/6.3A
 RPM..... 3450
 Phase Single
 Class..... B
 Start Capacitor 300MFD 125VAC
 Dimensions..... 1 7/8"D x 3 3/8"L

Electrical Safety

If you are unsure how to attach wires to terminals, DO NOT continue. Contact a qualified electrician for assistance. Connecting wires improperly may cause them to come loose or contact other wires, which can cause electrocution, fire, or a short.




⚠️ WARNING
 Disconnect power when replacing motor. Failure to do this may result in serious personal injury.



⚠️ WARNING
 Electrocution or fire could result if this motor is not grounded correctly or if your wire connections do not comply with local and state codes. Ensure compliance by checking with a qualified electrician!

Replaceable Parts




REF	PART #	DESCRIPTION
1	PH5380001	MOTOR FAN COVER
2	PH5380002	MOTOR FAN
3	PH5380003	S CAPACITOR COVER
4	PC300F	S CAPACITOR 300M 125V 1-7/8 X 3-3/8

REF	PART #	DESCRIPTION
5	PH5380005	JUNCTION BOX
6	PH5380006	CENTRIFUGAL SWITCH
7	PH5380007	CONTACT PLATE

COPYRIGHT © DECEMBER, 2007 BY GRIZZLY INDUSTRIAL, INC.
WARNING: NO PORTION OF THIS INSTRUCTION SHEET MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.
 #JB10239 PRINTED IN TAIWAN


H5380 Wiring Diagram



View this page in color at
www.grizzly.com.

COLOR KEY

BLACK	— Bk —
WHITE	— Wt —
GREEN	— Gn —
RED	— Rd —
YELLOW	— Yl —
BLUE	— Bl —



NOTICE
The motor wiring shown here is
current at the time of printing, but it
may not match your machine.
Always use the wiring diagram
inside the motor junction box.

