



MODEL H6235 ADJUSTABLE SEAT INSTRUCTION SHEET

Introduction

The Model H6235 Adjustable Seat makes working close to the floor comfortable and convenient. The 12" padded seat adjusts from 16¹/₂" to 20³/₄", and features a built-in 15¹/₂" diameter tool tray and five 2¹/₂" urethane casters. A convenient air pressure lever adjustment controls the seat height. The adjustable seat height and rotation, the rolling casters, and the built-in tool tray make this seat ideal for sitting while making automotive repairs.

Inventory (Figure 1)

- A. Padded Seat..... 1
- B. Extension Tube 1
- C. Tool Tray Base..... 1



Figure 1. Model H6235.

	<p>⚠️ WARNING Falling off this seat may result in serious injury. DO NOT stand on any part of this seat or use it as a riding toy!</p>
--	---------------------------------------------------------------------------------------------------------------------------------------------------

	<p>⚠️ CAUTION Exceeding the maximum allowable weight of 350 lbs. for this adjustable seat may result in personal injury.</p>
--	-----------------------------------------------------------------------------------------------------------------------------------------

Assembly Instructions

1. Position the tool tray base with wheels down and insert the wide black end of the extension tube in the center hole of the base.
2. Insert the chrome end of the extension tube into the hole in the bottom of the padded seat.

Operation Instructions

- Raise the padded seat by lifting up on the lever found under the seat.
- Lower the padded seat by applying downward pressure on the seat while lifting up on the lever.

If you need help with your new adjustable seat, call our Tech Support at: (570)546-9663.