



MODELS T24649-52 URETHANE BANDSAW TIRES INSTRUCTIONS

For questions or help with this product contact Tech Support at (570) 546-9663 or techsupport@grizzly.com

Introduction

Urethane bandsaw tires provide a long lasting, easily installed, alternative to rubber bandsaw tires. Replace the tires as a pair to ensure even wear and optimum performance.

Models	Sizes
T24650	14"
T24651	17"
T24652	19"
T24649	21"



Figure 1. Urethane bandsaw tire.

Inventory

Description	Qty
A. Urethane Bandsaw Tires	2

Installation

1. Remove the bandsaw wheel.
2. Remove the old bandsaw tires from the wheels and clean the wheels thoroughly.
3. With the wheel held firmly in place, slip the end of the tire over the base of the wheel, as shown in **Figure 2**.



Figure 2. Installing the tire on the wheel.

4. Stretch the tire over the rest of the wheel, and carefully center around the wheel. If necessary, slide the shaft of a screwdriver under the tire and along the wheel, as shown in **Figure 3**, to help center it in position.



Figure 3. Using a screwdriver to help center the tire on the wheel.

Note: On some wheels, the tire may be slightly narrower than the wheel. As long as the tire is properly centered, this will not affect performance.

5. Replace the wheel.