




15" SCROLL SAW
MODEL G1572
PARTS LIST



GRIZZLY IMPORTS, INC.

COPYRIGHT ©1993 BY GRIZZLY IMPORTS, INC.
**WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY
SHAPE OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY IMPORTS, INC.**
REPRINTED MAY 1994

XIV. PARTS DIAGRAM

