


Parts Breakdown G5353



REF PART # DESCRIPTION

1	P5353001	AIR CAP SET
2	P5353002	O-RING
3	P5353003	FLUID NOZZLE
4	P5353004	HEAD
5	P5353005	SCREW
6	P5353006	GUN BODY
7	P5353007	WASHER
8	P5353008	NUT
9	P5353009	SLEEVE
10	P5353010	RETAINER
11	P5353011	WIPER
12	P5353012	NEEDLE
13	P5353013	NEEDLE NUT
14	P5353014	NUT
15	P5353015	GASKET
16	P5353016	HOUSING
17	P5353017	CONTROL BODY
18	P5353018	RING
19	P5353019	COMPRESSION SPRING
20	P5353020	SCREW
21	P5353021	NUT
22	P5353022	PACKING
23	P5353023	VALVE BODY

REF PART # DESCRIPTION

24	P5353024	VALVE
25	P5353025	COMPRESSION SPRING
26	P5353026	GASKET
27	P5353027	TRIGGER
28	P5353028	TRIGGER SCREW
29	P5353029	TRIGGER STUD
30	P5353030	SCREW
31	P5353031	CONNECTION
32	P5353032	STEM
33	P5353033	SLEEVE
34	P5353034	RETAINER RING
35	P5353035	SLEEVE
36	P5353036	O-RING
37	P5353037	SCREW
38	P5353038	FEED TUBE ASSEMBLY
39	P5353039	YOKE ASSEMBLY
40	P5353040	CAP LOCK
41	P5353041	DRIP TUBE
42	P5353042	CUP LID ASSEMBLY
43	P5353043	NUT
44	P5353044	CUP GASKET
45	P5353045	CUP