



WWW.GRIZZLY.COM

## AIR COMPRESSORS

MODEL G8694 2HP / G8695 2.5HP / G8889 2HP

## PARTS LIST



G8694



G8889



G8695

COPYRIGHT © 1999 BY GRIZZLY INDUSTRIAL, INC.

1821 VALENCIA ST., BELLINGHAM, WA 98226

**WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.**

NOVEMBER, 1999 PRINTED IN CHINA

### PARTS LIST DISCLAIMER

THIS PARTS LIST AND DRAWINGS REPRESENT THE CONFIGURATION OF THE MACHINE AS IT IS CURRENTLY BEING SHIPPED. THE MACHINE CONFIGURATION CAN CHANGE AS PRODUCT IMPROVEMENTS ARE INCORPORATED. IF YOU OWN AN EARLIER VERSION OF THE MACHINE, THIS PARTS LIST MAY NOT DEPICT YOUR MACHINE EXACTLY. CONTACT CUSTOMER SERVICE IF YOU HAVE ANY QUESTIONS ABOUT PART DIFFERENCES. PREVIOUS PARTS LIST VERSIONS ARE NOT AVAILABLE ONLINE.

# PARTS LIST G8694/G8695 AIR COMPRESSOR

| Ref. # | Part #    | Description               |
|--------|-----------|---------------------------|
| 001    | P8694001  | Bolt M6 x 155mm           |
| 002    | P8694002  | Spring Washer 6 mm        |
| 003    | P8694003  | Washer 6mm                |
| 004    | P8694004  | Rear Cover                |
| 005    | P8694005  | Corrugated Washer         |
| 006    | P8694006  | Bearing 180203            |
| 007    | P8694007  | Stator                    |
| 008    | P8694008  | Rotor                     |
| 009    | P8694009  | Crankcase                 |
| 010    | P8694010  | Bearing 108205            |
| 011    | P8694011  | Shaft                     |
| 012    | P8694012  | Cap Screw M8 x 30 mm      |
| 013    | P8694013  | Crank                     |
| 014    | P8694014  | Rubber Gasket             |
| 015    | P8694015  | Front Cover               |
| 016    | P8694016  | Washer 5 mm               |
| 017    | P8694017  | Spring Washer 5 mm        |
| 018    | P8694018  | Screw M6 x 20 mm          |
| 019    | P8694019  | Oil Leveler Washer        |
| 020    | P8694020  | Oil Leveler               |
| 021    | P8694021  | Breather pipe washer      |
| 022    | P8694022  | Breather pipe             |
| 023    | P8694023  | Stud M8 x 15 mm           |
| 023A   | P8694023A | Stud M8 x 20 mm           |
| 024    | P8694024  | Spring Washer 8 mm        |
| 025    | P8694025  | Connecting Rod            |
| 026    | P8694026  | Nut M8                    |
| 027    | P8694027  | Piston                    |
| 028    | P8694028  | Piston Pin Retaining Clip |
| 029    | P8694029  | Piston Pin                |
| 030    | P8694030  | Oil Scraper Ring          |
| 031    | P8694031  | Piston Ring               |
| 032    | P8694032  | Piston Ring               |
| 033    | P8694033  | Cylinder Gasket           |
| 034    | P8694034  | Cylinder                  |
| 035    | P8694035  | Valve Gasket              |
| 036    | P8694036  | Valve Plate               |
| 037    | P8694037  | Check Valve               |
| 038    | P8694038  | Valve Inner Gasket        |
| 039    | P8694039  | Valve Plate               |
| 040    | P8694040  | Cylinder Head Gasket      |
| 041    | P8694041  | Cylinder Head             |
| 042    | P8694042  | Right Angle Connector     |
| 043    | P8694043  | Hex Bolt M6 x 50          |
| 044    | P8694044  | Air Filter                |
| 045    | P8694045  | Washer 4 mm               |
| 046    | P8694046  | Wing Nut M4               |

| Ref. # | Part #   | Description            |
|--------|----------|------------------------|
| 047    | P8694047 | Nut M6                 |
| 048    | P8694048 | Capacitor              |
| 049    | P8694049 | Fan Cover              |
| 050    | P8694050 | Big Washer 5 mm        |
| 051    | P8694051 | Screw M5 x 12 mm       |
| 052    | P8694052 | Screw M4 x 12 mm       |
| 053    | P8694053 | Spring Washer 4 mm     |
| 054    | P8694054 | Screw M4 x 8 mm        |
| 055    | P8694055 | Washer 12 mm           |
| 056    | P8694056 | Fan                    |
| 057    | P8694057 | Spring Washer 12 mm    |
| 058    | P8694058 | Nut M12 x 1.5 mm       |
| 101    | P8694101 | Pressure Regulator     |
| 102    | P8694102 | Regulator Control Knob |
| 103    | P8694102 | Outlet Valve           |
| 104    | P8694104 | Output Pressure Gauge  |
| 105    | P8694105 | Tank Pressure Gauge    |
| 106    | P8694106 | One-Way Check Valve    |
| 107    | P8694107 | Discharge Pipe         |
| 108    | P8694108 | Drain Cock             |
| 109    | P8694109 | Wheel                  |
| 110    | P8694110 | Wheel Hub              |
| 111    | P8694111 | Pressure Tank          |
| 112    | P8694112 | Handle Grip            |
| 113    | P8694113 | Handle                 |
| 114    | P8694114 | Safety Relief Valve    |
| 115    | P8694115 | Rubber Pad             |
| 116    | P8694116 | Power Cord             |
|        |          |                        |

