


# Parts Breakdown



# Parts List

## REF PART # DESCRIPTION

|    |           |                                          |
|----|-----------|------------------------------------------|
| 1  | PH8148001 | FLAT WASHER 5MM (H8148/H8149)            |
|    | PH8150001 | FLAT WASHER 1/4 (H8150)                  |
| 2  | PH8148002 | DATA/WARNING LABEL (H8148)               |
|    | PH8149002 | DATA/WARNING LABEL (H8149)               |
|    | PH8150002 | DATA/WARNING LABEL (H8150)               |
| 3  | PFS02M    | FLANGE SCREW M6-1 X 12                   |
| 4  | PLW17M    | LOCK WASHER 7MM                          |
| 5  | PS06      | PHLP HD SCR 10-24 X 3/8                  |
| 6  | PH8148006 | FEMALE KNOB 1/4-20                       |
| 7  | PS18      | PHLP HD SCR 10-24 X 1/4<br>(H8148/H8149) |
|    | PS04      | PHLP HD SCR 1/4-20 X 1/2 (H8150)         |
| 8  | PB17M     | HEX BOLT M6-1.25 X 10                    |
| 9  | PH8148009 | NUTPLATE                                 |
| 10 | PH8148010 | EYESHIELD (H8148)                        |
|    | PH8149010 | EYESHIELD (H8149)                        |
|    | PH8150010 | EYESHIELD (H8150)                        |
| 11 | PH8148011 | LEFT BRACKET (H8148/H8149)               |
|    | PH8150011 | LEFT BRACKET (H8150)                     |
| 12 | PH8148012 | RIGHT BRACKET (H8148/H8149)              |
|    | PH8150012 | RIGHT BRACKET (H8150)                    |
| 13 | PH8148013 | LEFT SPARK ARRESTOR (H8148/H8149)        |
|    | PH8150013 | LEFT SPARK ARRESTOR (H8150)              |
| 14 | PH8148014 | RIGHT SPARK ARRESTOR (H8148/H8149)       |
|    | PH8150014 | RIGHT SPARK ARRESTOR (H8150)             |
| 15 | PH8148015 | ARROW LABEL                              |
| 16 | PH8148016 | RUBBER FOOT (H8148)                      |
|    | PH8149016 | RUBBER FOOT (H8149)                      |
|    | PH8150016 | RUBBER FOOT (H8150)                      |
| 17 | PH8148017 | BASE PLATE (H8148)                       |
|    | PH8149017 | BASE PLATE (H8149)                       |
|    | PH8150017 | BASE PLATE (H8150)                       |
| 18 | PH8148018 | SWITCH PLATE (H8148)                     |
|    | PH8149018 | SWITCH PLATE (H8149/H8150)               |
| 19 | G8988     | SAFETY PADDLE SWITCH<br>(H8148/H8149)    |
|    | PH8150019 | TOGGLE SWITCH RF-1001 (H8150)            |
| 20 | PLW01M    | LOCK WASHER 5MM                          |
| 21 | PH8148021 | COPPER WASHER 5MM                        |
| 22 | PS18      | PHLP HD SCR 10-24 X 1/4                  |
| 23 | PH8148023 | POWER CORD 110V                          |
| 24 | PH8148024 | CAPACITOR CAP (H8148/H8149)              |
|    | PH8150024 | CAPACITOR CAP (H8150)                    |
| 25 | PH8148025 | FIXTURE CLIP (H8148/H8149)               |
|    | PH8150025 | FIXTURE CLIP (H8150)                     |
| 26 | PH8148026 | CAPACITOR 100MFD 125V (H8148)            |
|    | PH8149026 | CAPACITOR 200MFD 125V (H8149)            |
|    | PH8150026 | CAPACITOR 300MFD 125V (H8150)            |
| 27 | PS18      | PHLP HD SCR 10-24 X 1/4                  |

## REF PART # DESCRIPTION

|    |           |                                      |
|----|-----------|--------------------------------------|
| 28 | PH8148028 | WIRE PLATE                           |
| 29 | PH8148029 | STRAIN RELIEF                        |
| 30 | PB07      | HEX BOLT 5/16-18 X 3/4               |
| 31 | PW01M     | FLAT WASHER 8MM                      |
| 32 | PH8148032 | RIGHT TOOL REST (H8148)              |
|    | PH8149032 | RIGHT TOOL REST (H8149)              |
|    | PH8150032 | RIGHT TOOL REST (H8150)              |
| 33 | PH8148033 | LEFT TOOL REST (H8148)               |
|    | PH8149033 | LEFT TOOL REST (H8149)               |
|    | PH8150033 | LEFT TOOL REST (H8150)               |
| 34 | PS04      | PHLP HD SCR 1/4-20 X 1/2             |
| 35 | PH8148035 | LEFT OUTER WHEEL GUARD (H8148)       |
|    | PH8149035 | LEFT OUTER WHEEL GUARD (H8149)       |
|    | PH8150035 | LEFT OUTER WHEEL GUARD (H8150)       |
| 36 | PH8148036 | RIGHT OUTER WHEEL GUARD (H8148)      |
|    | PH8149036 | RIGHT OUTER WHEEL GUARD (H8149)      |
|    | PH8150036 | RIGHT OUTER WHEEL GUARD (H8150)      |
| 37 | PH8148037 | RIGHT 1/2" ARBOR NUT (H8148)         |
|    | PH8149037 | RIGHT 5/8" ARBOR NUT (H8149)         |
|    | PH8150037 | RIGHT 1" ARBOR NUT (H8150)           |
| 38 | PH8148038 | LEFT 1/2" ARBOR NUT (H8148)          |
|    | PH8149038 | LEFT 5/8" ARBOR NUT (H8149)          |
|    | PH8150038 | LEFT 1" ARBOR NUT (H8150)            |
| 39 | PH8148039 | 1/2" BORE A60 GRINDING WHEEL (H8148) |
|    | PH8149039 | 5/8" BORE A60 GRINDING WHEEL (H8149) |
|    | PH8150039 | 1" BORE A60 GRINDING WHEEL (H8150)   |
| 40 | PH8148040 | 1/2" BORE A36 GRINDING WHEEL (H8148) |
|    | PH8149040 | 5/8" BORE A36 GRINDING WHEEL (H8149) |
|    | PH8150040 | 1" BORE A36 GRINDING WHEEL (H8150)   |
| 41 | PH8148041 | 1/2" WHEEL FLANGE (H8148)            |
|    | PH8149041 | 5/8" WHEEL FLANGE (H8149)            |
|    | PH8150041 | 1" WHEEL FLANGE (H8150)              |
| 42 | PS04      | PHLP HD SCR 1/4-20 X 1/2             |
| 43 | PH8148043 | RIGHT INNER WHEEL GUARD (H8148)      |
|    | PH8149043 | RIGHT INNER WHEEL GUARD (H8149)      |
|    | PH8150043 | RIGHT INNER WHEEL GUARD (H8150)      |
| 44 | PH8148044 | LEFT INNER WHEEL GUARD (H8148)       |
|    | PH8149044 | LEFT INNER WHEEL GUARD (H8149)       |
|    | PH8150044 | LEFT INNER WHEEL GUARD (H8150)       |
| 45 | PS22      | PHLP HD SCR 10-24 X 5/8              |
| 46 | PH8148046 | CENTRIFUGAL SWITCH PLATE (H8148)     |
|    | PH8149046 | CENTRIFUGAL SWITCH PLATE (H8149)     |
|    | PH8150046 | CENTRIFUGAL SWITCH PLATE (H8150)     |
| 47 | PH8148047 | CENTRIFUGAL SWITCH ASSY. (H8148)     |
|    | PH8149047 | CENTRIFUGAL SWITCH ASSY. (H8149)     |
|    | PH8150047 | CENTRIFUGAL SWITCH ASSY. (H8150)     |
| 48 | PH8148048 | MOTOR COVER (H8148)                  |
|    | PH8149048 | MOTOR COVER (H8149)                  |
|    | PH8150048 | MOTOR COVER (H8150)                  |



| REF | PART #    | DESCRIPTION                 |
|-----|-----------|-----------------------------|
| 49  | P6202     | BALL BEARING 6202ZZ (H8148) |
|     | P6204     | BALL BEARING 6204ZZ (H8149) |
|     | P6206     | BALL BEARING 6206ZZ (H8150) |
| 50  | PH8148050 | FAN (H8148)                 |
|     | PH8149050 | FAN (H8149)                 |
|     | PH8150050 | FAN (H8150)                 |
| 51  | PN05      | HEX NUT 1/4-20              |
| 52  | PW09M     | FLAT WASHER 7MM             |
| 53  | PSS07     | SET SCREW 1/4-20 X 1/2      |
| 54  | PH8148054 | BASE (H8148)                |
|     | PH8149054 | BASE (H8149)                |
|     | PH8150054 | BASE (H8150)                |

| REF | PART #    | DESCRIPTION             |
|-----|-----------|-------------------------|
| 55  | PH8148055 | MOTOR HOUSING (H8148)   |
|     | PH8149055 | MOTOR HOUSING (H8149)   |
|     | PH8150055 | MOTOR HOUSING (H8150)   |
| 56  | PH8148056 | STRAIN RELIEF           |
| 57  | PH8148057 | STATOR (H8148)          |
|     | PH8149057 | STATOR (H8149)          |
|     | PH8150057 | STATOR (H8150)          |
| 59  | PS06      | PHLP HD SCR 10-24 X 3/8 |
| 60  | PH8148060 | ROTOR AND SHAFT (H8148) |
|     | PH8149060 | ROTOR AND SHAFT (H8149) |
|     | PH8150060 | ROTOR AND SHAFT (H8150) |

## WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or [www.grizzly.com](http://www.grizzly.com) to order new labels.

