




Phone #: (360) 734-3482 • Online Tech Support: tech-support@shopfox.biz • Web: www.shopfox.biz


D3674	. Back Cutter for D3333 2 ¹ /4" Crown
D3675	. Back Cutter for D3334 2 ³ / ₄ " Crown
D3676	. Back Cutter for D3335 3 ¹ /4" Crown
D3677	. Back Cutter for D3336 3 ⁵ /8" Crown
D3678	. Back Cutter for D3337 4 ¹ /4" Crown
D3679	. Back Cutter for D3338 4 ⁵ /8" Crown

Installation

Install the back cutters as shown, using the bolts only. DO NOT use the washers or the bolts will hit the workpiece during operation.



COPYRIGHT © JANUARY, 2008 BY WOODSTOCK INTERNATIONAL, INC. REVISED APRIL, 2008 (TR) WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT #10438TR THE WRITTEN APPROVAL OF WOODSTOCK INTERNATIONAL, INC.



COPYRIGHT © JANUARY, 2008 BY WOODSTOCK INTERNATIONAL, INC. REVISED APRIL, 2008 (TR) WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT #10438TR THE WRITTEN APPROVAL OF WOODSTOCK INTERNATIONAL, INC.