



# MODELS T23070-72 URETHANE BANDSAW TIRES INSTRUCTIONS

For questions or help with this product contact Tech Support at (570) 546-9663 or techsupport@grizzly.com

## Introduction

Urethane bandsaw tires provide a long lasting, easily installed, alternative to rubber bandsaw tires. Replace the tires as a pair to ensure even wear and optimum performance.

Models	Sizes
T23070 .....	14"
T23071 .....	17"
T23072 .....	19"



Figure 1. Urethane bandsaw tire.

## Inventory

Description	Qty
A. Urethane Bandsaw Tires .....	2

## Installation

1. Remove the bandsaw wheel.
2. Remove the old bandsaw tires from the wheels and clean the wheels thoroughly.

3. With the wheel held firmly in place, slip the end of the tire over the base of the wheel, as shown in **Figure 2**.



Figure 2. Installing the tire on the wheel.

4. Stretch the tire over the rest of the wheel, adjusting it as needed to center it on the wheel.

**Tip:** Carefully slide the shaft of a screwdriver under the tire and along the wheel to adjust the tire on the wheel, as shown in **Figure 3**.



Figure 3. Sliding screwdriver to adjust the placement of the tire.

5. Replace the wheel.

COPYRIGHT © MAY, 2012 BY GRIZZLY INDUSTRIAL, INC.

**WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.**

#KN15018 PRINTED IN THE UNITED STATES