


MODEL T32733 SKEW GRINDING ATTACHMENT FOR T32732 INSTRUCTIONS

For questions or help with this product contact Tech Support at (570) 546-9663 or techsupport@grizzly.com

Introduction

The Model T32733 Skew Grinding Attachment allows you to securely position skew chisels in two additional V-holders at offset angles for precision sharpening. The left and right V-holders are adjustable to allow you to maintain bevels at exact skew angles.



AWARNING

To reduce your risk of serious injury, read this entire manual BEFORE using machine.

Inventory

| Description | | Qty |
|-------------|----------------------------------|-----|
| Α. | Skew Attachment | 1 |
| B. | Button Head Cap Screws M6-1 x 10 | 2 |
| C. | Hex Wrench 4mm | 1 |




Figure 1. Inventory.

Assembly

The Model T32733 must be attached to the long arm of the T32732 Bench Grinder Sharpening System before use.



To assemble:

1. Attach skew attachment to long arm with (2) M6-1 x 10 button head cap screws (see Figure 2).




Figure 2. Attaching skew attachment to long arm.

COPYRIGHT © OCTOBER, 2021 BY GRIZZLY INDUSTRIAL, INC.
NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE
OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.
(FOR MODELS MFD. SINCE 10/21) #CS22113 PRINTED IN TAIWAN

Using Skew Attachment

The skew attachment supplies two additional V-holders for supporting a woodturning tool using the long arm. Since these are offset from the center of the grinding wheel, and are adjustable from side to side, they allow for sharper-angled bevel grinding.

IMPORTANT: Refer to your grinder manual or instructions for information on safely operating your grinder.

AWARNING

Eye and face injuries and respiratory problems can occur while operating this tool. Wear personal protective equipment to reduce your risk from these hazards.









AWARNING

Keep hair, clothing, and jewelry away from moving parts at all times. Entanglement can result in death, amputation, or severe crushing injuries!

To use skew attachment:

- DISCONNECT GRINDER FROM POWER!
- 2. Place woodturning tool handle in desired V-holder (see **Figure 3**).

Note: Loosen knobs shown in **Figure 3** to adjust outside V-holder positions.

Adjust long arm until entire bevel of tool contacts grinding wheel, then secure position by pulling base handles forward (see Figure 3).




Figure 3. Example of tool supported by long arm.

- **4.** Tilt tool away from grinding wheel, connect grinder to power, and turn machine *ON*.
- Use firm grip to return tool to surface of grinding wheel to perform grinding operation (see Figure 4).




Figure 4. Example of skew attachment in use.

Note: Chisel with short left side should be supported by left V-holder while chisel with short right side should be supported by right V-holder (see **Figure 5**).




Figure 5. V-holder side determined by short side of chisel.

