

MODEL T34392 SPLIT-TOP TOOL STAND INSTRUCTIONS

For questions or help with this product contact Tech Support at (570) 546-9663 or techsupport@grizzly.com

Introduction


The Model T34392 Split-Top Tool Stand is ideally suited for small shops. The hevea wood top can be adjusted from 14" to 17½" to accommodate a variety of benchtop machines of up to 500 lbs. The flared steel legs and sturdy cross bracing provide a stable foundation. Non-marring feet reduce vibration and help protect floors from damage.



Figure 1. Model T34392 Split-Top Tool Stand.

Specifications

Max. Top Dimensions	25" x 17½"
Stand Height	32"
Footprint	
Product Weight	26 lbs.
Max. Weight Capacity	500 lbs.



AWARNING

To reduce your risk of serious injury, read this entire manual BEFORE using stand.

WARNING

Failure to follow these guidelines could result in serious personal injury:

- Ensure tool stand is correctly set up on a stable, level surface before using.
- Use proper mounting hardware when securing a tool to the stand.
- DO NOT apply an unbalanced load that might cause tipping.
- · DO NOT stand or sit on tool stand.
- DO NOT exceed maximum weight capacity of 500 lbs.

COPYRIGHT © DECEMBER, 2024 BY GRIZZLY INDUSTRIAL, INC.

NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE

OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.

(FOR MODELS MFD. SINCE 12/24) #SG23467 PRINTED IN CAMBODIA

Inventory

Des	Description Q		
A.	Top Long Braces	2	
B.	Table Boards	2	
C.	Top Short Braces	2	
D.	Bottom Long Braces	2	
E.	Shelf Boards	2	
F.	Bottom Short Braces	2	
G.	Stand Legs	4	
H.	Tap Screws M5 x 15	. 8, 4	
I.	Button Head Cap Screws M6-1 x 15	16, 8	
J.	Foot Pads	4	
K.	Lock Nuts M6-1	16, 8	




Figure 2. Inventory.

Assembly



Tools Needed	Qty
Hex Wrench 4mm	1
Open-End Wrench 10mm	1
Phillips Head Screwdriver #2	1
Power Drill	1
Drill Bit 3mm	1

To assemble tool stand:

1. Arrange (2) top long braces and (2) top short braces in a rectangle, then attach stand legs to each corner using (16) M6-1 x 15 button head cap screws and (16) M6-1 lock nuts (see **Figure 3**). Only hand-tighten for now.

Note: Do not fully tighten connecting hardware until stand is fully assembled.




Figure 3. Attaching stand legs to top braces.

Arrange table boards together, then place stand on top (see Figure 4). Ensure stand is square with boards and evenly spaced side to side and front to back.




Figure 4. Stand positioned on table boards.

3. Using top short brace slots as a template, mark and drill (8) pilot holes in table boards at locations shown in **Figure 5**, then attach boards to stand with (8) M5 x 15 tap screws through top short braces. Only hand-tighten for now.




Figure 5. Attaching table boards to top short braces.

- **4.** Adjust table boards apart as desired.
- 5. Using top long brace holes as a template, mark and drill (4) pilot holes in table boards at locations shown in **Figure 6**, then attach boards to stand with (4) M5 x 15 tap screws through top long braces.




Figure 6. Attaching table boards to top long braces.

- **6.** Fully tighten screws from **Step 3**.
- 7. Attach (2) bottom short braces and (2) bottom long braces using (8) M6-1 x 15 button head cap screws and (8) M6-1 lock nuts (see **Figure 7**). Only hand-tighten for now.




Figure 7. Attaching lower braces to legs.

8. Press (4) foot pads onto stand legs, as shown in **Figure 8**.




Figure 8. Pressing foot pads onto stand legs.

Flip stand upright, and place (2) shelf boards on lower braces (see Figure 9).





Figure 9. Shelf boards placed on lower braces.

 Place tool stand on flat surface, push down on table top to ensure all 4 legs contact floor, then fully tighten fasteners from Step 1 and Step 7.

T34392 Parts Breakdown & List



REF PART# **DESCRIPTION**

1	PT34392001	LONG BRACE, TOP
2	PT34392002	TABLE BOARD
3	PT34392003	SHORT BRACE, TOP
4	PT34392004	LONG BRACE, BOTTOM
5	PT34392005	SHELF BOARD
6	PT34392006	SHORT BRACE, BOTTOM
7	PT34392007	STAND LEG

REF PART# DESCRIPTION

8	PT34392008	FOOT PAD
9	PT34392009	BUTTON HD CAP SCR M6-1 X 15
10	PT34392010	LOCK NUT M6-1
11	PT34392011	TAP SCREW M5 X 15
12	PT34392012	MACHINE ID LABEL
13	PT34392013	GRIZZLY.COM LABEL
14	PT34392014	TOUCH-UP PAINT, GLOSSY BLACK

AWARNING

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this machine MUST replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or www.grizzly.com.

Please Note: We do our best to stock replacement parts whenever possible, but we cannot guarantee that all parts shown here are available for purchase. Call (800) 523-4777 or visit our online parts store at www.grizzly.com to check for availability.



