



For questions or help with this product contact Tech Support at (570) 546-9663 or techsupport@grizzly.com

MODEL T34445 3-PIECE MITER SAW WORKSTATION INSTRUCTIONS

Introduction

The Model T34445 3-Piece Miter Saw Workstation provides a stable and adjustable platform for your miter saw. The workstation features adjustable 10-gauge steel legs, 14-gauge steel braces, and a 1½" thick hevea wood butcher block tabletop.




Figure 1. Model T34445 3-Piece Miter Saw Workstation.

Specifications

Center Stand Height Range28"–31"
Side Stand Height Range.....32"–35"
Tabletop Dimensions32" W x 24" D x 1½" H
Weight Capacity500 lbs.

Needed for Assembly

Safety Glasses (Per Person).....1 Pr.
Open-End Wrenches 19mm.....2
Hex Wrench 5mm.....1
Power Drill1
Drill Bit 4.25mm1
Phillips Head Bit #21
Pencil.....1
Level.....1



⚠ WARNING

Wear safety glasses during the entire setup process!

Inventory

Main (Figure 2)	Qty
A. Front Top Long Braces.....	3
B. Rear Top Long Braces	3
C. Top Short Braces	6
D. Bottom Short Braces	6
E. Front Bottom Long Braces	3
F. Rear Bottom Long Braces.....	3
G. Connector Plates	4
H. Long Legs.....	8
I. Short Legs.....	4
J. Tabletops	3




Figure 2. Inventory.

COPYRIGHT © MARCH, 2025 BY GRIZZLY INDUSTRIAL, INC.
NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE
OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.
(FOR MODELS MFD. SINCE 03/25) #JA23508 PRINTED IN CAMBODIA

V1.03.25

*****Keep for Future Reference*****

Fasteners (Figure 3)		Qty
K.	Button Head Cap Screws M8-1.25 x 20....	112
L.	Tap Screws M5 x 25.....	42
M.	Hex Nuts M8-1.25.....	16
N.	Flat Washers 8mm	32




Figure 3. Fasteners (1 of each shown).



Assembly

The Model T34445 must be fully assembled before it can be used. Before beginning the assembly process, refer to **Needed for Assembly** and gather all listed items.

To assemble workstation:

1. Attach (4) long legs to (1) front top long brace, (1) rear top long brace, and (2) top short braces using (16) M8-1.25 x 20 button head cap screws (see **Figure 4**).

Note: Top braces have holes across top edge for attaching table tops while bottom braces do not.




Figure 4. Long legs attached to top braces.

2. Attach (1) front bottom long brace, (1) rear bottom long brace, and (2) bottom short braces to assembly from **Step 1** with (16) M8-1.25 x 20 button head cap screws (see **Figure 5**).




Figure 5. Bottom braces attached to assembly.

3. Repeat **Steps 1–2** to assemble remaining tall stand assembly.
4. Repeat **Steps 1–2** with (4) short legs and remaining braces to assemble short stand assembly.
5. Place (3) tabletops face down on a flat protected surface with alignment templates facing up.
6. Align stand assemblies with alignment templates on tabletops, as shown in **Figure 6**.




Figure 6. Stand assembly aligned with templates.



7. On each tabletop, use stand assembly as a template to mark center of each fastener hole, then remove stand assembly, and drill (14) pilot holes into each table top (see **Figure 7**).




Figure 7. Pilot holes drilled into table top.

8. Place (1) stand assembly on each tabletop, then secure each with (14) M5 x 25 tap screws (see **Figure 8**).




Figure 8. Attaching stand assembly to table top.

9. Turn stand assemblies right side up.
10. Loosen or tighten adjustable feet (see **Figure 9**) to adjust each stand to desired height.




Figure 9. Location of adjustable feet.

11. Secure stand assemblies together with (4) connector plates, (16) M8-1.25 x 20 button head cap screws, (16) M8-1.25 hex nuts and (32) 8mm flat washers (see **Figure 10**) Finger-tighten for now.

Note: Ensure short stand assembly is positioned between tall stand assemblies and that all stand labels face the same direction, as shown in **Figure 10**.





Figure 10. Attaching connector plates.

12. Check workspace to ensure it is level front to back and left to right.
 - If workstation *is* level, then no further action is needed. Tighten fasteners from **Step 11**.
 - If workstation *is not* level, tighten or loosen adjustable feet (see **Figure 9**) as needed until workstation is level, then tighten fasteners from **Step 11**.
13. Hold each adjustable foot in place while you adjust each foot hex nut up against stand to secure setting.



T34445 Parts Breakdown & List



!WARNING

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this product **MUST** replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or www.grizzly.com.

REF	PART #	DESCRIPTION
1	PT34445001	BRACE, LONG TOP
2	PT34445002	BRACE, SHORT TOP
3	PT34445003	LEG, LONG 29"
4	PT34445004	BRACE, LONG BOTTOM
5	PT34445005	BRACE, SHORT BOTTOM
6	PT34445006	TABLETOP
7	PT34445007	LEG, SHORT 25"
8	PT34445008	CONNECTOR PLATE
9	PT34445009	BUTTON HD CAP SCR M8-1.25 X 20

REF	PART #	DESCRIPTION
10	PT34445010	TAP SCREW M5 X 25
11	PT34445011	HEX NUT M8-1.25
12	PT34445012	FLAT WASHER 8MM
13	PT34445013	ADJUSTABLE FOOT M12-1.75 X 100
14	PT34445014	HEX NUT M12-1.75
20	PT34445020	GRIZZLY INDUSTRIAL LOGO GREEN & GOLD
21	PT34445021	COMBO LABEL
22	PT34445022	TOUCH-UP PAINT, GLOSSY BLACK

Please Note: We do our best to stock replacement parts whenever possible, but we cannot guarantee that all parts shown here are available for purchase. Call (800) 523-4777 or visit our online parts store at www.grizzly.com to check for availability.

