



Parts Breakdown



Parts Breakdown



Parts List

REF	PART #	DESCRIPTION
1	P0463001	TRANSMISSION GEAR
2	P0463002	DIAL FORK
3	P0463003	SMALL GEAR RACK
5	P0463005	DUST CAP
6	P0463006	OIL SEAL
7	P0463007	SPINDLE
8	P0463008	SLEEVE
9	P0463009	OIL SEAL
10	P0463010	QUILL
11	P0463011	HEAD CASTING
12	P0463012	DRAWBAR
13	P0463013	SPACER
14	P0463014	SPACER
15	P0463015	SLEEVE
16	P0463016	BEARING SEAT
17	P0463017	SPINDLE GEAR
18	P0463018	COVER
19	P0463019	SPACER
20	P0463020	DRAWBAR CAP
21	P0463021	BEARING SEAT
22	P0463022	GEAR
23	P0463023	SHAFT
24	P0463024	SLEEVE
25	P0463025	TRANSMISSION GEAR
26	P0463026	FENDER WASHER
27	P0463027	SHAFT
28	P0463028	UPPER FLANGE
29	P0463029	GEAR
30	P0463030	LOWER FLANGE
31	P0463031	BEARING SEAT
32	P0463032	SPACER
33	P0463033	FLANGE
34	P0463034	COVER
35	P0463035	GEAR
36	P0463036	FLAT WASHER 12MM
37	P0463037	MOTOR FIXED TRAY
38	P0463038	CONTROL BOX
39	P0463039	SPACER
40	P0463040	GEAR
41	P0463041	SPACER
42	P0463042	SPRING COVER
43	P0463043	FLAT COIL SPRING
44	P0463044	BUSHING
45	P0463045	LEFT SUPPORT FLANGE
46	P0463046	PINION
47	P0463047	RIGHT SUPPORT FLANGE
48	P0463048	COLLAR
49	P0463049	HANDLE HUB
50	P0463050	CAP
51	P0463051	DIAL FORK SHAFT

REF	PART #	DESCRIPTION
52	P0463052	QUILL HANDLE
53	P0463053	SHAFT
54	P0463054	BUSHING
55	P0463055	RIGHT SUPPORT FLANGE
56	P0463056	BUSHING
57	P0463057	HIGH/LOW KNOB
58	P0463058	SPINDLE LOCK SLEEVE II
59	P0463059	SPINDLE LOCK HANDLE
60	P0463060	SPINDLE LOCK SLEEVE I
61	P0463061	SPACER
62	P0463062	SMALL HANDLE
63	P0463063	GIB ADJUST SCREW
64	P0463064	GIB
65	P0463065	COLUMN PLATE
66	P0463066	END CAP
67	P0463067	CAP
68	P0463068	ARBOR R8/JT6
68-1	P0463068-1	CHUCK 3-16MM/JT6
68-2	P0463068-2	CHUCK KEY
69	P0463069	SMALL HANDLE
70	P0463070	COMPRESSION SPRING
71	P0463071	FLAT SPRING
72	P0463072	BEARING 8106
73	P0463073	BEARING 6007
74	P0463074	BEARING 6001
75	P0463075	TIMING BELT
76	P0463076	OIL FITTING
77	P0463077	OIL FITTING
78	P0463078	STEEL BALL
79	P0463079	BEARING Z007106
80	P0463080	BEARING 6006
81	P0463081	CAP SCREW M5-.8 X 20
82	P0463082	CAP SCREW M5-.8 X 40
83	P0463083	SOLID PIN 6 X 25
84	P0463084	KEY 4 X 4 X 40
85	P0463085	PHLP HD SCR M4-.7 X 16
86	P0463086	ROLL PIN 4 X 16
87	P0463087	SET SCREW M6-1 X 16
88	P0463088	HEX NUT M6-1
89	P0463089	CAP SCREW M5-.8 X 12
90	P0463090	ROLL PIN 4 X 8
91	P0463091	SET SCREW M5-.8 X 12
92	P0463092	SET SCREW M6-1 X 12
93	P0463093	LOCK RING M27 -1.5
94	P0463094	INT RETAINING RING 62MM
95	P0463095	EXT RETAINING RING 35MM
96	P0463096	FLAT WASHER 12MM
97	P0463097	HEX NUT M12-1.75
98	P0463098	KEY 8 X 8 X 20



Parts List

REF	PART #	DESCRIPTION
99	P0463099	KEY 4 X 4 X 25
100	P0463100	KEY 5 X 5 X 20
101	P0463101	CAP SCREW M4-.7 X 16
102	P0463102	LOCK WASHER 4MM
103	P0463103	KEY 4 X 4 X 16
104	P0463104	CAP SCREW M4-.7 X 8
105	P0463105	EXT RETAINING RING 16MM
106	P0463106	PHLP HD SCR M5-.8 X 16
107	P0463107	PHLP HD SCR M4-.7 X 8
108	P0463108	EXT RETAINING RING 10MM
109	P0463109	KEY 3 X 3 X 16
110	P0463110	PHLP HD SCR M6-1 X 16
111	P0463111	CAP SCREW M4-.7 X 6
112	P0463112	EXT RETAINING RING 16MM
113	P0463113	ROLL PIN 3 X 10
114	P0463114	EXT RETAINING RING 16MM
115	P0463115	ROLL PIN 4 X 16
116	P0463116	CAP SCREW M4-.7 X 16
117	P0463117	CAP SCREW M6-1 X 16
118	P0463118	CAP SCREW M5-.8 X 16
119	P0463119	FLAT WASHER 5MM
120	P0463120	ROLL PIN 4 X 10
121	P0463121	LONG HANDLE SLEEVE
122	P0463122	SET SCREW M6-1 X 6
123	P0463123	CAP SCREW M10-1.5 X 25
124	P0463124	KEY 4 X 4 X 12
125	P0463125	ROLL PIN 5 X 10
126	P0463126	ROLL PIN 6 X 26
127	P0463127	SET SCREW M5-.8 X 6
128	P0463128	PHLP HD SCR M4-.7 X 20
129	P0463129	COLUMN
130	P0463130	LEFT SIDE PLATE
131	P0463131	RIGHT SIDE PLATE
133	P0463133	LIMIT SLEEVE
134	P0463134	LOWER BEARING SEAT
135	P0463135	VERTICAL LEAD SCREW
136	P0463136	VERTICAL LEAD NUT
137	P0463137	SUPPORT
138	P0463138	UPPER BEARING SEAT
139	P0463139	REAR CABINET
140	P0463140	SMALL COVER
141	P0463141	LARGE COVER
142	P0463142	CAP SCREW M6-1 X 10
143	P0463143	CAP SCREW M5-.8 X 8
144	P0463144	FLAT WASHER 10MM
145	P0463145	CAP SCREW M8-1.25 X 20
146	P0463146	ROLL PIN 8 X 45
147	P0463147	SET SCREW M5-.8 X 8
148	P0463148	PHLP HD SCR M4-.7 X 6
149	P0463149	HEX BOLT M10-1.5 X 50

REF	PART #	DESCRIPTION
150	P0463150	ROLL PIN 4 X 20
151	P0463151	ROLL PIN 4 X 25
152	P0463152	ROLL PIN 4 X 30
153	P0463153	RULER
155	P0463155	BEARING 8101
156	P0463156	BEARING 6001
157	P0463157	ADJUSTABLE FOOT
158	P0463158	BASE
159	P0463159	SADDLE
160	P0463160	WORKTABLE
161	P0463161	SPACER
162	P0463162	X-AXIS FEED SCREW
163	P0463163	Y-AXIS FEED SCREW NUT
164	P0463164	X-AXIS FEED SCREW NUT
165	P0463165	Y-AXIS GIB
166	P0463166	X-AXIS BEARING SEAT
167	P0463167	GEAR 48T LARGE
167A	P0463167A	GEAR SMALL 24T
168	P0463168	SLEEVE
169	P0463169	Z-AXIS SHAFT
170	P0463170	SUPPORT FLANGE
171	P0463171	Y-AXIS FEED SCREW
172	P0463172	X-AXIS GIB
173	P0463173	Y-AXIS BEARING SEAT
174	P0463174	HEX NUT M12-1.75
175	P0463175	HANDWHEEL
176	P0463176	HEX NUT M8-1.25
177	P0463177	HANDWHEEL
178	P0463178	POINTER
179	P0463179	HANDLE SLEEVE
180	P0463180	INLAY RING
181	P0463181	GRADUATED DIAL
182	P0463182	SHOULDER SCREW M8-1.25 X 55
183	P0463183	CAP SCREW M4-.7 X 12
184	P0463184	SET SCREW M6-1 X 25
185	P0463185	FLAT WASHER 8MM
186	P0463186	ROLL PIN 3 X 20
187	P0463187	PHLP HD SCR M6-1 X 6
188	P0463188	RIVET
189	P0463189	CAP NUT
196	P0463196	MACHINE ID LABEL I
197	P0463197	MOTOR LABEL
198	P0463198	MACHINE ID LABEL II
199	P0463199	LOCK LABEL
208	P0463208	FINE LEAD WIRE 1 X 85
212	P0463212	STRAIN RELIEF
213	P0463213	FLEX CONDUIT
214	P0463214	SWITCH LABEL
215	P0463215	FUSE BOX
216	P0463216	POWER INDICATING LAMP



Parts List

REF	PART #	DESCRIPTION
217	P0463217	RPM CONTROLER
218	P0463218	EMERGENCY STOP SWITCH
219	P0463219	REV/OFF/FWD SWITCH
220	P0463220	PC BOARD
223	P0463223	POWER CORD
224	P0463224	MOTOR
225	P0463225	FAULT INDICATING LAMP
226	P0463226	POWER SWITCH
227	P0463227	SAFETY GLASSES LABEL
228	P0463228	READ MANUAL LABEL
229	P0463229	ELECTRICITY LABEL
230	P0463230	UNPLUG 110V LABEL
231	P0463231	ENTAGLEMENT LABEL

REF	PART #	DESCRIPTION
232	P0463232	SPINDLE BREAK-IN LABEL
233	P0463233	CHANGE GEARS LABEL
234	P0463234	WRENCH 17 X 19
235	P0463235	WRENCH 12 X 14
236	P0463236	WRENCH 8 X 10
237	P0463237	HEX WRENCH 3MM
238	P0463238	HEX WRENCH 4MM
239	P0463239	HEX WRENCH 5MM
240	P0463240	HEX WRENCH 6MM
241	P0463241	T-NUT 3/8"
242	P0463242	MOTOR BRUSH
243	P0463243	PIN SPANNER WRENCH

WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.

