




G0506X/G0506X3 Lower Frame and Motor



G0506X/G0506X3 Lower Wheel Assembly




G0506X/G0506X3 Table and Blade Guides



[illegible]

G0506X/G0506X3 Upper Wheel Assembly



G0506X/G0506X3 Parts List

REF	PART #	DESCRIPTION
1	P0506001	FRAME
2	P0506002	HINGE PIN
3	P0506003	UPPER WHEEL GUARD
4	P0506004	LOWER WHEEL GUARD
5	PSB17	CAP SCREW 1/4-20 X 3/8
6	P0506006	WHEEL GUARD LOCK KNOB
7	PSB05	CAP SCREW 1/4-20 X 3/4
8	PN05	HEX NUT 1/4-20
9	P0506X009	MOTOR 3HP, 1 PHASE (G0506X)
9	P0506X3009	MOTOR 3HP, 3 PHASE (G0506X3)
9-1	P0506X009-1	MOTOR FAN (G0506X)
9-1	P0506X3009-1	MOTOR FAN (G0506X3)
9-2	P0506X009-2	FAN COVER (G0506X)
9-2	P0506X3009-2	FAN COVER (G0506X3)
9-3	P0506X009-3	JUNCTION BOX (G0506X)
9-3	P0506X3009-3	JUNCTION BOX (G0506X3)
9-4	P0506X009-4	START CAPACITOR 400MFD-125VAC
9-5	P0506X009-5	RUN CAPACITOR 30MFD, 300VAC
10	PK43M	KEY 8 X 8 X 45
11	P0506011	MOTOR PULLEY
12	PSS08	SET SCREW 5/16-18 X 1/2
13	P0506013	MOTOR FLANGE
14	P0506X014	SPECIAL BOLT 3/8-16 X 1-1/4
15	PN08	HEX NUT 3/8-16
17	PW02	FLAT WASHER 3/8
18	PLW04	LOCK WASHER 3/8
23	PVA37	V-BELT A-37 4L370
24	P0506024	DUST BOARD
25	P0506025	WOOD BOARD
26	PB07	HEX BOLT 5/16-18 X 3/4
27	PW07	FLAT WASHER 5/16
28	PN02	HEX NUT 5/16-18
29	PS06	PHLP HD SCR 10-24 X 3/8
30	P0506030	DUST PORT
31	PS06	PHLP HD SCR 10-24 X 3/8
32	P0506032	BLADE TENSION SCALE
33	PSB41	CAP SCREW 10-24 X 1/2
34	P0506034	WIRE BRACKET
35	PS06	PHLP HD SCR 10-24 X 3/8
36	PB58	HEX BOLT 3/8-16 X 2
37	PN08	HEX NUT 3/8-16
38	P0506X038	MAG SWITCH 3HP-1 PH, 22A (G0506X)
38	P0506X3038	MAG SWITCH 3HP-3 PH, 9A (G0506X3)
38-1	P0506X038-1	MAG SWITCH BACK COVER (G0506X)
38-1	P0506X3038-1	MAG SWITCH BACK COVER (G0506X3)
38-2	P0506X038-2	CONTACTOR (G0506X)
38-2	P0506X3038-2	CONTACTOR (G0506X3)
38-3	P0506X038-3	THERMAL OVERLOAD RELAY (G0506X)
38-3	P0506X3038-3	THERMAL OVERLOAD RELAY (G0506X3)
38-4	P0506X038-4	MAG SWITCH FRONT COVER (G0506X)
38-4	P0506X3038-4	MAG SWITCH FRONT COVER (G0506X3)
38A	P0506X3038A	MAG SWITCH (440V-5A, G0506X3)
38A-1	P0506X3038A-1	MAG SWITCH BACK COVER (G0506X3)

REF	PART #	DESCRIPTION
38A-2	P0506X3038A-2	CONTACTOR (G0506X3)
38A-3	P0506X3038A-3	THERMAL OVERLOAD RELAY (G0506X3)
38A-4	P0506X3038A-4	MAG SWITCH FRONT COVER (G0506X3)
39	P0506039	ON SWITCH (GREEN)
40	P0506040	OFF SWITCH (RED)
41	P0506041	POWER CONTROL PANEL
42	PS06	PHLP HD SCR 10-24 X 3/8
43	P0506043	CONNECTION PLATE
44	P0506044	BRAKE LINING
45	PB18	HEX BOLT 3/8-16 X 1
46	PB19	HEX BOLT 1/4-20 X 1/2
47	P0506047	FOOT BRAKE PEDAL
48	PLW04	LOCK WASHER 3/8
49	PN08	HEX NUT 3/8-16
50	P0506050	HELICAL SPRING 110MM
51	PN08	HEX NUT 3/8-16
52	PB18	HEX BOLT 3/8-16 X 1
53	P0506053	STOP SWITCH
54	PSB22M	CAP SCREW M4-.7 X 35
55	P0506055	UPPER WHEEL
56	P0506056	UPPER WHEEL SHAFT
57	P6205	BALL BEARING 6205ZZ
58	P0506058	IN BUSHING
59	P0506059	OUT BUSHING
60	PR26M	INT RETAINING RING 52MM
61	P0506061	SPECIAL FLAT WASHER 10MM
62	PB07	HEX BOLT 5/16-18 X 3/4
63	P0506063	TIRE
64	P0506064	LOWER WHEEL
65	P0506065	LOWER WHEEL SHAFT
66	P0506066	BRUSH BRACKET*
67	P0506067	BRUSH
68	PB03	HEX BOLT 5/16-18 X 1
69	PW07	FLAT WASHER 5/16
70	PN02	HEX NUT 5/16-18
71	P0506071	SPECIAL WASHER 3/8~2
72	PB21	HEX BOLT 3/8-16 X 3/4
73	PB24	HEX BOLT 3/8-16 X 1-1/4
74	PN08	HEX NUT 3/8-16
75	P0506075	ARBOR BRACKET
76	PB42	HEX BOLT 1/2-12 X 2
77	PN06	HEX NUT 1/2-12
78	P0506078	BLADE TENSION SHAFT
79	P51104	THRUST BEARING 51104
82	P0506082	INDICATOR WIRE PULLER
83	P0506083	HELICAL SPRING 50MM
84	P0506084	BRACKET HOLDER
85	PN06	HEX NUT 1/2-12
86	PW01	FLAT WASHER 1/2
87	P0506087	BRACKET SHAFT
88	PN06	HEX NUT 1/2-12
89	P0506089	TENSION HANDWHEEL

* Part not shown on breakdown drawing



G0506X/G0506X3 Parts List

REF	PART #	DESCRIPTION
90	PSS05	SET SCREW 5/16-18 X 1/4
91	P0506091	TABLE
92	P0506092	FENCE RAIL
93	PB18	HEX BOLT 3/8-16 X 1
94	PW02	FLAT WASHER 3/8
95	P0506095	FENCE
96	P0506096	FENCE KNOB 3/8-16 X 1 1/4
97	P0506097	TRUNNION
98	PSB19	CAP SCREW 3/8-16 X 1-1/4
99	PLW04	LOCK WASHER 3/8
100	PB42	HEX BOLT 1/2-12 X 2
101	PW01	FLAT WASHER 1/2
102	P0506102	TRUNNION BRACKET
103	PB53	HEX BOLT 1/2-12 X 1
104	PLW07	LOCK WASHER 1/2
105	P0506105	BLADE GUIDE FORK
106	PB07	HEX BOLT 5/16-18 X 3/4
107	PW07	FLAT WASHER 5/16
108	P0506108	SHAFT CUP
109	PB03	HEX BOLT 5/16-18 X 1
110	PLW01	LOCK WASHER 5/16
111	P0506111	LOCK KNOB 3/8-16 X 2-1/4
112	P0506112	GUIDE SHAFT
113	PR19M	EXT RETAINING RING 28MM
114	P0506114	ELEVATION GEAR SHAFT
115	P0506115	GEAR SHAFT BASE
116	PB07	HEX BOLT 5/16-18 X 3/4
117	PLW01	LOCK WASHER 5/16
118	P0506118	GUIDE POST HANDWHEEL
119	P0506119	SPRING KEY M4 X 40
120	P0506120	BLADE TRACKING KNOB 3/8-16 X 2-1/2
121	PN08	HEX NUT 3/8-16
122	P0506122	BLADE GUARD
123	P0506123	BLADE GUARD BRACKET
124	PB19	HEX BOLT 1/4-20 X 1/2
125	PLW02	LOCK WASHER 1/4
126	PW06	FLAT WASHER 1/4
127	P0506127	BLADE GUIDE HOLDER
128	PB03	HEX BOLT 5/16-18 X 1
129	PW07	FLAT WASHER 5/16
130	PB07	HEX BOLT 5/16-18 X 3/4
131	P0506131	ADJUSTMENT BRACKET
132	P0506132	BRACKET ARBOR
133	P0506X133	BLADE GUIDE BASE
136	P0506X136	GUIDE BEARING SHAFT

REF	PART #	DESCRIPTION
138	P6202	BALL BEARING 6202ZZ*
139	P0506139	SLIDING BASE*
140	P0506140A	COMPLETE MITER GAUGE
140-1	P0506140	MITER GAUGE BODY
141	P0506141	T-SLOT WASHER 13MM
142	PFH03	FLAT HD SCR 1/4-20 X 1/2
143	P0506143	MITER BAR
144	P0506X144	SPECIAL BOLT 1/4-20 X 5/8
145	P0506145	STOP PIN
146	P0506146	BLOCK
147	P0506147	INDICATOR
148	PS29	PHLP HD SCR 6-32 X 5/8
149	PS06	PHLP HD SCR 10-24 X 3/8
150	P0506150	HANDLE 5/16-18 X 1-1/2
151	PW07	FLAT WASHER 5/16
152	PN12	HEX NUT 6-32
160	G8589	GRIZZLY NAMEPLATE-LARGE
161	PHTEK10M	TAP SCREW M4 X 11
162	P0506X162	G0506X ID LABEL
162	P0506X3162	G0506X3 ID LABEL
163	PLABEL-14	ELECTRICITY LABEL
164	PLABEL-18	UNPLUG BANDSAW LABEL 2" X 3-5/16"H
165	PLABEL-19	HANDS/BS BLADE 2" X 3-5/16"H
166	PLABEL-20	DONT OPEN 2"W X 3-5/16"H
167	PLABEL-12	READ MANUAL 2" X 3-5/16"
168	PLABEL-11	SAFETY GLASSES 2" X 3-5/16"
169	PLABEL-21	BS MOVING/ADJUST 2 X 3-5/16"H
174	P0506174	THRUST BEARING SHAFT
175	P6202RS	BEARING RUBBER SHIELD 6202
176	PEC05M	E-CLIP 15MM
177	P0506177	CABLE CLIP
178	P0506178	CABLE NUT 6-32
179	PS37	PHLP HD SCR 6-32 X 5/16
180	PS06	PHLP HD SCR 10-24 X 3/8
181	P0506181	TERMINAL BLOCK
182	P0506182	STUD 10-24 X 2 1/2
183	PN07	HEX NUT 10-24
184	PW03	FLAT WASHER 10-24
185	PSW10	STRAIN RELIEF 3/4
186	P0506186	TERMINAL BOX
189	P0506189	POWER CORD
190	P0506X190	LIFTING RING 10MM
191	P0506X191	G0506X MODEL NUMBER LABEL
191	P0506X3191	G0506X3 MODEL NUMBER LABEL

* Part not shown on breakdown drawing

WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.

