

We do our best to stock replacement parts when possible, but we cannot guarantee that all parts shown are available for purchase. Call **(800) 523-4777** or visit **www.grizzly.com/parts** to check for availability.

[illegible]


Stand Parts List

REF	PART #	DESCRIPTION
1	P0634Z001	FRAME (G0634Z)
1	P0634XP001	FRAME (G0634XP)
1-1	P0634Z001-1	HINGE SHAFT BRACKET RIGHT (G0634Z)
1-1	P0634XP001-1	HINGE SHAFT BRACKET RIGHT (G0634XP)
1-2	P0634Z001-2	HINGE SHAFT BRACKET LEFT (G0634Z)
1-2	P0634XP001-2	HINGE SHAFT BRACKET LEFT (G0634XP)
2	P0634Z002	DRIVE SHAFT COVER (G0634Z)
2	P0634XP002	DRIVE SHAFT COVER (G0634XP)
3	P0634Z003	COVER FRAME
3-1	P0634Z003-1	COVER (G0634Z)
3-1	P0634XP003-1	COVER (G0634XP)
4	P0634Z004	DOOR (G0634Z)
4	P0634XP004	DOOR (G0634XP)
5	P0634Z005	SIDE OPENING COVER (G0634Z)
5	P0634XP005	SIDE OPENING COVER (G0634XP)
5-1	P0634Z005-1	HEX BOLT 5/16-18 X 1/2
5-2	P0634Z005-2	FLAT WASHER 5/16
6	P0634Z006	CARRIAGE BOLT 3/8-16 X 1
6-1	P0634Z006-1	PLATE SCREW 3/8-16 X 2
7	P0634Z007	FLAT WASHER 3/8
8	P0634Z008	HEX NUT 3/8-16
9	P0634Z009	MOTOR BRACKET
10	P0634Z010	PLANNER SCALE
12	P0634Z012	REINFORCEMENT PLATE
12-1	P0634Z012-1	HEX BOLT 5/16-18 X 5/8
12-2	P0634Z012-2	FLAT WASHER 5/16
12-3	P0634Z012-3	HEX NUT 5/16-18
12-4	P0634Z012-4	HEX BOLT 5/16-18 X 2-3/4
13	P0634Z013	SQUARE SUPPORT
13-1	P0634Z013-1	HEX BOLT 5/16-18 X 1/2
13-2	P0634Z013-2	TAP SCREW 1/4 X 1
13-3	P0634Z013-3	FLAT WASHER 1/4
14	P0634Z014	SWITCH BOX W/O SWITCH
14-1	P0634Z014-1	SWITCH KNOB
15	P0634Z015	EMERGENCY STOP SWITCH CORD
16	P0634Z016	KNOB BOLT 3/8-16

REF	PART #	DESCRIPTION
17	P0634Z017	STRAIN RELIEF TYPE-3 M22-1.5
18	P0634Z018	POWER CORD
19	P0634Z019	DEPTH SCALE
20	P0634Z020	LIMIT SWITCH CORD
21	P0634Z021	CAP SCREW 3/8-16 X 1
21-1	P0634Z021-1	CAP SCREW 3/8-16 X 1-1/2
22	P0634Z022	HEX BOLT 1/4-20 X 5/8
23	P0634Z023	FLAT WASHER 1/4
24	P0634Z024	GROMMET
25	P0634Z025	GROMMET
26	P0634Z026	STRAIN RELIEF TYPE-3 M22-1.5
27	P0634Z027	FLAT WASHER 1/4
28	P0634Z028	HEX BOLT 1/4-20 X 3/8
29	P0634Z029	MAGNETIC SWITCH ASSY SDE MP-18
29-1	P0634Z029-1	MAG SWITCH FRONT COVER
29-2	P0634Z029-2	MAG SWITCH BACK COVER
29-3	P0634Z029-3	CONTACTOR SDE MA-18 220V
29-4	P0634Z029-4	OL RELAY SDE RA-30 18-26A
29-5	P0634Z029-5	ON BUTTON
29-6	P0634Z029-6	OFF BUTTON
30	P0634Z030	PHLP HD SCR 10-24 X 5/8
31	P0634Z031	STRAIN RELIEF TYPE-3 M16-1.5
32	P0634Z032	PHLP HD SCR 1/4-20 X 5/16
34	P0634Z034	HEX NUT 1/4-20
35	P0634Z035	POINTER
35-1	P0634Z035-1	PHLP HD SCR 10-24 X 1/4
36	P0634Z036	PROTECTION PLATE (LEFT)
37	P0634Z037	PROTECTION PLATE (RIGHT)
39	P0634Z039	TAP SCREW #5 X 3/8
40	P0634Z040	WRENCH 12 X 14MM OPEN-ENDS
42	P0634Z042	HEX WRENCH 3MM
43	P0634Z043	COVER SCREW 5/16-18 X 1-1/2
44	P0634XP044	HEX WRENCH 3/32 (G0634XP)
49	P0634Z049	KNOB 1/4-20 X 1/2
51	P0634Z051	CABLE CLAMP
52	P0634Z052	HEX NUT 10-24



Jointer Table




REF	PART #	DESCRIPTION
101V3	P0634Z101V3	INFEED TABLE V3.09.18 (G0634Z)
101V2	P0634XP101V2	INFEED TABLE V2.09.18 (G0634XP)
102	P0634Z102	OUTFEED TABLE (G0634Z)
102	P0634XP102	OUTFEED TABLE (G0634XP)
103	P0634Z103	TABLE LIP
104-2	P0634Z104-2	JOINTER DUST PORT 4" (G0634Z)
104-2	P0634XP104-2	JOINTER DUST PORT 4" (G0634XP)
105	P0634Z105	HINGE SHAFT A
106	P0634Z106	HINGE SHAFT B
107	P0634Z107	OUTFEED TABLE ADJ. KNOB
108	P0634Z108	GUIDE SCREW
109	P0634Z109	HEX NUT 1/2-12
110	P0634Z110	INFEED HANDGRIP
111	P0634Z111	INFEED LOCK LEVER
112	P0634Z112	OUTFEED LOCK LEVER
113	P0634Z113	PLASTIC KNOB
114	P0634Z114	EXT RETAINING RING 12MM
117	P0634Z117	HEX BOLT 5/16-18 X 3/4
118V2	P0634Z118V2	KNOB SCREW 5/16-18 X 3/4 V2.11.16
119	P0634Z119	PHLP HD SCR 10-24 X 1/4
120	P0634Z120	FLAT WASHER 5/16
121	P0634Z121	CAP SCREW 5/16-18 X 3/4
124	P0634Z124	CAP SCREW 3/8-16 X 1-1/4

125	P0634Z125	HEX NUT 5/16-18
126	P0634Z126	CAP SCREW 1/4-20 X 1/2
128	P0634Z128	CAP SCREW 5/16-18 X 3/8
129	P0634Z129	HANDLE
130	P0634Z130	HOLLOW STUD 1/2-12 X 1-9/16, 5/16 ID
131	P0634Z131	PLUNGER
132	P0634Z132	COMPRESSION SPRING
133	P0634Z133	KNOB
134	P0634Z134	PUSH BLOCK-SMALL (PAIR)
135-4	P0634Z135-4	JOINTER DUST PORT L-BRACKET (G0634Z)
135-4	P0634XP135-4	JOINTER DUST PORT L-BRACKET (G0634XP)
135-5	P0634Z135-5	JOINTER DUST PORT PLATE (G0634Z)
135-5	P0634XP135-5	JOINTER DUST PORT PLATE (G0634XP)
135-8	P0634Z135-8	JOINTER DUST PORT PLATE (PLASTIC)
136	P0634Z136	PHLP HD SCR 10-24 X 1/2
137	P0634Z137	HEX NUT 10-24
701	P0634Z701	CUTTERHEAD GUARD
702	P0634Z702	ROLL PIN 6 X 36
703	P0634Z703	GUARD TORSION PIN
704	P0634Z704	ROLL PIN 5 X 30
705	P0634Z705	TORSION SPRING
707	P0634Z707	EXT RETAINING RING 11MM
710	P0634Z710	WAVY WASHER 12MM



Cutterhead & Motor




REF	PART #	DESCRIPTION
200	P0634Z200	CUTTERHEAD MOUNTING BLOCK
201V2	P0634Z201V2	SPIRAL CUTTERHEAD 12" 10-32 V2.09.09
201-1	P0634Z201-1	INDEXABLE INSERTS 15 X 15 X 2.5 (10 PK)
201-2	P0634XP201-2	T-HEAD TORX T25 10-32 X 1/2
201-2V2	P0634Z201-2V2	T-HEAD TORX T25 10-32 X 1/2 V2.01.11
201-3	P0634Z201-3	T-HANDLE TORX DRIVER 1/4
201-4	P0634Z201-4	TORX BIT T-25
204-1A	P0634Z204-1A	PLANER DUST PORT 4" V2.09.07 (G0634Z)
204-1A	P0634XP204-1A	PLANER DUST PORT 4" (G0634XP)
206V2	P0634Z206V2	OUTFEED ROLLER V2.01.20
207	P0634Z207	INFEED ROLLER
208V2	P0634Z208V2	COVER V2.04.16 (G0634Z)
208V2	P0634XP208V2	COVER V2.04.16 (G0634XP)
209	P0634Z209	ALIGNMENT PIN
210	P0634Z210	PIVOT PIN
211	P0634Z211	SQUARE SUPPORT
212	P0634Z212	DOWEL
213	P0634Z213	COMPRESSION SPRING
214	P0634Z214	KEY 5 X 5 X 30
215	P0634Z215	DUST CHUTE (G0634Z)
215	P0634XP215	DUST CHUTE (G0634XP)
215-6	P0634Z215-6	PLANER DUST PORT L-BRACKET (G0634Z)
215-6	P0634XP215-6	PLANER DUST PORT L-BRACKET (G0634XP)
215-7	P0634Z215-7	PLANER DUST PORT PLATE (G0634Z)
215-7	P0634XP215-7	PLANER DUST PORT PLATE (G0634XP)
215-9	P0634Z215-9	PLANER DUST PORT PLATE (PLASTIC)
216	P0634Z216	MOTOR PULLEY
217V2	P0634Z217V2	CUTTERHEAD PULLEY V2.01.08 (G0634Z)
217	P0634XP217	CUTTERHEAD PULLEY (G0634XP)
218	P0634Z218	ROLLER SUPPORT BLOCK

REF	PART #	DESCRIPTION
219	P0634Z219	ANTI KICKBACK FINGER
220	P0634Z220	SPACER
221	P0634Z221	SET SCREW 1/4-20 X 1/2
222	P0634Z222	INT RETAINING RING 52MM
224	P0634Z224	BALL BEARING 6205-2RS
225	P0634Z225	GUARD (G0634Z)
225	P0634XP225	GUARD (G0634XP)
226	P0634Z226	FLAT WASHER 1/4
227	P0634Z227	HEX BOLT 1/4-20 X 3/8
228	P0634XP228	SET SCREW M5-.8 X 4 (G0634XP)
228V2	P0634Z228V2	SET SCREW M5-.8 X 4 V2.01.08 (G0634Z)
229V2	P0634Z229V2	SET SCREW 1/4-20 X 3/4 CONE-PT V2.04.16
230	P0634Z230	MOTOR 5HP 220V 1-PH
230-1	P0634Z230-1	JUNCTION BOX
230-2	P0634Z230-2	FAN COVER
230-3	P0634Z230-3	MOTOR FAN
230-4	P0634Z230-4	CAPACITOR COVER
230-5	P0634Z230-5	S CAPACITOR 400M 125V 1-3/8 X 3-1/8
230-6	P0634Z230-6	R CAPACITOR 50M 350V 2 X 3-1/2
231	P0634Z231	MOTOR CORD
232	P0634Z232	PIVOT PIN
233	P0634Z233	V-BELT M52 3L520
234	P0634Z234	CAP SCREW 5/16-18 X 3-1/4
235	P0634Z235	SET SCREW 1/4-20 X 3/8
236	P0634Z236	PHLP HD SCR 10-24 X 3/8
237	P0634Z237	FLAT WASHER #10
239	P0634Z239	SET SCREW M5-.8 X 6
243	P0634Z243	FLANGE SCREW 10-24 X 1/2
244	P0634Z244	HEX NUT 10-24



Drive Assembly




REF	PART #	DESCRIPTION
301	P0634Z301	SPROCKET 66T
302	P0634Z302	SPROCKET 34T
303	P0634Z303	BUSHING
304	P0634Z304	SPROCKET 18T
305	P0634Z305	SPACER
306	P0634Z306	ARM
307	P0634Z307	BALL BEARING 6204-2RS
308	P0634Z308	TENSION SPRING
309	P0634Z309	BALL BEARING 608-2RS
310	P0634Z310	ROLLER CHAIN
311	P0634Z311	ROLLER CHAIN
312	P0634Z312	CONTACT WHEEL
313	P0634Z313	LEVER
314	P0634Z314	TENSION SPRING
315	P0634Z315	CAM
316	P0634Z316	CAM SHAFT
317	P0634Z317	ROLL PIN
318V2	P0634Z318V2	SPACER 8 X 15 X 8MM V2.03.15
319V2	P0634Z319V2	SPROCKET 19T, 17 X 32.5 X 17MM V2.10.14
320	P0634Z320	INT RETAINING RING 22MM
321	P0634Z321	SPRING STUD

REF	PART #	DESCRIPTION
322	P0634Z322	FLAT WASHER 3/8
323	P0634Z323	CAP SCREW 3/8-16 X 1/2
324	P0634Z324	LEVER
325	P0634Z325	SET SCREW 5/16-18 X 3/8
326	P0634Z326	SET SCREW 1/4-20 X 1
327	P0634Z327	HEX NUT 1/4-20
328	P0634Z328	CAP SCREW 5/16-18 X 2
329	P0634Z329	FLAT WASHER 5/16
330	P0634Z330	HEX NUT 5/16-18
331	P0634Z331	FLAT WASHER 1/2
332	P0634Z332	HEX NUT 1/2-20
333	P0634Z333	BUSHING
334	P0634Z334	CAP SCREW 1/4-20 X 3/4
335	P0634Z335	CAP SCREW 1/4-20 X 3/8
336	P0634Z336	CAP SCREW 5/16-18 X 3/4
337	P0634Z337	LOCK NUT 3/8-16
338	P0634Z338	CAP SCREW 5/16-18 X 2-1/2
339	P0634Z339	LOCK WASHER 5/16
340	P0634Z340	PLASTIC KNOB
341	P0634Z341	SPACER 8.6 X 15 X 18.6MM



Planer Table




REF	PART #	DESCRIPTION
401	P0634Z401	PLANER TABLE
402	P0634Z402	COLUMN
403	P0634Z403	CYLINDER LINER
404	P0634Z404	LOCK SCREW
405	P0634Z405	COLLAR
406	P0634Z406	THICKNESS POINTER
407	P0634Z407	GEAR BOX
408	P0634Z408	BUSHING
408-1	P0634Z408-1	SELF-LUBRICATING SHLDR BUSHING
408-2	P0634Z408-2	SELF-LUBRICATION BUSHING
409	P0634Z409	GEAR
410	P0634Z410	WORM SHAFT
411	P0634Z411	ELEVATION LEAD SCREW
412	P0634Z412	SHIELD PLATE
413	P0634Z413	HANDWHEEL
414	P0634Z414	HEX NUT 5/16-18
415	P0634Z415	UNIVERSAL LOCK LEVER
417	P0634Z417	ROLL PIN
418	P0634Z418	THRUST BEARING NTB1528 +2AS
419	P0634Z419	INT RETAINING RING 19MM

REF	PART #	DESCRIPTION
420	P0634Z420	BUSHING
421	P0634Z421	FLAT WASHER 5/16
422	P0634Z422	LOCK NUT 5/16-18
423	P0634Z423	LOCK WASHER 1/4
424	P0634Z424	CAP SCREW 1/4-20 X 2-1/4
425	P0634Z425	INT RETAINING RING 8MM
426	P0634Z426	ROLL PIN 5 X 30
427	P0634Z427	SET SCREW 5/16-18 X 1/4
428	P0634Z428	FENDER WASHER 13.5 X 34 X 4MM
429	P0634Z429	LOCK WASHER 3/8
430	P0634Z430	HEX BOLT 3/8-16 X 1-1/2
431	P0634Z431	SET SCREW 5/16-18 X 1
432	P0634Z432	CAP SCREW 3/8-16 X 1-1/4
433	P0634Z433	HEX BOLT 5/16-18 X 1/2
434	P0634Z434	HEX NUT 3/8-16
435	P0634Z435	SET SCREW 3/8-16 X 2
436	P0634Z436	PHLP HD SCR 5/16-18 X 3/4
437	P0634Z437	HANDLE
438	P0634Z438	SHOULDER SCREW 3/8-16 X 5/8, 3/8 X 2-1/2



Limit Switch




REF	PART #	DESCRIPTION
501-1	P0634Z501-1	SWING LEVER (F)
501-2	P0634Z501-2	SWING LEVER (M)
501-3	P0634Z501-3	LIMIT SWITCH BRACKET
502	P0634Z502	COMPRESSION SPRING
503	P0634Z503	EXTENSION SPRING
504	P0634Z504	SWITCH ACTIVATION ROD #1
505	P0634Z505	SWITCH ACTIVATION ROD #2
506	P0634Z506	SWITCH ACTIVATION ROD #3
507	P0634Z507	LOCK NUT 5/16-18

REF	PART #	DESCRIPTION
508	P0634Z508	FLAT WASHER 5/16
509	P0634Z509	HEX BOLT 5/16-18 X 1
510	P0634Z510	HEX BOLT 5/16-18 X 1/2
511	P0634Z511	HEX NUT 5/16-18
512	P0634Z512	CAP SCREW 10-24 X 1-1/4
513	P0634Z513	CAP SCREW 1/4-20 X 1
514	P0634Z514	LIMIT SWITCH
515	P0634Z515	LIMIT SWITCH CONTROL CORD



Fence (G0634Z)




Fence Parts List (G0634Z)

REF	PART #	DESCRIPTION
601	P0634Z601	FENCE BASE
602V2	P0634Z602V2	ADJUSTMENT TUBE W/RACK V2.08.16
603	P0634Z603	TRUNNION BRACKET
604	P0634Z604	TRUNNION
604-1	P0634Z604-1	FENCE ANGLE SCALE
605	P0634Z605	PIVOT STUD
606	P0634Z606	SPACER
607	P0634Z607	ADJUSTMENT SCREW
608	P0634Z608	ADJUSTMENT ROD
609	P0634Z609	FENCE
610	P0634Z610	SLIDING BOLT
611	P0634Z611	ECCENTRIC SHAFT
612	P0634Z612	LOCK KNOB 3/8-16
613	P0634Z613	PINION SHAFT
614	P0634Z614	FENCE SUPPORT
615	P0634Z615	PLASTIC PROTECTION SHOE
616	P0634Z616	BUSHING
617	P0634Z617	HEX BOLT 5/16-18 X 1
619	P0634Z619	LOCK NUT 5/16-18
620	P0634Z620	FLAT WASHER 5/16
621V2	P0634Z621V2	CUTTER KNIFE GUARD V2.06.18
622	P0634Z622	DOVETAIL BRACKET FOR QUICK RELEASE
623	P0634Z623	FLAT WASHER 1/4
624	P0634Z624	FLAT HD SCR 1/4-20 X 3/8

REF	PART #	DESCRIPTION
625	P0634Z625	TUBE LOCKING SHOE
626	P0634Z626	UNIVERSAL LOCK LEVER
627	P0634Z627	UNIVERSAL LOCK LEVER
628	P0634Z628	POINTER
629	P0634Z629	FLAT WASHER 1/4
630	P0634Z630	PHLP HD SCR 1/4-20 X 3/8
631	P0634Z631	SET SCREW 1/4-20 X 3/8
632	P0634Z632	PHLP HD SCR 10-24 X 5/8
633	P0634Z633	HEX BOLT 5/16-18 X 1-1/4
634	P0634Z634	SET SCREW 5/16-18 X 1
635	P0634Z635	HEX NUT 5/16-18
636	P0634Z636	CONTROL KNOB
636-1	P0634Z636-1	EXT RETAINING RING 10MM
637	P0634Z637	HEX BOLT 1/4-20 X 3/4
638	P0634Z638	HEX NUT 1/4-20
639	P0634Z639	HEX BOLT 1/4-20 X 3-1/4
640	P0634Z640	SET SCREW 1/4-20 X 1/4
641	P0634Z641	KNOB SCREW 1/4
642	P0634Z642	HEX BOLT 1/4-20 X 1/2
643	P0634Z643	CAP SCREW 1/4-20 X 1
644	P0634Z644	FLAT WASHER 1/4
645	P0634Z645	FLAT WASHER 1/4 (PLASTIC)
646	P0634Z646	SET SCREW 10-24 X 1/4
647	P0634Z647	FENCE BASE PLATE



Fence (G0634XP)





REF	PART #	DESCRIPTION
600	P0634XP600	COMPLETE FENCE ASSEMBLY
601	P0634XP601	FENCE
602	P0634XP602	FENCE FIXED PLATE
603	P0634XP603	LEFT FENCE CAP
604	P0634XP604	RIGHT FENCE CAP
605	P0634XP605	TAP SCREW #10 X 1/2
606	P0634XP606	REAR GUARD HINGE
607	P0634XP607	PHLP HD SCR M4-.7 X 6
608	P0634XP608	REAR GUARD CONNECTOR
608-1	P0634XP608-1	REAR GUARD LINK
609	P0634XP609	FENCE ANGLE SCALE
610	P0634XP610	FENCE LOCK LEVER
610-1	P0634XP610-1	COMPRESSION SPRING
610-2	P0634XP610-2	PHLP SHOULDER SCR M5-.8 X 15
611	P0634XP611	FENCE LOCK LEVER SCREW
612	P0634XP612	FLAT WASHER 3/8
613	P0634XP613	LOCK NUT 3/8-16
614	P0634XP614	FLAT WASHER 3/8
615	P0634XP615	ANGLE ADJUSTMENT KNOB 3/8
616	P0634XP616	HEX NUT 5/16-18
617	P0634XP617	SET SCREW 5/16-18 X 1
618	P0634XP618	FLAT WASHER 5/16

REF	PART #	DESCRIPTION
619	P0634XP619	FENCE ANGLE SUPPORT
620	P0634XP620	CAP SCREW 5/16-18 X 1
621	P0634XP621	STUD-UDE 3/8-16 X 2-1/2 1/2, 3/4 RH
623	P0634XP623	HEX NUT 1/4-20
624	P0634XP624	SET SCREW 1/4-20 X 5/8
625	P0634XP625	FENCE SUPPORT
626	P0634XP626	FENCE SUPPORT PLATE
627	P0634XP627	FLAT HD SCR 10-24 X 3/8
631V2	P0634XP631V2	FENCE RAIL W/HOLES V2.04.11
632	P0634XP632	CAP SCREW 3/8-16 X 2-1/4
633	P0634XP633	BUSHING
634	P0634XP634	LOCK WASHER 3/8
635	P0634XP635	HEX NUT 3/8-16
636	P0634XP636	FENCE RAIL END CAP
639	P0634XP639	FIXED PLATE
640	P0634XP640	PLASTIC PROTECTION SHOE
641	P0634XP641	SET SCREW 10-24 X 1/4
642	P0634XP642	FENCE RAIL BRACE
643	P0634XP643	HEX BOLT 3/8-16 X 1-1/2
644	P0634XP644	FLAT WASHER 1/4
645	P0634XP645	HEX BOLT 1/4-20 X 1/2



Labels & Cosmetics



REF	PART #	DESCRIPTION
800	P0634Z800	READ MANUAL LABEL
801	P0634Z801	RESPIRATOR/GLASSES LABEL
802	P0634Z802	MACHINE ID LABEL (G0634Z)
802	P0634XP802	MACHINE ID LABEL (G0634XP)
803	P0634Z803	CUTTERHEAD WARNING LABEL
804	P0634Z804	EAR PROTECTION LABEL
805	P0634Z805	DISCONNECT POWER LABEL
806	P0634Z806	CHANGING OPERATIONS WARNING LABEL
807	P0634Z807	TOUCH UP PAINT, GRIZZLY GREEN
808	P0634Z808	TOUCH UP PAINT, GREY PUTTY (G0634Z)

REF	PART #	DESCRIPTION
808	P0634XP808	TOUCH-UP PAINT, PB WHITE (G0634XP)
809	P0634Z809	ELECTRICITY LABEL
810	P0634Z810	MODEL NUMBER LABEL (G0634Z)
810	P0634XP810	MODEL NUMBER LABEL (G0634XP)
811	P0634Z811	TABLE LOCK KNOB NOTICE (G0634Z)
811	P0634XP811	POLAR BEAR LOGO 2-1/2 X 9-1/2 (G0634XP)
812	P0634Z812	CHANGE LEVER LABEL
813	P0634Z813	GRIZZLY NAMEPLATE-SMALL
814	P0634XP814	TABLE LOCK KNOB NOTICE (G0634XP)

⚠ WARNING

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this machine **MUST** replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or www.grizzly.com.

