

Main Parts List

| REF | PART # | DESCRIPTION |
|------|------------|---------------------------------------|
| 1 | P0965001 | MACHINE BODY |
| 2 | P0965002 | CASTER 3" SWIVEL |
| 3 | P0965003 | CASTER 3" LOCKING |
| 4 | P0965004 | FLAT WASHER 5/16 |
| 5 | P0965005 | HEX BOLT 5/16-18 X 3/4 |
| 6 | P0965006 | LOCK WASHER 5/16 |
| 7 | P0965007 | HOSE FITTING 3/4 PT STRAIGHT BARBED |
| 8 | P0965008 | HOSE CLAMP 3/4" |
| 9 | P0965009 | HOSE 3/4" X 16" |
| 10 | P0965010 | U-BOLT 3/8-16 X 1, 1-1/8 |
| 11 | P0965011 | CAP 3/4 PT |
| 12 | P0965012 | PIPE 3/4 PT X 8-5/16 PERFORATED |
| 13 | P0965013 | T-FITTING 3/4 PT |
| 14 | P0965014 | FLANGE NUT 3/8-16 |
| 15 | P0965015 | COVER PLATE |
| 16 | P0965016 | TAP SCREW #8 X 1/2 |
| 17 | P0965017 | LATCH |
| 18 | P0965018 | AIR TANK |
| 19 | P0965019 | HEX NUT 5/16-18 |
| 20 | P0965020 | SAFETY RELIEF VALVE |
| 21 | P0965021 | HOSE FITTING 1/4 PT STRAIGHT BARBED |
| 22 | P0965022 | HOSE CLAMP 1/4" |
| 23 | P0965023 | HOSE 1/4" X 18" |
| 24 | P0965024 | HIGH-FLOW PULSE VALVE |
| 25 | P0965025 | PIPE 3/4 PT X 4-11/16" |
| 26 | P0965026 | CONNECTOR 3/4 PT STRAIGHT |
| 27 | P0965027 | HOSE 1/4" X 21-11/16 |
| 28 | P0965028 | T-FITTING 1/4 PT |
| 29 | P0965029 | HOSE 1/4" X 8-11/16" |
| 30 | P0965030 | HOSE FITTING 1/4 NPT (MALE) |
| 31 | P0965031 | BALL DRAIN VALVE 1/4 PT |
| 32 | P0965032 | ELBOW FITTING 1/4 PT 90 DEG BARBED |
| 33 | P0965033 | ELBOW FITTING 1/4 PT X 1/4 NPT |
| 34 | P0965034 | HOSE FITTING 1/4 NPT (FEMALE) |
| 35 | P0965035 | COMPRESSION FITTING 1/4PT X 8MM |
| 36 | P0965036 | CONTROL VALVE SHAKO MSV9832-02PBB |
| 37 | P0965037 | FITTING 1/4 PT X 5/16" |
| 38 | P0965038 | MUFFLER 1/4 PT |
| 39 | P0965039 | CAP SCREW M5-.8 X 12 |
| 40 | P0965040 | LATCH BASE |
| 41 | P0965041 | FENDER WASHER 1/4 |
| 42 | P0965042 | HEX BOLT 1/4-20 X 3/4 |
| 43 | P0965043 | FILTER ALUMINUM MESH 630 X 285 X 22MM |
| 44 | P0965044 | AUX POWER CONTROL BOX ASSEMBLY |
| 44-1 | P0965044-1 | ON/OFF SWITCH JI-HONG J9301A 20A/125V |
| 44-2 | P0965044-2 | CIRCUIT BREAKER ZE-700S-7 250VAC 7A |
| 44-3 | P0965044-3 | RECEPTACLE 5-15 125V 15A |
| 44-4 | P0965044-4 | TAP SCREW 5/32 X 1 |
| 44-5 | P0965044-5 | CONTROL BOX COVER |
| 44-6 | P0965044-6 | CONTROL BOX HOUSING |
| 45 | P0965045 | PHLP HD SCR 10-24 X 5/8 |
| 46 | P0965046 | PIVOT FRAME (LEFT) |
| 47 | P0965047 | PIVOT FRAME (RIGHT) |
| 48 | P0965048 | LATCH PLATE |
| 49 | P0965049 | KNOB BOLT 5/16-18 X 1, 5-LOBE, D20 |
| 50 | P0965050 | CANISTER FILTER |
| 51 | P0965051 | MAINTENANCE DOOR |
| 52 | P0965052 | HINGE |
| 53 | P0965053 | FLANGE NUT M5-.8 |

| REF | PART # | DESCRIPTION |
|-------|-------------|---|
| 54 | P0965054 | COMPRESSION LATCH ASSEMBY |
| 55 | P0965055 | FLAT HD CAP SCR M5-.8 X 14 |
| 56 | P0965056 | PRESSURE GAUGE 0-10"/H2O |
| 57 | P0965057 | HOSE 5 X 8 X 1500MM |
| 58 | P0965058 | MAGNETIC SWITCH 230V NHD MS1-09D3H7N83P |
| 58-1 | P0965058-1 | CONTACTOR NHD C-09D10H7 230V |
| 58-2 | P0965058-2 | OL RELAY NHD NTH-8 3PE 6-8A |
| 58-3 | P0965058-3 | MAGNETIC SWITCH COVER |
| 58-4 | P0965058-4 | AUX. CONTACTOR NHD 1P 1A 600V |
| 58X | P0965058X | MAGNETIC SWITCH 460V NHD MS1-09D3S7N43P |
| 58X-1 | P0965058X-1 | CONTACTOR NHD C-09D10S7 460V |
| 58X-2 | P0965058X-2 | OL RELAY NHD NTH-4 3PE 2.9-4A |
| 58X-3 | P0965058X-3 | MAGNETIC SWITCH COVER |
| 58X-4 | P0965058X-4 | AUX. CONTACTOR NHD 1P 1A 600V |
| 59 | P0965059 | POWER CORD 14G 4W 118" |
| 60 | P0965060 | MOTOR CORD 14G 4W 59" |
| 61 | P0965061 | DUST DRAWER |
| 62 | P0965062 | DRAWER HANDLE |
| 63 | P0965063 | DUST TRAY |
| 64 | P0965064 | WAVE INSERT |
| 65 | P0965065 | HEX BOLT 5/16-18 X 1 |
| 66 | P0965066 | FLAT WASHER 8 X 30 X 2MM |
| 67 | P0965067 | IMPELLER 12-1/8" |
| 68 | P0965068 | MOTOR BRACKET |
| 69 | P0965069 | MOTOR 2HP 230V/460V 3PH |
| 69-1 | P0965069-1 | MOTOR FAN COVER |
| 69-2 | P0965069-2 | MOTOR FAN |
| 69-3 | P0965069-3 | JUNCTION BOX |
| 69-4 | P0965069-4 | BALL BEARING 6305ZZ |
| 70 | P0965070 | HEX BOLT 5/16-18 X 1-1/2 |
| 71 | P0965071 | LOCK NUT 5/16-18 |
| 72 | P0965072 | HEPA FILTER 457 X 508 X 150MM |
| 73 | P0965073 | FILTER CAGE |
| 74 | P0965074 | KNOB BOLT 1/4-20 X 3/4, 6-LOBE, D35 |
| 75 | P0965075 | TABLE GRATE W/HOLES (LEFT) |
| 76 | P0965076 | TABLE GRATE W/HOLES (RIGHT) |
| 77 | P0965077 | SIDE DOOR (LEFT) |
| 78 | P0965078 | SIDE DOOR (RIGHT) |
| 79 | P0965079 | BACK WALL |
| 80 | P0965080 | HINGE |
| 81 | P0965081 | STRIKE PLATE SIDE DOOR |
| 82 | P0965082 | TOP COVER |
| 83 | P0965083 | WORK LIGHT ASSEMBLY GOLDEN GWDE120 |
| 84 | P0965084 | WORK LIGHT CLAMP |
| 85 | P0965085 | ADJUSTABLE FOOT M16-2 X 150 |
| 86 | P0965086 | HEX NUT M16-2 |
| 87 | P0965087 | TABLE PANEL GASKET |
| 88 | P0965088 | MAINTENANCE DOOR GASKET |
| 89 | P0965089 | TABLE PANEL W/HOLES |
| 90 | P0965090 | HANDLE |
| 91 | P0965091 | HEX NUT 10-24 |
| 92 | P0965092 | L-HANDLE SPRING PLUNGER |
| 93 | P0965093 | ACORN NUT 5/16-18 |
| 94 | P0965094 | FENDER WASHER 5/16 |
| 96 | P0965096 | PIPE 3/4 PT X 1-3/16" |
| 97 | P0965097 | SPACER |
| 98 | P0965098 | THUMB SCREW M6-1 X 30 |
| 99 | P0965099 | STRAIN RELIEF TYPE-3 PG13.5 |



Labels & Cosmetics (Front)





| REF | PART # | DESCRIPTION |
|-----|----------|---------------------|
| 101 | P0965101 | MODEL NUMBER LABEL |
| 102 | P0965102 | ELECTRICITY LABEL |
| 103 | P0965103 | AIR PULSE LABEL |
| 104 | P0965104 | COMBO WARNING LABEL |
| 105 | P0965105 | MACHINE ID LABEL |

| REF | PART # | DESCRIPTION |
|-----|----------|----------------------|
| 106 | P0965106 | GRIZZLY LOGO PLATE |
| 107 | P0965107 | CLOSE DOOR LABEL |
| 108 | P0965108 | EXTREME SERIES LABEL |
| 109 | P0965109 | MAX LOAD LABEL |



Labels & Cosmetic (Rear)



| REF | PART # | DESCRIPTION |
|-----|----------|--------------------------|
| 201 | P0965201 | ROTATION DIRECTION LABEL |
| 202 | P0965202 | AMPUTATION HAZARD LABEL |

| REF | PART # | DESCRIPTION |
|-----|----------|-------------------|
| 203 | P0965203 | ELECTRICITY LABEL |
| 204 | P0965204 | 230 VOLT LABEL |

!WARNING

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this machine **MUST** replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or www.grizzly.com.

