


SECTION 9: PARTS

We do our best to stock replacement parts when possible, but we cannot guarantee that all parts shown are available for purchase. Call **(800) 523-4777** or visit **www.grizzly.com/parts** to check for availability.

Controls




Controls Parts List

REF	PART #	DESCRIPTION
1	P0969001	BODY
3	P0969003	COVER
4	P0969004	BUTTON HD CAP SCR 10-32 X 1/4
5	P0969005	SWITCH COVER
6	P0969006	ON/OFF SWITCH KINGCRAFT CS00-10601
7	P0969007	FLAT WASHER 5MM
12	P0969012	AIR NOZZLE
18	P0969018	HEX BOLT 1/4-20 X 1/2
19	P0969019	TENSION PLATE
20	P0969020	HOLD-DOWN MOUNT PLATE
21	P0969021	BUTTON HD CAP SCR 10-32 X 3/8
22	P0969022	KNOB 1/4-20, D25, WING
23	P0969023	FLAT WASHER 1/4
24	P0969024	HOLD-DOWN CLAMP BOLT 1/4-20
25	P0969025	HOLD-DOWN BAR
26	P0969026	CAP SCREW 10-32 X 1/2
27	P0969027	HOLD-DOWN SHOE
28	P0969028	AIR NOZZLE MOUNT
29	P0969029	TAP SCREW #8 X 3/8
30	P0969030	VARIABLE SPEED KNOB
31V2	P0969031V2	POTENTIOMETER W/CORD V2.05.25
32V2	P0969032V2	CORD 24G 3W V2.05.25 42"
33	P0969033	TAP SCREW M3-.5 X 8
35	P0969035	BUTTON HD CAP SCR 1/4-20 X 1/2
37	P0969037	SOCKET 5-15 RF-2004-3.0-6.3A
38	P0969038	FUSE 3.15A 250V 20X5MM FAST-ACTING
40	P0969040	GEAR COVER
41	P0969041	HEX NUT 3/8-16
45	P0969045	BUTTON HD CAP SCR 10-32 X 2-1/4
46	P0969046	SET SCR 3/8-16 X 5/8 SLOTTED
47	P0969047	EXT TOOTH WASHER #8
48	P0969048	PHLP HD SCR 8-32 X 1/4

REF	PART #	DESCRIPTION
51	P0969051	LOCK NUT 10-24
52	P0969052	LOCK NUT 1/4-20
53	P0969053	LOCK WASHER 1/4
54	P0969054	FLAT WASHER 1/4
56	P0969056	HEX BOLT 1/4-20 X 2-1/2
57	P0969057	UPPER ARM
58	P0969058	KNOB M8-1.25, D50, ROUND KD
59	P0969059	HEX NUT M8-1.25
60	P0969060	STUD M8-1.25 X 70
61V2	P0969061V2	CONTROL BOX V2.05.25
62	P0969062	CROSS BLOCK RETAINER
63	P0969063	HOUSING CROSS BLOCK
64	P0969064	FLAT WASHER 6 X 16 X 2MM
65	P0969065	LOCK NUT M6-1
66	P0969066	BUTTON HD CAP SCR 10-32 X 1/2
67	P0969067	CORD CLAMP
68	P0969068	FLAT WASHER #10
69	P0969069	LOCK NUT 10-32
70	P0969070	BUTTON HD CAP SCR 10-32 X 5/16
71	P0969071	PLUG
72	P0969072	SET SCREW M4-.7 X 5
75	P0969075	STRAIN RELIEF TYPE-3 PG11
76V2	P0969076V2	CIRCUIT BOARD V2.05.25 EX2130PWM-1
84	P0969084	SWITCH BOX
92V2	P0969092V2	MOTOR CORD 18G 2W 42" V2.05.25
93	P0969093	BLADE GUARD UPPER
94	P0969094	BLADE GUARD LOWER
103	P0969103	PROTECTION BRACKET
107	P0969107	3-PIN RECEPTACLE W/DUST CAP
108V2	P0969108V2	FOOT PEDAL ASSEMBLY V2.05.25
109	P0969109	FOOT PEDAL CIRCUIT BOARD
110	P0969110	SPONGE WIRE DAMPER



Table & Base



REF PART # DESCRIPTION


201	P0969201	TRUNNION
202	P0969202	SIDE PANEL
203	P0969203	TRUNNION PLATE REAR
204	P0969204	TRUNNION PLATE FRONT
205	P0969205	TABLE
207	P0969207	POWER CORD 18G 3W 72" 5-15P
210	P0969210	HEX BOLT 1/4-20 X 1/2
211	P0969211	LOCK WASHER 1/4
212	P0969212	FLAT WASHER 1/4
213	P0969213	FLAT WASHER 12 X 41 X 4.5
214	P0969214	GEAR 12T
215	P0969215	HEX BOLT 1/4-20 X 3/4
216	P0969216	TILT ROD BRACKET
217	P0969217	BUTTON HD CAP SCR 10-32 X 5/16
218	P0969218	FLAT WASHER #10
219	P0969219	FLANGE NUT 1/4-20
220	P0969220	INDEXING BRACKET
221	P0969221	BUTTON HD CAP SCR 1/4-20 X 1
222	P0969222	E-CLIP 3MM

REF PART # DESCRIPTION

223	P0969223	BARREL SLEEVE
224	P0969224	COMPRESSION SPRING 8 X 1 X 10.5
225	P0969225	PLUNGER PIN
226	P0969226	TILT KNOB
227	P0969227	LOCK WASHER 1/4
228	P0969228	ADJUSTABLE HANDLE 1/4-20 X 3/4, 1-1/2L
229	P0969229	FLAT HD CAP SCR 1/4-20 X 3/4
235	P0969235	LEVELING FOOT 3/8-16 X 1-1/4
236	P0969236	TILT ROD
237	P0969237	HEX NUT 3/8-16
238	P0969238	INDICATOR
239	P0969239	PHLP HD SCR M4-.7 X 6
240	P0969240	FLAT WASHER 4MM
245	P0969245	SHROUD
246	P0969246	DUST PORT 2-1/2"
248	P0969248	EXT TOOTH WASHER 4MM
249	P0969249	PHLP HD SCR 8-32 X 3/8
250	P0969250	FLAT WASHER #8



Motor & Drivetrain



Motor & Drivetrain Parts List

REF	PART #	DESCRIPTION
302	P0969302	BALANCE BLOCK
303	P0969303	SET SCREW M6-1 X 6
304	P0969304	BUTTON HD CAP SCR 1/4-20 X 1/2
305	P0969305	LOCK WASHER 1/4
306	P0969306	FLAT WASHER 1/4
307	P0969307	MOTOR COVER PLATE
308	P0969308	FLAT HD CAP SCR M6-1 X 16
309	P0969309	BALL BEARING 6008ZZ
310	P0969310	MOTOR CAM
311	P0969311	HEX NUT M8-1.25 LH
312	P0969312	NEEDLE BEARING HK0810
314	P0969314	ROCKER CAM
315	P0969315	LOCK NUT M5-.8
317	P0969317	NEEDLE BEARING HK0609
318	P0969318	INNER BEARING SLEEVE 6.03 X 21
319	P0969319	CAP SCREW M5-.8 X 28
320	P0969320	BEARING COVER
321	P0969321	NEEDLE BEARING HK1412
322	P0969322	PIVOT SHAFT
323	P0969323	HEX NUT M4-.7
324	P0969324	CAP SCREW M4-.7 X 25
326	P0969326	BELLOWS
327	P0969327	ROCKER ARM
328	P0969328	FLAT WASHER 8 X 15 X 0.6MM
329	P0969329	INNER BEARING SLEEVE 8 X 18
330	P0969330	INNER BEARING SLEEVE 6 X 37
331	P0969331	ROCKER MOUNT
332	P0969332	CAP SCREW M4-.7 X 45

REF	PART #	DESCRIPTION
333	P0969333	CAP SCREW M4-.7 X 24
335	P0969335	STRUT
336	P0969336	BLADE MOUNT LOWER
337	P0969337	SET SCREW M6-1 X 8
338	P0969338	KNOB BOLT M1/4-20 X 3/4, D1, WING
339	P0969339	BLADE 5" PLAIN-END 25 TPI
340	P0969340	HEX WRENCH 3MM
341	P0969341	CLAMP BRACKET
342	P0969342	SET SCREW 1/4-20 X 1/2
343	P0969343	COMPRESSION SPRING 8 X 1 X 10.5
344	P0969344	TENSION LEVER
345	P0969345	PHLP HD SCR M4-.7 X 6
346	P0969346	BLADE MOUNT UPPER
357	P0969357	FLAT WASHER 4MM
358	P0969358	INNER BEARING SLEEVE 6 X 16.5
359	P0969359	INNER BEARING SLEEVE 8 X 21.5
360	P0969360	FLAT WASHER 5MM
361	P0969361	CAP SCREW M4-.7 X 27
362	P0969362	FLAT WASHER 4 X 14 X 1.2MM
364	P0969364	DRIVE LINK
365	P0969365	MOTOR 50W 60V 1-PH DC
366	P0969366	SPACER 10ID X 20OD X 2L
367	P0969367	INNER BEARING SLEEVE 6 X 16
368	P0969368	CAP SCREW M4-.7 X 30
369	P0969369	FLAT WASHER 4MM
370	P0969370	MOTOR BRUSH (2-PC)
371	P0969371	BINDING BARREL M4-.7 X 6




Labels & Cosmetics

MODEL G0969 21" VS SCROLL SAW w/FOOT PEDAL		Specifications	WARNING!
Size	21"	Motor: 500W 110V, 1-4P, 60 Hz Full Load Current Rating: 3.8A Blade Stroke: 24" - 400-1000 SPM Blade: 1" - 1/2" Thick Steel Maximum Cutting Height: 4" Maximum Cutting Depth: 21" Voltage: 110, 240V Weight: 75 lbs.	1. To reduce the risk of serious injury, please read the instructions. 2. Read and understand owner's manual before operating. 3. Always wear ANSI-approved eye protection and earplugs. 4. Never touch moving blade - keep hands out of blade path. 5. Only plug power cord into a grounded outlet. 6. Only operate power scroll saw when blade is stopped. 7. Use power switch to holding jig for not small or narrow pieces. 8. Disconnect power before changing blade or adjusting saw. 9. Verify blade is secure and properly tensioned before operating. 10. Hold workpiece firmly against table to maintain contact. 11. Never reach under table while blade is in motion. 12. Disconnect power before cleaning and tooling. 13. Do NOT operate in rain or wet conditions. 14. Do not operate under influence of drugs or alcohol, or when fatigued. 15. Prevent unauthorized use by children or untrained users.


401

G0969

402



403



404

405

REF	PART #	DESCRIPTION
401	P0969401	MACHINE ID LABEL
402	P0969402	MODEL NUMBER LABEL
403	P0969403	COMBO WARNING LABEL

REF	PART #	DESCRIPTION
404	P0969404	ELECTRICITY LABEL
405	P0969405	TOUCH-UP PAINT, GRIZZLY GREEN

