





9" BANDSAW

MODEL G1052

PARTS LIST



COPYRIGHT © 1995 BY GRIZZLY INDUSTRIAL, INC.


WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.

APRIL, 1999 PRINTED IN U.S.A.

PARTS LIST DISCLAIMER

THIS PARTS LIST AND DRAWINGS REPRESENT THE CONFIGURATION OF THE MACHINE AS IT IS CURRENTLY BEING SHIPPED. THE MACHINE CONFIGURATION CAN CHANGE AS PRODUCT IMPROVEMENTS ARE INCORPORATED. IF YOU OWN AN EARLIER VERSION OF THE MACHINE, THIS PARTS LIST MAY NOT DEPICT YOUR MACHINE EXACTLY. CONTACT CUSTOMER SERVICE IF YOU HAVE ANY QUESTIONS ABOUT PART DIFFERENCES. PREVIOUS PARTS LIST VERSIONS ARE NOT AVAILABLE ONLINE.

PARTS DIAGRAMS



BEARING GUIDES






TABLE AND FENCE



MOTOR AND GEARBOX



PARTS LISTS

REF#	PART#	DESCRIPTION
001	P1052001	BODY
002	P1052002	TENSION KNOB
004	P1052004	SPRING
005	P1052005	COLLAR
006	PSS29	SETSCREW 4 - 40 x 1/4"
007	P1052007	TENSION BRACKET
008	PSB04	CAP SCREW 1/4" - 20 x 1/2"
009	P1052009	SLIDING GIB
010	PSB17	CAP SCREW 1/4" - 20 x 3/8"
011	PSS26	SETSCREW 10 - 24 x 3/8"
012	P1052012	SLIDING BRACKET
013	P1052013	HINGE PIN
014	PEC09M	E-CLIP 6mm
015	P1052015	SHAFT HINGE
016	PSS24	SETSCREW 10 - 32 x 3/16"
018	P1052018	TOP WHEEL
019	P6200	BEARING 6200-2RS
020	PR35M	SNAP RING 30mm
021	P1052021	SPACER
022	P1052022	KNURLED KNOB
023	P1052023	TRACKING KNOB
024	PN20	HEX NUT 5/16" - 24
025	PW07	FLAT WASHER 5/16"
026	PS03	HEX BOLT 10 - 24 x 1"
027	P1052027	GUIDE POST BRACKET
028	P1052028	GUIDE POST W/29
029	P1052029	SPRING
030	PS18	PHLP HD SCRW 10 - 24 x 1/4"
031	P1052031	KNOB
032	P1052032	UPPER GUIDE BRACKET
033	PSS24	SETSCREW 10 - 32 x 3/16"
035	PS16	PHLP HD SCRW 6 - 32 x 1/4"
036	P1052036	GUARD
037	P1052037	BLADE GUIDE SHAFT W/039

REF#	PART#	DESCRIPTION
038	P1052038	BLADE BACKUP SHAFT W/039
039	P2921001	BEARING
040	PR03	SNAP RING 1/4"
041	CATALOG	BLADE
042	P1052042	TIRE
043	P1052043	LOWER WHEEL
044	PK05M	KEY 4 x 4 x 10mm
045	PSB05	CAP SCREW 1/4" - 20 x 3/4"
046	PW07	FLAT WASHER 5/16"
047	P1052047	LOWER GUIDE BRACKET
048	PSB04	CAP SCREW 1/4" - 20 x 1/2"
049	P1052049	TRUNNION
050	PFH12	FLAT HEAD SCRW 1/4" - 20 x 1"
051	P1052051	SPECIAL BOLT
053	P1052053	LOCK HANDLE ASSEMBLY
054	PW07	FLAT WASHER 5/16"
055	P1052055	TABLE
056	PS19	PHLP HD SCRW 1/4" - 20 x 1"
057	PWN02	WING NUT 1/4" - 20
058	PLW02	LOCK WASHER #10
059	PSS10	SETSCREW 1/4" - 20 x 5/8"
060	P1052060	HANDLE
061	P1052061	REAR LOCK BRACKET
062	P1052062	LOCK ROD
063	P1052063	FENCE TUBE
064	P1052064	FRONT LOCK BRACKET
065	PS01	PHLP HD SCRW 10 - 24 x 1/2"
066	PW06	FLAT WASHER 1/4"
067	P3105071	MITER GAUGE
068	P1052068	TABLE INSERT
069	P1052069	BRUSH W/070
070	P1052070	BRACKET
071	P1052071	TOP WHEEL GUARD
072	P1057072	LOWER WHEEL GUARD

REF# PART# DESCRIPTION

073	PS01	PHLP HD SCRW 10 - 24 x 1/2"
074	PW03	FLAT WASHER #10
075	P1073098	LATCH
076	P1073099	STRIKE
077	PS16	PHLP HD SCRW 6 - 32 x 1/4"
078	PN12	HEX NUT 6 - 32
079	P1052079	POWER CORD
080	P1015017-1	STRAIN RELIEF (N/S)
081	P1052081	MOTOR
082	P1052082	GEAR BOX COVER
083	P1052083	GEAR BOX CASE
084	PSB07	CAP SCREW 5/16" - 18 x 3/4"
085	PW07	FLAT WASHER 5/16"
086	PSB05	CAP SCREW 1/4" - 20 x 3/4"
087	P6202	BEARING 6202 - 2RS
088	P1052088	SEAL 15 - 35 x 7
089	P1052089	GEAR 12T

REF# PART# DESCRIPTION

090	P1052090	GEAR 36T
091	P1052091	SHAFT
092	PK47M	KEY 4 x 4 x 15mm
093	PK05M	KEY 4 x 4 x 10mm
094	P1052094	SCREW
095	P1052095	LOGO
096	PLW02	LOCK WASHER 1/4"
097	P1052097	FENDER WASHER 1/4"
098	P1052098	SHIM
099	PW16	FLAT WASHER #6
100	PSW06	SWITCH
101	P1052101	OUTER WIRE BOX
102	P1052102	INNER WIRE BOX
103	P1052103	MOTOR FAN
104	P1052104	FAN COVER
105	P1052105	CAPACITOR COVER
106	PC150	CAPACITOR 150MFD