


XI. PARTS DIAGRAM



XII. PARTS LIST

Ref #	Description	Qty.
1.	Base	1
2.	Motor	1
3.	Floor Plate	1
4.	Pan Head Screw	4
5.	Washer	4
6.	Rubber Foot	4
7.	Switch Plate	1
8.	Pan Head Screw	2
9.	Switch	1
10.	Wheel Cover	1
11.	Spindle Nut	2
12.	Wheel Flange	4
13.	Grinding Wheel	1
14.	Tool Rest	2
15.	Washer	2
16.	Hex Bolt	2
17.	Hex Nut	6
18.	Washer	6
19.	Pan Head Screw	6
20.	Pan Head Screw	4
21.	Washer	4

Ref #	Description	Qty.
22.	Hex Nut	4
23.	Eye Shield	2
24.	Wheel Guard Left	1
25.	Hex Bolt	2
26.	Washer	2
27.	Holder Plate	2
28.	Hex Bolt	2
29.	Washer	2
30.	Wing Nut	2
31.	Machine Screw	2
32.	Washer	2
33.	Shield Bracket	2
34.	Machine Screw	4
35.	Washer	4
36.	Hex Nut	4
37.	Wheel Guard Right	1
38.	Sharpening Wheel	1
39.	Wheel Cover Right	1
40.	Cord	1
41.	Capacitor	1
42.	Clamp	1