


MODEL G2908 1½ HP ELECTRIC MOTOR INSTRUCTIONS

For questions or help with this product contact Tech Support at (570) 546-9663 or techsupport@grizzly.com

Model G2908 Specifications

Power	1½ HP
Cycle	60Hz
Voltage	110/220V
Prewired	110V
Amps	15.6A/7.8A
RPM	3450
Phase	Single
Class	E






WARNING

Electrocution or fire could result if this motor is not grounded correctly or if your wire connections do not comply with local and state codes. Ensure compliance by checking with a qualified electrician!

Replaceable Parts




REF PART # DESCRIPTION

1	P2908001	S CAPACITOR COVER
2	P2908002	S CAPACITOR 400M 125V 1-3/4 X 3-3/8
3	P2908003	WIRING COVER PLATE
4	P2908004	CENTRIFUGAL SWITCH 1/2-3450
5	P2908005	CONTACT PLATE
6	P2908006	BALL BEARING 6202ZZ
7	P2908007	BALL BEARING 6203ZZ
8	P2908008	KEY 3/16 X 3/16 X 1-1/4
9	P2908009	R CAPACITOR COVER
10	P2908010	R CAPACITOR 25M 250V 1-3/8 X 2-3/8

Making Wire Connections

If you are unsure how to attach wires to terminals, DO NOT continue. Contact an electrician for assistance. Connecting wires improperly may cause electrocution, fire, or a short.



COPYRIGHT © JULY, 2012 BY GRIZZLY INDUSTRIAL, INC., REVISED JUNE, 2024 (LW) NO PORTION OF THIS INSTRUCTION SHEET MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC. (FOR MODELS MFD. SINCE 08/24) #KN15083 PRINTED IN TAIWAN

V2.06.24