


Parts Breakdown



Parts List

REF	PART #	DESCRIPTION
1	P5771001	BASE
2	PW06M	FLAT WASHER 12MM
3	PLW05M	LOCK WASHER 12MM
4	PB75M	HEX BOLT M12-1.75 X 35
5	P5771005	LIFT STAND
6	P5771006	SETTING KNOB PIN
7	P5771007	SETTING KNOB
8	P5771008	SET SCREW M10 X 30
9	P5771009	RIGHT STAND
10	P5771010	GEAR LOCKING SHAFT
11	P5771011	BEARING 30 X 38 X 24
12	P5771012	GEAR 19T
13	P5771013	GEAR 13T
14	P5771014	GEAR 16T
15	P5771015	KEY B10 X 25
16	P5771016	GEAR 40T
17	PW04M	FLAT WASHER 10MM
18	PB14M	HEX BOLT M10-1.5 X 35
19	P5771019	GEAR COVER

REF	PART #	DESCRIPTION
20	PLW03M	LOCK WASHER 6MM
21	PB18M	HEX BOLT M6-1 X 15
22	P5771022	FEED ROLLER KNOB
23	PB09M	HEX BOLT M8-1.25 X 20
24	P5771024	HEX SCREW M12 X 65
25	P5771025	ROLLER #1 BASE
26	P5771026	ROLLER #1
27	P5771027	ROLLER BASE
28	P5771028	FEED ROLLER
29	P5771029	ROLLER #2
30	P5771030	SHAFT
31	P5771031	HANDLE LOCKING BUSH
32	PSS20M	SET SCREW M8-1.25 X 8
33	P5771033	ROLLER #1 BUSHING M10 X 15
34	PSS10M	SET SCREW M10-1.5 X 20
35	P5771035	CRANK HANDLE
36	PN03M	HEX NUT M8-1.25
37	P5771037	GRIP
38	P5771038	GRIP SHAFT

