


Parts Breakdown



Parts List

REF	PART #	DESCRIPTION
1	P5772001	TABLE
2	P5772002	CUTTER BAR
3	P5772003	HOLD DOWN
4	P5772004	RH SIDE PANEL
5	P5772005	LH SIDE PANEL
6	P5772006	FRONT ARM EXT
7	P5772007	HEX BOLT M12-1.75 X 45
8	P5772008	HOLD DOWN SPRING 12
9	P5772009	HOLD DOWN SPRING STUD
10	P5772010	HEX NUT M12-1.75
11	P5772011	HEX BOLT M12-1.75 X 65
12	P5772012	FLAT WASHER 12MM
13	P5772013	FINGER GUARD
14	P5772014	CAP SCREW M8-1.25 X 12
15	P5772015	LH TABLE SCALE
16	P5772016	RH TABLE SCALE
17	P5772017	TABLE SCALE SCREW
17A	P5772017A	TABLE SCALE WASHER
18	P5772018	SET SCREW M10-1.5 X 50
19	P5772019	CAP SCREW M10-1.5 X 40
21	P5772021	HEX BOLT M16-2 X 120
22	P5772022	FLAT WASHER 16MM
23	P5772023	HEX NUT M16-1.5
24	P5772024	MOVING KNIFE (UPPER)
25	P5772025	FIXED KNIFE (LOWER)
26	P5772026	HEX BOLT M10-1.5 X 40
27	P5772027	CAP SCREW M10-1.5 X 55
28	P5772028	FLAT WASHER 10MM
29	P5772029	FLAT WASHER 10MM
30	P5772030	SET SCREW M12-1.75 X 12
31	P5772031	GIB
32	P5772032	CAP SCREW M10-1.5 X 30
33	P5772033	HEX NUT M10-1.5
34	P5772034	STRAIGHTENER ROD
35	P5772035	FLAT WASHER 16MM
36	P5772036	HEX NUT M16-1.5
37	P5772037	ADJ SCREW M16 X 50
38	P5772038	HEX NUT M16-1.5
39	P5772039	FLAT WASHER 16MM
40	P5772040	SET SCREW M10-1.5 X 20
41	P5772041	FOOT PEDAL SPRING

REF	PART #	DESCRIPTION
41A	P5772041A	CAP SPRING
42	P5772042	SWIVEL TOP
43	P5772043	SWIVEL BOTTOM
44	P5772044	STUD
45	P5772045	LOCK WASHER 16MM
46	P5772046	HEX NUT M16-1.5
47	P5772047	SPRING MOUNTING BRACKET
48	P5772048	CAP SCREW M10-1.5 X 25
49	P5772049	FLAT WASHER 10MM
50	P5772050	TOP SWIVEL SCREW
51	P5772051	BOTTOM SWIVEL SCREW
53	P5772053	HINGE PIN
58	P5772058	BACK GAUGE ROD
59	P5772059	BACK GAUGE STOP
60L	P5772060L	BACK GAUGE EXT BAR (L)
60R	P5772060R	BACK GAUGE EXT BAR (R)
61	P5772061	ADJUSTABLE BLOCK
62	P5772062	ADJUSTABLE DIAL
63	P5772063	ADJUSTABLE SCREW
64	P5772064	HEX NUT M10-1.5
65	P5772065	LOCK KNOB
66	P5772066	STUD
67	P5772067	ROD BRACKET
68	P5772068	EXT BAR SCREW
69	P5772069	HEX BOLT M10-1.5 X 25
70	P5772070	HEX NUT M10-1.5
71	P5772071	FRONT STOP
72	P5772072	T-BOLT
73	P5772073	FLAT WASHER 3/8"
74	P5772074	WING NUT
75	P5772075	BEVEL GAUGE
76	P5772076	SET SCREW M10-1.5 X 20
77	P5772077	FOOT PEDAL
78	P5772078	MACHINE ID LABEL
79	P5772079	SAFETY GLASSES LABEL
80	P5772080	READ MANUAL LABEL
81	P5772081	SHEARED FINGERS LABEL
82	P5772082	GUARD LABEL
83	P5772083	MODEL NUMBER LABEL
902	P57720902	PEDAL ASSY
903	P57720903	BACK GAUGE ASSY

WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.

