

MODEL H5377 3/4 HP ELECTRIC MOTOR INSTRUCTIONS

For questions or help with this product contact Tech Support at (570) 546-9663 or techsupport@grizzly.com

Model H5377 Specifications

Power	3/4 HP
Cycle	60 Hz
Voltage	110/220V
Prewired Voltage	110V
Amps	9/4.5A
Speed	1725 RPM
Phase	Single-Phase
Class	B



AWARNING


Electrocution or fire could result if this motor is not grounded correctly or if your wire connections do not comply with local and state codes. Ensure compliance by checking with a qualified electrician!



WARNING

Disconnect power when replacing motor. Failure to do this may result in serious personal injury.

Replaceable Parts



REF	PART #	DESCRIPTION
1	PH5377001	MOTOR FAN COVER
2	PH5377002	MOTOR FAN
3	PH5377003	S CAPACITOR COVER
4	PH5377004	S CAPACITOR 200M 125V 1-1/2 X 2-3/8
5	PH5377005	R CAPACITOR COVER
6	PH5377006	R CAPACITOR 30M 250V 1-1/2 X 2-3/8
7	PH5377007	JUNCTION BOX
8	PH5377008	CENTRIFUGAL SWITCH
9	PH5377009	CONTACT PLATE

Making Wire Connections

If you are unsure how to attach wires to terminals, DO NOT continue. Contact an electrician for assistance. Connecting wires improperly may cause them to come loose or contact other wires, which can cause electrocution, fire, or a short.

V2.11.24

COPYRIGHT © DECEMBER, 2007 BY GRIZZLY INDUSTRIAL, INC., REVISED NOVEMBER, 2024 (LW) NO PORTION OF THIS INSTRUCTION SHEET MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC. (FOR MODELS MFD. SINCE 08/24) #JB10223 PRINTED IN TAIWAN