


Parts Breakdown



Parts List

REF	PART #	DESCRIPTION
1	PH7760001	PHLP HD SCR M5-.8 X 45
2	PH7760002	LEFT WHEEL COVER
3	PH7760003	HEX NUT M12-1.75 LH
4	PH7760004	FLANGE
5	PH7760005	GRINDING WHEEL A36N5V
6	PH7760006	PHLP HD SCR M5-.8 X 10
7	PH7760007	LEFT SAFE GUARD
8	PH7760008	SPARK BREAKER
9	PH7760009	FLAT WASHER 5MM
10	PH7760010	PHLP HD SCR M5-.8 X 8
11	PH7760011	SUPPORT ARM
12	PH7760012	BRACKET
13	PH7760013	FLAT WASHER 8MM
14	PH7760014	HEX BOLT M8-1.25 X 14
15	PH7760015	CARRIAGE BOLT M6-1.0 X 18
16	PH7760016	EYESHIELD PLATE
17	PH7760017	FLAT WASHER 6MM
18	PH7760018	PHLP HD SCR M4-.7 X 10
19	PH7760019	HOUSING SCR M5-.8 X 123
20	PH7760020	KNOB M8-1.25
21	PH7760021	END BELL
22	PH7760022	HEX NUT M8-1.25
23	PH7760023	WAVY WASHER 28MM
24	PH7760024	BEARING 6202-RS
25	PH7760025	STATOR
26	PH7760026	ROTOR
27	PH7760027	HEX NUT M5-.8
28	PH7760028	EXT TOOTH WASHER 5MM
29	PH7760029	LEFT MOUNT TOOL REST
30	PH7760030	EYESHIELD
31	PH7760031	KNOB BOLT M5-.8 X 10
32	PH7760032	LOCK WASHER 5MM
33	PH7760033	FLAT WASHER 4MM
34	PH7760034	HEX NUT M4-.7
35	PH7760035	HEX NUT M12-1.75
36	PH7760036	SANDING BELT 2" X 27"
37	PH7760037	RIGHT WHEEL COVER
38	PH7760038	EXT TOOTH WASHER 4MM
39	PH7760039	PHLP HD SCR M4-.7 X 8
40	PH7760040	RIGHT SAFE GUARD
41	PH7760041	CORD BUSHING
42	PH7760042	R CAPACITOR 9M 300V

REF	PART #	DESCRIPTION
43	PH7760043	CAPACITOR SUPPORT
44	PH7760044	LOCK WASHER 4MM
45	PH7760045	WHEEL DRESSING TOOL
46	PH7760046	LAMP SUPPORT
47	PH7760047	MOTOR HOUSING
48	PH7760048	CORD & PLUG
49	PH7760049	CORD CLIP
50	PH7760050	HEX NUT M10-1.0
51	PH7760051	LOCK WASHER 10MM
52	PH7760052	SWITCH PLATE
53	PH7760053	SWITCH
54	PH7760054	HEX NUT M4-.7
55	PH7760055	PHLP HD SCR M4-.7 X 15
56	PH7760056	FLAT WASHER 4MM
57	PH7760057	RUBBER FOOT
58	PH7760058	COOLANT TRAY
59	PH7760059	BOTTOM PLATE
60	PH7760060	RIGHT MOUNT TOOL REST
61	PH7760061	FLAT WASHER 5MM
62	PH7760062	PHLP HD SCR M5-.8 X 10
63	PH7760063	BULB S-25 12V 10W
64	PH7760064	LAMPSHADE
65	PH7760065	DRESSING BASE
66	PH7760066	KNOB M6-1.0 X 10
67	PH7760067	ADJUSTMENT ROD
68	PH7760068	SPRING
69	PH7760069	TENSION PLATE
70	PH7760070	DRIVE SHAFT WASHER
71	PH7760071	BALL BEARING 6201ZZ
72	PH7760072	UPPER DRIVE CYLINDER
73	PH7760073	DRIVE SHAFT
74	PH7760074	WORK SUPPORT
75	PH7760075	DRIVE SHAFT SPACER
76	PH7760076	LOWER DRIVE CYLINDER
77	PH7760077	HEX NUT M6-1.0
78	PH7760078	KNOB BOLT M5-.8 X 10
79	PH7760079	DUST PORT
80	PH7760080	INT RETAIN RING 32MM
81	PH7760081	SAFE BOARD
82	PH7760082	HEX NUT M5-.8
83	PH7760083	MACHINE ID LABEL

WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.

