


# Parts Breakdown



# Parts List

| REF | PART #    | DESCRIPTION                    |
|-----|-----------|--------------------------------|
| 1   | PS06      | PHLP HD SCR 10-24 X 3/8        |
| 2   | PH8126002 | WIRE NUT                       |
| 3   | PW02M     | FLAT WASHER 5MM                |
| 4   | PH8126004 | ARROW LABEL                    |
| 5   | PS24      | PHLP HD SCR 8-32 X 3/8         |
| 6   | PN14      | HEX NUT 8-32                   |
| 7   | PW05M     | FLAT WASHER 4MM                |
| 8   | PW06      | FLAT WASHER 1/4                |
| 9   | PB51      | HEX BOLT 1/4-20 X 3/8          |
| 10  | PH8126010 | LEFT SPARK GUARD               |
| 11  | PH8126011 | RIGHT SPARK GUARD              |
| 12  | PH8126012 | BRACKET                        |
| 13  | PH8126013 | NUT PLATE                      |
| 14  | PH8126014 | EYE SHIELD                     |
| 15  | PH8126015 | LEFT TOOL REST                 |
| 16  | PH8126016 | RIGHT TOOL REST                |
| 17  | PB15      | HEX BOLT 5/16-18 X 3/8         |
| 18  | PW07      | FLAT WASHER 5/16               |
| 19  | PLW01M    | LOCK WASHER 5MM                |
| 20  | PH8126020 | COPPER WASHER 5MM              |
| 21  | PH8126021 | SPECIAL TOOTH SCR 1/4-20 X 3/8 |
| 22  | PH8126022 | SPECIAL TOOTH SCR 10-24 X 1/4  |
| 23  | PS18      | PHLP HD SCR 10-24 X 1/4        |
| 24  | PH8126024 | RIGHT 1/2" ARBOR NUT           |
| 25  | PH8126025 | LEFT 1/2" ARBOR NUT            |
| 26  | PH8126026 | RIGHT OUTER WHEEL GUARD        |
| 27  | PH8126027 | LEFT OUTER WHEEL GUARD         |
| 28  | PH8126028 | RIGHT INNER WHEEL GUARD        |
| 29  | PH8126029 | LEFT INNER WHEEL GUARD         |

| REF | PART #    | DESCRIPTION               |
|-----|-----------|---------------------------|
| 30  | PH8126030 | GRAY GRINDING WHEEL #36   |
| 31  | PH8126031 | WHITE GRINDING WHEEL #100 |
| 32  | PH8126032 | WHEEL FLANGE              |
| 33  | PH8126033 | RUBBER FOOT               |
| 34  | PH8126034 | BOTTOM PLATE              |
| 35  | PH8126035 | STRAIN RELIEF             |
| 36  | PH8126036 | 110V POWER CORD           |
| 37  | PH8126037 | WIRE NUT                  |
| 38  | PH8126038 | SWITCH PLATE              |
| 39  | PH8126039 | ROCKER SWITCH SW-155-BB2  |
| 40  | PH8126040 | CAPACITOR RETAINER        |
| 41  | PH8126041 | CAPACITOR 6MFD 250VAC     |
| 42  | PN07      | HEX NUT 10-24             |
| 43  | PH8126043 | PHLP HD SCR 10-24 X 4-1/4 |
| 44  | PW06      | FLAT WASHER 1/4           |
| 45  | PLW02     | LOCK WASHER 1/4           |
| 46  | PN05      | HEX NUT 1/4-20            |
| 47  | PSS06     | SET SCREW 1/4-20 X 3/4    |
| 48  | PH8126048 | STRAIN RELIEF             |
| 49  | PH8126049 | BASE                      |
| 50  | PH8126050 | END COVER                 |
| 51  | PH8126051 | MOTOR CASE                |
| 52  | P6202     | BALL BEARING 6202ZZ       |
| 55  | PH8126055 | FAN                       |
| 56  | PH8126056 | STATOR                    |
| 57  | PH8126057 | DATA/WARNING LABEL        |
| 58  | PH8126058 | ROTOR AND SHAFT           |
| *59 | PPAINT-1  | PAINT-GRIZZLY GREEN       |

\*Not shown on parts diagram.

## WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or [www.grizzly.com](http://www.grizzly.com) to order new labels.

