


Parts Breakdown



Parts List

REF PART # DESCRIPTION

1	PH8148001	FLAT WASHER 5MM (H8148/H8149)
	PH8150001	FLAT WASHER 1/4 (H8150)
2	PH8148002	DATA/WARNING LABEL (H8148)
	PH8149002	DATA/WARNING LABEL (H8149)
	PH8150002	DATA/WARNING LABEL (H8150)
3	PFS02M	FLANGE SCREW M6-1 X 12
4	PLW17M	LOCK WASHER 7MM
5	PS06	PHLP HD SCR 10-24 X 3/8
6	PH8148006	FEMALE KNOB 1/4-20
7	PS18	PHLP HD SCR 10-24 X 1/4 (H8148/H8149)
	PS04	PHLP HD SCR 1/4-20 X 1/2 (H8150)
8	PB17M	HEX BOLT M6-1.25 X 10
9	PH8148009	NUTPLATE
10	PH8148010	EYESHIELD (H8148)
	PH8149010	EYESHIELD (H8149)
	PH8150010	EYESHIELD (H8150)
11	PH8148011	LEFT BRACKET (H8148/H8149)
	PH8150011	LEFT BRACKET (H8150)
12	PH8148012	RIGHT BRACKET (H8148/H8149)
	PH8150012	RIGHT BRACKET (H8150)
13	PH8148013	LEFT SPARK ARRESTOR (H8148/H8149)
	PH8150013	LEFT SPARK ARRESTOR (H8150)
14	PH8148014	RIGHT SPARK ARRESTOR (H8148/H8149)
	PH8150014	RIGHT SPARK ARRESTOR (H8150)
15	PH8148015	ARROW LABEL
16	PH8148016	RUBBER FOOT (H8148)
	PH8149016	RUBBER FOOT (H8149)
	PH8150016	RUBBER FOOT (H8150)
17	PH8148017	BASE PLATE (H8148)
	PH8149017	BASE PLATE (H8149)
	PH8150017	BASE PLATE (H8150)
18	PH8148018	SWITCH PLATE (H8148)
	PH8149018	SWITCH PLATE (H8149/H8150)
19	G8988	SAFETY PADDLE SWITCH (H8148/H8149)
	PH8150019	TOGGLE SWITCH RF-1001 (H8150)
20	PLW01M	LOCK WASHER 5MM
21	PH8148021	COPPER WASHER 5MM
22	PS18	PHLP HD SCR 10-24 X 1/4
23	PH8148023	POWER CORD 110V
24	PH8148024	CAPACITOR CAP (H8148/H8149)
	PH8150024	CAPACITOR CAP (H8150)
25	PH8148025	FIXTURE CLIP (H8148/H8149)
	PH8150025	FIXTURE CLIP (H8150)
26	PH8148026	CAPACITOR 100MFD 125V (H8148)
	PH8149026	CAPACITOR 200MFD 125V (H8149)
	PH8150026	CAPACITOR 300MFD 125V (H8150)
27	PS18	PHLP HD SCR 10-24 X 1/4

REF PART # DESCRIPTION

28	PH8148028	WIRE PLATE
29	PH8148029	STRAIN RELIEF
30	PB07	HEX BOLT 5/16-18 X 3/4
31	PW01M	FLAT WASHER 8MM
32	PH8148032	RIGHT TOOL REST (H8148)
	PH8149032	RIGHT TOOL REST (H8149)
	PH8150032	RIGHT TOOL REST (H8150)
33	PH8148033	LEFT TOOL REST (H8148)
	PH8149033	LEFT TOOL REST (H8149)
	PH8150033	LEFT TOOL REST (H8150)
34	PS04	PHLP HD SCR 1/4-20 X 1/2
35	PH8148035	LEFT OUTER WHEEL GUARD (H8148)
	PH8149035	LEFT OUTER WHEEL GUARD (H8149)
	PH8150035	LEFT OUTER WHEEL GUARD (H8150)
36	PH8148036	RIGHT OUTER WHEEL GUARD (H8148)
	PH8149036	RIGHT OUTER WHEEL GUARD (H8149)
	PH8150036	RIGHT OUTER WHEEL GUARD (H8150)
37	PH8148037	RIGHT 1/2" ARBOR NUT (H8148)
	PH8149037	RIGHT 5/8" ARBOR NUT (H8149)
	PH8150037	RIGHT 1" ARBOR NUT (H8150)
38	PH8148038	LEFT 1/2" ARBOR NUT (H8148)
	PH8149038	LEFT 5/8" ARBOR NUT (H8149)
	PH8150038	LEFT 1" ARBOR NUT (H8150)
39	PH8148039	1/2" BORE A60 GRINDING WHEEL (H8148)
	PH8149039	5/8" BORE A60 GRINDING WHEEL (H8149)
	PH8150039	1" BORE A60 GRINDING WHEEL (H8150)
40	PH8148040	1/2" BORE A36 GRINDING WHEEL (H8148)
	PH8149040	5/8" BORE A36 GRINDING WHEEL (H8149)
	PH8150040	1" BORE A36 GRINDING WHEEL (H8150)
41	PH8148041	1/2" WHEEL FLANGE (H8148)
	PH8149041	5/8" WHEEL FLANGE (H8149)
	PH8150041	1" WHEEL FLANGE (H8150)
42	PS04	PHLP HD SCR 1/4-20 X 1/2
43	PH8148043	RIGHT INNER WHEEL GUARD (H8148)
	PH8149043	RIGHT INNER WHEEL GUARD (H8149)
	PH8150043	RIGHT INNER WHEEL GUARD (H8150)
44	PH8148044	LEFT INNER WHEEL GUARD (H8148)
	PH8149044	LEFT INNER WHEEL GUARD (H8149)
	PH8150044	LEFT INNER WHEEL GUARD (H8150)
45	PS22	PHLP HD SCR 10-24 X 5/8
46	PH8148046	CENTRIFUGAL SWITCH PLATE (H8148)
	PH8149046	CENTRIFUGAL SWITCH PLATE (H8149)
	PH8150046	CENTRIFUGAL SWITCH PLATE (H8150)
47	PH8148047	CENTRIFUGAL SWITCH ASSY. (H8148)
	PH8149047	CENTRIFUGAL SWITCH ASSY. (H8149)
	PH8150047	CENTRIFUGAL SWITCH ASSY. (H8150)
48	PH8148048	MOTOR COVER (H8148)
	PH8149048	MOTOR COVER (H8149)
	PH8150048	MOTOR COVER (H8150)



REF	PART #	DESCRIPTION
49	P6202	BALL BEARING 6202ZZ (H8148)
	P6204	BALL BEARING 6204ZZ (H8149)
	P6206	BALL BEARING 6206ZZ (H8150)
50	PH8148050	FAN (H8148)
	PH8149050	FAN (H8149)
	PH8150050	FAN (H8150)
51	PN05	HEX NUT 1/4-20
52	PW09M	FLAT WASHER 7MM
53	PSS07	SET SCREW 1/4-20 X 1/2
54	PH8148054	BASE (H8148)
	PH8149054	BASE (H8149)
	PH8150054	BASE (H8150)

REF	PART #	DESCRIPTION
55	PH8148055	MOTOR HOUSING (H8148)
	PH8149055	MOTOR HOUSING (H8149)
	PH8150055	MOTOR HOUSING (H8150)
56	PH8148056	STRAIN RELIEF
57	PH8148057	STATOR (H8148)
	PH8149057	STATOR (H8149)
	PH8150057	STATOR (H8150)
59	PS06	PHLP HD SCR 10-24 X 3/8
60	PH8148060	ROTOR AND SHAFT (H8148)
	PH8149060	ROTOR AND SHAFT (H8149)
	PH8150060	ROTOR AND SHAFT (H8150)

WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.

