



Replacement Parts And Labels



REF	PART #	DESCRIPTION
1	PH8155001	WELDERS MASK
2	PH8155002	MASK HANDLE
3	PH8155003	LENSE RETAINING CLIP
4	PH8155004	MASK LENSE
5	PH8155005	UTILITY BRUSH AND SLAG HAMMER
6	PH8155006	CONTROL TIP WRENCH
7	PH8155007	CONTROL TIP
8	PH8155008	WELDING TORCH NOZZLE
9	PH8155009	GAS INLET TUBE
10	PH8155010	HANDLE BRACKET
11	PHTEK11	TAP SCREW #8 X 3/4

REF	PART #	DESCRIPTION
12	PH8155012	HANDLE
13	PH8155013	WIRE FEED ASSEMBLY
14	PH8155014	WIRE SPOOL RETAINING NUT
15	PWN02	WING NUT 1/4-20
16	PH8155016	WELDING TORCH ASSEMBLY
17	PH8155017	WORK CLAMP ASSEMBLY
18	PH8155018	MACHINE ID LABEL
19	PLABEL-14	ELECTRICITY LABEL
20	PH8155020	SHOCK WARNING LABEL
21	PLABEL-12	READ MANUAL 2" X 3 5/16"

⚠ WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.

