


H8236 PARTS

Brad Nailer Breakdown




Brad Nailer Parts List

REF	PART #	DESCRIPTION
1	PH8235101	SPECIAL BOLT
2	PH8235102	EXHAUST PORT
3	PH8235103	COMPRESSION SPRING
4	PB42M	HEX BOLT M5-.8 X 20
5	PLW01M	LOCK WASHER 5MM
6	PH8235106	CYLINDER CAP
7	PORP014	O-RING 13.8 X 2.4 P14
8	PH8235108	SEALING RING
9	PH8235109	COMPRESSION SPRING
10	PH8235110	PLUNGER
11	PORS031-5	O-RING 31.0 X 2.0 S31.5
12	PORP025	O-RING 24.7 X 3.5 P25
13	PH8235113	CYLINDER CAP GASKET
14	PH8235114	CYINDER SLEEVE
15	PORP029-5	O-RING 29.2 X 3.5 P29.5
16	PORS042	O-RING 2.0 X 41.5 S42
17	PH8235117	CYLINDER
18	PORP022	O-RING 21.8 X 2.4 P22
19	PH8235119	PISTON W/DRIVER
20	PH8235120	BUMPER
21	PH8235121	NAILER BODY
22	PH8235122	RUBBER WASHER
23	PH8235123	SEAL
24	PH8235124	INNER VALVE SEAT
25	PH8235125	TRIGGER VALVE
26	PORP011-2	O-RING 11 X 2.4 P11.2
27	PH8235127	TRIGGER VALVE GUIDE
28	PORP011-2	O-RING 11 X 2.4 P11.2
29	PH8235129	COMPRESSION SPRING
30	PH8235130	GROOVED CLEVIS PIN
31	PH8235131	TRIGGER
32	PEC01M	E-CLIP 3MM
33	PH8235133	SAFETY PLATE
34	PRP11M	ROLL PIN 2.5 X 16
35	PH8235135	BRACKET

REF	PART #	DESCRIPTION
36	PH8235136	COMPRESSION SPRING
37	PH8235137	SAFETY NOSE
38	PH8235138	DRIVER GUIDE
39	PH8235139	SPACER
40	PSB15M	CAP SCREW M5-.8 X 20
41	PSB23M	CAP SCREW M4-.7 X 12
42	PSB17M	CAP SCREW M4-.7 X 10
43	PH8235143	DRIVER GUIDE COVER
44	PH8235144	NAIL GUIDE LINER
45	PH8235145	MAGAZINE SEAT
46	PSS35M	SET SCREW M4-.7 X 16
47	PH8235147	MAGAZINE CAP
48	PH8235148	BRACKET
49	PSB41M	CAP SCREW M4-.7 X 14
50	PH8235150	PUSHER
51	PH8235151	PUSHER SHAFT
52	PH8235152	COMPRESSION SPRING
53	PLN01M	LOCK NUT M4-.7
54	PH8235154	GROOVED CLEVIS PIN
55	PH8235155	LATCH TORSION SPRING
56	PH8235156	LATCH
57	PSB18M	CAP SCREW M4-.7 X 8
58	PH8235158	LATCH BRACKET
59	PSB16M	CAP SCREW M4-.7 X 16
60	PH8235160	RUBBER HAND GRIP
61	PORP036	O-RING 35.7 X 3.5 P36
62	PH8235162	CAP
63	PH8235163	AIR VALVE 1/4 NPT
64	PH8235164	PISTON REPAIR KIT
65	PH8235165	O-RING REPAIR KIT
66	PH7665090	CARRYING CASE
67	PAW03M	HEX WRENCH 3MM
68	PAW04M	HEX WRENCH 4MM
69	PH8235093	SAFETY GOGGLES

Stapler Breakdown and Parts List



REF PART #	DESCRIPTION
101	PSB15M CAP SCREW M5-.8 X 20
102	PH8236102 EXHAUST PORT
103	PH8236103 COMPRESSION SPRING
104	PH8236104 SPACER
105	PH8236105 CYLINDER COVER
106	PORP011-2 O-RING 11 X 2.4 P11.2
107	PORP016 O-RING 15.8 X 2.4 P16
108	PH8236108 HEAD VALVE PISTON
109	PH8236109 COLLAR
110	POR0030 O-RING 30 X 3.1
111	PH8236111 CYLINDER
112	PORP018 O-RING 17.8 X 2.4 P18
113	PH8236113 MAIN PISTON
114	PH8236114 BUMPER
115	PH8236115 SEALING WASHER
116	PH8236116 GUN BODY
117	PH8236117 RUBBER WASHER
118	PH8236118 SPACER
119	PH8236119 TRIGGER VALVE RING
120	PH8236120 TRIGGER VALVE STEM
121	PORP003 O-RING 2.8 X 1.9 P3
122	PH8236122 TRIGGER VALVE GUIDE
123	PORP011-2 O-RING 11 X 2.4 P11.2
124	PH8236124 SAFETY RING
125	PH8236125 COMPRESSION SPRING
126	PH8236126 GROOVED CLEVIS PIN

REF PART #	DESCRIPTION
127	PH8236127 TRIGGER
128	PEC16M E-CLIP 2.5MM
129	PLW01M LOCK WASHER 5MM
130	PH8236130 DRIVER GUIDE
131	PH8236131 SPACER
132	PH8236132 MAGAZINE
133	PH8236133 MAGAZINE SLIDER
134	PH8236134 MAGAZINE PUSHER
135	PH8236135 SHAFT
136	PH8236136 COMPRESSION SPRING
137	PW05M FLAT WASHER 4MM
138	PS110M PHLP HD SCR M4-.7 X 4
139	PSB18M BRACK SCREW M4-.7 X 8
140	PH8236140 RACKET
141	PN04M HEX NUT M4-.7
142	PH8236142 GROOVED CLEVIS PIN
143	PH8236143 TORSION SPRING
144	PH8236144 MAGAZINE LATCH
145	PH8236145 MAGAZINE LATCH LEVER
146	PN06M HEX NUT M5-.8
147	PH8236147 RUBBER HAND GRIP
148	PORS035-5 O-RING 35.0 X 2.0 S35.5
149	PH8236149 END CAP
150	PH8236150 AIR INLET QUICK CONNECT
151	PH8236151 PISTON REPAIR KIT
152	PH8236152 O-RING REPAIR KIT