


# H9565 Parts Breakdown



# H9565 Parts List

REF PART #	DESCRIPTION
1	PH9565001 UPPER BLADE GUIDE ASSEMBLY
1-1	PH9565001-1 UPPER BLADE GUIDE SUPPORT
1-2	PH9565001-2 BIAS SHAFT
1-3	PR05M EXT RETAINING RING 15MM
1-4	P6202 BALL BEARING 6202ZZ
1-5	PH9565001-5 HANDLE BUSHING
1-6	PSB48M CAP SCREW M6-1 X 35
1-7	PH9565001-7 UPPER SPACING SLEEVE
1-8	PSS01M SET SCREW M6-1 X 10
2	PH9565002 LOWER BLADE GUIDE ASSEMBLY
2-4	PH9565002-4 LOWER BLADE GUIDE SUPPORT
2-5	PSB01M CAP SCREW M6-1 X 16
2-6	PH9565002-6 BIAS SHAFT

REF PART #	DESCRIPTION
2-7	PR05M EXT RETAINING RING 15MM
2-8	P6202 BALL BEARING 6202ZZ
2-9	PH9565002-9 HANDLE BUSHING
2-10	PSB48M CAP SCREW M6-1 X 35
3	PH9565003 SAW BLADE ADJUSTMENT
3-1	PH9565003-1 CAP SCREW M16-1 X 16
3-2	PH9565003-2 UPPER GUIDE SUPPORT BLOCK
3-3	PH9565003-3 ADJUST BAR
4	PH9565004 HARDWARE KIT
4-1	PH9565004-1 BUTTON HEAD SCREW M10-1.75 X 25
4-2	PW04M FLAT WASHER 10MM
4-3	PH9565004-3 LEFT COVER
4-4	PH9565004-4 RIGHT COVER

