


SECTION 5: PARTS

Main Parts Breakdown



Main Parts List

REF	PART #	DESCRIPTION
1	PT27158001	NOZZLE ARBOR NUT
2	PT27158002	NOZZLE SET
2-1	PT27158002-1	NOZZLE 9/64"
2-2	PT27158002-2	NOZZLE 1/8"
2-3	PT27158002-3	NOZZLE 7/64"
2-4	PT27158002-4	NOZZLE 3/32"
3	PT27158003	GASKET
5	PT27158005	BALL VALVE 3/8"
8	PT27158008	NOZZLE ARBOR
9	PT27158009	FEMALE CONNECTOR 3/8"
10	PT27158010	WATER TRAP FILTER
11	PT27158011	PRESSURE GAUGE
14	PT27158014	AXLE
15	PT27158015	AIR HOSE
17	PT27158017	COTTER PIN 1/8" X 1"
18	PT27158018	WHEEL
19	PT27158019	HOSE CLAMP 1"

REF	PART #	DESCRIPTION
23	PT27158023	LEG
20	PT27158020	BLAST HOSE 1" THICK
21	PT27158021	SAND ELBOW
24	PT27158024	TANK 20 GALLON
25	PT27158025	SAFETY RELIEF VALVE
26	PT27158026	SPECIAL O-RING
27	PT27158027	FILLER CAP
28	PT27158028	FUNNEL
29	PT27158029	HOOD W/LENSE
30	PT27158030	HANDLEBAR
31	PT27158031	HEX NUT M6-1
32	PT27158032	PHLP HD SCR M6-1 X 30
33	PT27158033	PIPE
34	PT27158034	HANDLE GRIP
35	PT27158035	FLAT WASHER 12MM
36	PT27158036	MANIFOLD
38	PT27158038	PUSH-ON HOSE NIPPLE 3/8"

