


SECTION 9: PARTS

We do our best to stock replacement parts when possible, but we cannot guarantee that all parts shown are available for purchase. Call (800) 523-4777 or visit www.grizzly.com/parts to check for availability.

Main




Main Parts List

REF	PART #	DESCRIPTION
1	PT30945001	REAR SUPPORT
2	PT30945002	INT TOOTH WASHER 5MM
3	PT30945003	KNOB BOLT M6-1 X 18, D32, WING
4	PT30945004	SPLASH HOOD
5	PT30945005	KNOB M6-1, 6-LOBE, D32
6	PT30945006	SPLASH HOOD MOUNTING BRACKET
7	PT30945007	FLANGE SCREW M4-.7 X 6
8	PT30945008	HEX BOLT M6-1 X 30
9	PT30945009	KNOB M5-.8, 6-LOBE, D32
10	PT30945010	FLAT WASHER 5MM
11	PT30945011	HEX BOLT M5-.8 X 20
12	PT30945012	LOCK NUT M3-.5
13	PT30945013	PHLP HD SCR M3-.5 X 20
14	PT30945014	MITER GUIDE
15	PT30945015	MITER GUIDE FIXED SEAT
16	PT30945016	MITER GUIDE SLIDING SEAT
17	PT30945017	TAP SCREW M4.2 X 9
18	PT30945018	TAP SCREW M4.2 X 16
19	PT30945019	FENCE LOCK HANDLE
20	PT30945020	FENCE LOCK CAM
21	PT30945021	ECCENTRIC SHAFT
22	PT30945022	BUTTON HD CAP SCR M5-.8 X 65
23	PT30945023	FENCE LOCK CAM BRACKET
24	PT30945024	RUBBER PLATE
25	PT30945025	PHLP HD SCR M4-.7 X 6
26	PT30945026	SLIDING PLATE (LH)
27	PT30945027	SLIDING PLATE (RH)
28	PT30945028	HEX NUT M4-.7
29	PT30945029	FLAT HD SCR M4-.7 X 6
30	PT30945030	FENCE FIXED SEAT
31	PT30945031	SET SCREW M4-.7 X 6
32	PT30945032	PHLP HD SCR M3-.5 X 8
33	PT30945033	POINTER
34	PT30945034	PHLP HD SCR M4-.7 X 10
35	PT30945035	RIP FENCE
36	PT30945036	RIP FENCE COVER
37	PT30945037	BEVEL TABLE
38	PT30945038	BEVEL STOP BRACKET (LH)
39	PT30945039	BEVEL STOP BRACKET (RH)
40	PT30945040	BEVEL BRACKET SEAT
41	PT30945041	BEVEL LOCK PLATE
42	PT30945042	PHLP HD SCR M5-.8 X 12
43	PT30945043	BASE (LH)
44	PT30945044	CAP SCREW M8-1.25 X 25
45	PT30945045	HEX NUT M8-1.25
46	PT30945046	FOOT COVER (FR-LH)
47	PT30945047	FOOT COVER (RR-LH)
48	PT30945048	FOOT (LH)

REF	PART #	DESCRIPTION
49	PT30945049	FOOT (RH)
50	PT30945050	TAP SCREW M4.8 X 16
51	PT30945051	BASE TUBE
52	PT30945052	FOOT COVER (RR-RH)
53	PT30945053	FOOT COVER (FR-RH)
54	PT30945054	FOOT TUBE
55	PT30945055	BASE (RH)
56	PT30945056	HEX BOLT M6-1 X 30
57	PT30945057	WRENCH SEAT
58	PT30945058	ARBOR WRENCH 8MM
59	PT30945059	WRENCH 19MM CLOSED-END
60	PT30945060	KNOB M6-1, D46, WING
61	PT30945061	MOTOR COVER
62	PT30945062	PHLP HD SCR M4-.7 X 12
63	PT30945063	STRAIN RELIEF TYPE-1 9/16
64	PT30945064	POWER CORD 18G 3W 86" 5-15P
65	PT30945065	LOCK WASHER 4MM
66	PT30945066	PHLP HD SCR M4-.7 X 8
67	PT30945067	FLAT WASHER 4MM
68	PT30945068	ON/OFF SWITCH KEDU HY18 20A 125/250V
69	PT30945069	SWITCH FRONT PANEL
70	PT30945070	SWITCH REAR PANEL
71	PT30945071	TAP SCREW M3.5 X 13
72	PT30945072	TABLE
73	PT30945073	GASKET 320 X 20 X 8
74	PT30945074	SCREW COVER
75	PT30945075	WATER TRAY
76	PT30945076	OVERFLOW DRAIN PLUG
77	PT30945077	CAP SCREW M6-1 X 16
78	PT30945078	O-RING 54.5 X 3.55
79	PT30945079	WATER TRAY SEALING COVER
80	PT30945080	TAP SCREW M2.9 X 8
81	PT30945081	SEALING WASHER 27 X 17.5 X 2.5MM
82	PT30945082	HEX NUT M12-1.5
83	PT30945083	OUTER BLADE FLANGE 56 X 8MM
84	PT30945084	BLADE 7"
85	PT30945085	INNER BLADE FLANGE 56 X 14.6MM
86	PT30945086	CAP SCREW M6-1 X 25
87	PT30945087	PHLP HD SCR M4-.7 X 8
88	PT30945088	CAPACITOR BRACKET
89	PT30945089	R CAPACITOR 35M 250V 1-3/8 X 2-5/8
90	PT30945090	FLAT WASHER 5MM
91	PT30945091	LOCK WASHER 5MM
92	PT30945092	FLAT WASHER 6MM
104	PT30945104	MOTOR 1HP 120V 1-PH
104-1	PT30945104-1	MOTOR FAN
104-2	PT30945104-2	BALL BEARING 6201-2RS (FRONT)
104-3	PT30945104-3	BALL BEARING 6003-2RS (BACK)



Labels & Cosmetics



REF	PART #	DESCRIPTION
201	PT30945201	MODEL NUMBER LABEL
202	PT30945202	ELECTRICITY LABEL
203	PT30945203	SPLASH HOOD LABEL
204	PT30945204	TOUCH-UP PAINT, GRIZZLY BLACK
205	PT30945205	EYE/EAR/LUNG INJURY LABEL

REF	PART #	DESCRIPTION
206	PT30945206	READ MANUAL LABEL
207	PT30945207	TOUCH-UP PAINT, GRIZZLY GREEN
208	PT30945208	DISCONNECT POWER LABEL
209	PT30945209	MACHINE ID LABEL
210	PT30945210	DRIP LOOP/GFCI LABEL

WARNING

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this machine **MUST** replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or www.grizzly.com.

