




MODEL T31762

4" HORIZONTAL

SLIDE TABLE

PARTS LIST

For questions or help with this product contact Tech Support at (570) 546-9663 or techsupport@grizzly.com



REF PART # DESCRIPTION

1	PT31762001	TABLE BASE
2	PT31762002	SHOULDER SCREW M6-1 X 8, 9 X 40
3	PT31762003	HANDWHEEL HANDLE 15 X 40, 9
4	PT31762004	FIXED HANDLE 10 X 32, M6-1 X 8
5	PT31762005	LOCK NUT M8-1.25
6	PT31762006	HANDWHEEL TYPE-10 60D X 10B X M6-1
7	PT31762007	THRUST BEARING 51100
8	PT31762008	DIAL RING
9	PT31762009	CAP SCREW M6-1 X 20

REF PART # DESCRIPTION

10	PT31762010	HANDWHEEL BRACKET
11	PT31762011	KEY 4 X 4 X 10
12	PT31762012	LEADSCREW
13	PT31762013	LEADSCREW NUT
14	PT31762014	SET SCREW M6-1 X 10
15	PT31762015	FLANGE SCREW M6-1 X 25
16	PT31762016	SLIDE TABLE
17	PT31762017	ADJUSTABLE HANDLE M6-1 X 25, 50L
18	PT31762018	GIB

COPYRIGHT © APRIL, 2020 BY GRIZZLY INDUSTRIAL, INC.
WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.
 (FOR MODELS MFD. SINCE 04/20) #KS21054 PRINTED IN CHINA

V1.04.20