


# T33254 Parts Breakdown & List



REF PART #	DESCRIPTION
1	PT33254001 DRAWER SLIDE SET
2	PT33254002 HEX BOLT 3/8-16 X 1
3	PT33254003 HEX BOLT 1/4-20 X 1/2
4	PT33254004 LOCK SET WITH 2 KEYS
5	PT33254005 CASTER, 6" FIXED
6	PT33254006 CASTER, 6" SWIVEL WITH BRAKE
7	PT33254007 DRAWER LINER, SMALL
8	PT33254008 DRAWER LINER, LARGE
9	PT33254009 CABINET BODY
10	PT33254010 HANDLE
11	PT33254011 WOOD TOP
12	PT33254012 DRAWER, LOWER

REF PART #	DESCRIPTION
13	PT33254013 DRAWER, MIDDLE
14	PT33254014 DRAWER, TOP
15	PT33254015 GRIZZLY NAMEPLATE
16	PT33254016 POWER CORD 18G 3W 72" 5-15P/C14
17	PT33254017 POWER CORD BRACKET
18	PT33254018 QR CODE LABEL
19	PT33254019 WARNING LABEL
20	PT33254020 GRIZZLY.COM LABEL
21	PT33254021 POWER STRIP 18G 3W 6"
22	PT33254022 MOUNTING PLATE
23	PT33254023 POWER STRIP LABEL
24	PT33254024 PHLP HD SCR 8-32 X 1/2

## WARNING

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this machine **MUST** replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or [www.grizzly.com](http://www.grizzly.com).

**Please Note:** We do our best to stock replacement parts whenever possible, but we cannot guarantee that all parts shown here are available for purchase. Call (800) 523-4777 or visit our online parts store at [www.grizzly.com](http://www.grizzly.com) to check for availability.

