


T33312 Parts Breakdown & List



REF	PART #	DESCRIPTION
1	PT33312001	LIFT FRAME
2	PT33312002	LOCK LEVER
3	PT33312003	EXTENSION SPRING 1.5 X 10 X 80
4	PT33312004	HEX BOLT M8-1.25 X 35
5	PT33312005	BUTTON HD CAP SCR M8-1.25 X 16
6	PT33312006	SHOULDER SCREW M8-1.25 X 14, 10 X 13
7	PT33312007	SHOULDER SCREW M8-1.25 X 13, 10 X 35
8	PT33312008	HEIGHT BRACKET
9	PT33312009	UPPER CROSS BEAM 15-7/8"
10	PT33312010	LOCK NUT M8-1.25
11	PT33312011	KNOB BOLT M8-1.25 X 20, 5-LOBE, D37

REF	PART #	DESCRIPTION
12	PT33312012	STAND
13	PT33312013	HEX BOLT M8-1.25 X 45
14	PT33312014	LOCK NUT M12-1.75
15	PT33312015	FLAT WASHER 12MM
16	PT33312016	HEX BOLT M8-1.25 X 65
17	PT33312017	CASTER 3", LOCKING SWIVEL
18	PT33312018	LOWER CROSS BEAM 14-15/16"
19	PT33312019	MACHINE ID LABEL
20	PT33312020	GRIZZLY.COM LABEL
21	PT33312021	MODEL NUMBER LABEL
22	PT33312022	TOUCH-UP PAINT, GRIZZLY GREEN

Please Note: We do our best to stock replacement parts whenever possible, but we cannot guarantee that all parts shown here are available for purchase. Call (800) 523-4777 or visit our online parts store at www.grizzly.com to check for availability.

