


T34010 Parts Breakdown & List



REF PART # DESCRIPTION

1	PT34010001	ADJUSTABLE LEG
2	PT34010002	LEG
3	PT34010003	LEG W/HOOK
4	PT34010004	CROSS BEAM
5	PT34010005	TABLE 20" X 48" X 1.25"
6	PT34010006	TAP SCREW M5 X 15

REF PART # DESCRIPTION

7	PT34010007	BUTTON HD CAP SCR M8-1.25 X 20
8	PT34010008	BUTTON HD CAP SCR M8-1.25 X 48
9	PT34010009	LOCK NUT M8-1.25
11	PT34010011	ADJUSTABLE FOOT M12-1.75 X 50
12	PT34010012	POWER STRIP TA1424121F12 125V 5-15P

We do our best to stock replacement parts when possible, but we cannot guarantee that all parts shown are available for purchase. Call (800) 523-4777 or visit www.grizzly.com/parts to check for availability.



Labels & Cosmetics



REF	PART #	DESCRIPTION
20	PT34010020	MACHINE ID LABEL
21	PT34010021	FIRE HAZARD LABEL
22	PT34010022	POWER LABEL

REF	PART #	DESCRIPTION
23	PT34010023	GRIZZLY OBLONG NAMEPLATE-MINI
24	PT34010024	TOUCH-UP PAINT, GLOSSY BLACK

WARNING

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this machine **MUST** replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or www.grizzly.com.

