
## T34358 Parts Breakdown & List



KEF	PARI#	DESCRIPTION
1	PT34358001	RAIL TUBE
2	PT34358002	LONG RAIL, FRONT

2	PT34358002	LONG RAIL, FRONT
3	PT34358003	LONG RAIL, REAR
4	PT34358004	SCALE 60"
5	PT34358005	EXTENSION LEG
6	PT34358006	ADJUSTABLE FOOT 1/2-12 x 5-1/2
7	PT34358007	BRACE
8	PT34358008	HEX BOLT 1/4-20 X 5/8
9	PT34358009	LOCK WASHER 1/4
10	PT3/358010	ELAT WASHER 1/A

## REF PART # DESCRIPTION

11	PT34358011	HEX NUT 1/2-12
12	PT34358012	FLAT WASHER 3/8
13	PT34358013	HEX BOLT 3/8-16 X 3/4
14	PT34358014	EXTENSION TABLE
15	PT34358015	WOOD SCREW #8 X 3/4
16	PT34358016	HEX NUT 3/8-16
17	PT34358017	FLAT WASHER 3/8
18	PT34358018	HEX BOLT 3/8-16 X 1-3/4
19	PT34358019	FENDER WASHER 1/4
20	PT34358020	TAP SCREW 1/4 X 3/4

Please Note: We do our best to stock replacement parts whenever possible, but we cannot guarantee that all parts shown here are available for purchase. Call (800) 523-4777 or visit our online parts store at www.grizzly.com to check for availability.

