


T34392 Parts Breakdown & List



REF PART #	DESCRIPTION
1	PT34392001 LONG BRACE, TOP
2	PT34392002 TABLE BOARD
3	PT34392003 SHORT BRACE, TOP
4	PT34392004 LONG BRACE, BOTTOM
5	PT34392005 SHELF BOARD
6	PT34392006 SHORT BRACE, BOTTOM
7	PT34392007 STAND LEG

REF PART #	DESCRIPTION
8	PT34392008 FOOT PAD
9	PT34392009 BUTTON HD CAP SCR M6-1 X 15
10	PT34392010 LOCK NUT M6-1
11	PT34392011 TAP SCREW M5 X 15
12	PT34392012 MACHINE ID LABEL
13	PT34392013 GRIZZLY.COM LABEL
14	PT34392014 TOUCH-UP PAINT, GLOSSY BLACK

WARNING

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this machine **MUST** replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or www.grizzly.com.

Please Note: We do our best to stock replacement parts whenever possible, but we cannot guarantee that all parts shown here are available for purchase. Call (800) 523-4777 or visit our online parts store at www.grizzly.com to check for availability.

