


SECTION 9: PARTS

We do our best to stock replacement parts when possible, but we cannot guarantee that all parts shown are available for purchase. Call **(800) 523-4777** or visit **www.grizzly.com/parts** to check for availability.

Main



Main Parts List

REF	PART #	DESCRIPTION
1	PT34441001	MOTOR HOUSING
2	PT34441002	BRUSH PORT
3	PT34441003	CARBON BRUSH (2-PC)
4	PT34441004	BRUSH CAP
5	PT34441005	STATOR
6	PT34441006	TAP SCREW M5 X 45
7	PT34441007	BALL BEARING 608ZZ
8	PT34441008	ROTOR
9	PT34441009	BALL BEARING 629-2RS
10	PT34441010	DEFLECTOR
11	PT34441011	GUIDE PLATE
12	PT34441012	BALL BEARING 686ZZ
13	PT34441013	COVER INNER
14	PT34441014	FLAT HD CAP SCR M6-1 X 18
15	PT34441015	SQUARE NUT M6-1
16	PT34441016	GEAR 43T
17	PT34441017	BALL BEARING 6202ZZ
18	PT34441018	GEAR SHAFT 11T
19	PT34441019	KEY 3 X 3 X 6 RE
20	PT34441020	CORD GRIP
21	PT34441021	TRIGGER SWITCH LM-07
22	PT34441022	OPERATION HANDLE RIGHT
23	PT34441023	TAP SCREW M4 X 14
24	PT34441024	WIRE CLAMP
25	PT34441025	OPERATION HANDLE LEFT
26	PT34441026	TAP SCREW M4 X 22
27	PT34441027	BLADE TENSION LEVER
28	PT34441028	SPACER 20 X 26 X 20MM
29	PT34441029	WHEEL HOUSING UPPER
30	PT34441030	ADJUSTABLE HANDLE
31	PT34441031	CAP SCREW M8-1.25 X 25
32	PT34441032	TAP SCREW M4 X 60
33	PT34441033	DOWEL PIN 6 X 16
34	PT34441034	BALL BEARING 696ZZ
35	PT34441035	DOWEL PIN 6 X 18
36	PT34441036	FLAT WASHER 4MM
37	PT34441037	PHLP HD SCR M4-.7 X 10
38	PT34441038	BLADE SLEEVE
39	PT34441039	BLADE WHEEL WEDGE
40	PT34441040	PHLP HD SCR M4-.7 X 16
41	PT34441041	PHLP HD SCR M5-.8 X 20
42	PT34441042	TENSION PLATE INNER
43	PT34441043	COMPRESSION SPRING 6 X 17 X 60
44	PT34441044	TENSION PLATE OUTER
45	PT34441045	FLANGED BUSHING
46	PT34441046	FLAT WASHER 6MM
47	PT34441047	IDLER WHEEL SHAFT
48	PT34441048	IDLER WHEEL
49	PT34441049	FLAT WASHER 30 X 34 X 1MM
50	PT34441050	LOCK WASHER 6MM
51	PT34441051	PHLP HD SCR M6-1 X 14
52	PT34441052	TIRE RUBBER

REF	PART #	DESCRIPTION
53	PT34441053	BLADE COVER UPPER
54	PT34441054	PHLP HD SCR M5-.8 X 10
55	PT34441055	CAP SCREW M5-.8 X 22
56	PT34441056	WHEEL HOUSING LOWER
57	PT34441057	BALL BEARING 627ZZ
58	PT34441058	GEAR 27T
59	PT34441059	BALL BEARING 6204ZZ
60	PT34441060	GEAR SHAFT 8T
61	PT34441061	PHLP HD SCR M5-.8 X 20
62	PT34441062	GEAR 43T
63	PT34441063	CAP SCREW M6-1 X 20
64	PT34441064	DRIVE SHAFT
65	PT34441065	BALL BEARING 6002-2RS
66	PT34441066	BLADE GUIDE FRAME UPPER
67	PT34441067	ECCENTRIC BOLT M5-.8 X 24
68	PT34441068	TAP SCREW M4 X 40
69	PT34441069	TAP SCREW M4 X 35
70	PT34441070	BLADE GUIDE FRAME LOWER
71	PT34441071	BLADE 44-7/8 X 1/2 X 0.025 14-18 TPI VP
72	PT34441072	BLADE COVER LOWER
73	PT34441073	THRUST BEARING 51201
74	PT34441074	COMPRESSION SPRING 0.75 X 12.5 X 24
75	PT34441075	PIVOT ARM
76	PT34441076	HEAD LOCKING PIN 4 X 28
77	PT34441077	PEDESTAL
78	PT34441078	WISE ANGLE BLOCK
79	PT34441079	WISE JAW FIXED
80	PT34441080	CAP SCREW M8-1.25 X 35
81	PT34441081	WISE JAW FLOATING
82	PT34441082	WISE PIVOT SHAFT
83	PT34441083	PRESS PLATE SMALL
84	PT34441084	STAND
85	PT34441085	FLANGED BUSHING
86	PT34441086	WISE SCREW MOUNT
87	PT34441087	WISE SCREW
88	PT34441088	CAP SCREW M8-1.25 X 16
89	PT34441089	BLADE SPEED DIAL ASSEMBLY
90	PT34441090	DRIVE WHEEL
91	PT34441091	SPACER 15 X 22 X 3MM
92	PT34441092	ON/OFF SWITCH LM-05
93	PT34441093	LOCK WASHER 8MM
94	PT34441094	FLAT WASHER 8MM
95	PT34441095	PHLP HD SCR M8-1.25 X 16
96	PT34441096	PIVOT BOLT M12-1.75 X 55
97	PT34441097	FLANGE NUT M12-1.75
98	PT34441098	PHLP HD SCR M5-.8 X 16
99	PT34441099	TAP SCREW M4 X 20
101	PT34441101	ROLL PIN 4 X 28
102	PT34441102	EXT RETAINING RING 14MM
103	PT34441103	PRESS PLATE LARGE
104	PT34441104	CAP SCREW M6-1 X 25
105	PT34441105	LOCK WASHER 10MM




Main Parts List (Cont.)

REF	PART #	DESCRIPTION
106	PT34441106	LOCK WASHER 14MM
107	PT34441107	POWER CORD 18G 3W 87" 5-15P
108	PT34441108	BUMPER M8-1.25 X 30 RUBBER
109	PT34441109	FLAT WASHER 8 X 19 X 2MM
110	PT34441110	HEX NUT M8-1.25
111	PT34441111	WISE SUPPORT PLATE
112	PT34441112	WORK STOP ROD
113	PT34441113	WORK STOP
114	PT34441114	HEX NUT M12-1.75


REF	PART #	DESCRIPTION
115	PT34441115	THUMB SCREW M6-1 X 25 WING
116	PT34441116	HEX WRENCH 6MM
117	PT34441117	CARRYING CASE
118	PT34441118	HEX NUT M6-1
119	PT34441119	FLAT WASHER 5MM
120	PT34441120	FLAT WASHER 6MM
121	PT34441121	LOCK WASHER 5MM
122	PT34441122	FLAT WASHER 8MM
123	PT34441123	LOCK WASHER 8MM



Labels & Cosmetics



Labels & Cosmetics (Cont.)



REF	PART #	DESCRIPTION
201	PT34441201	AMPUTATION HAZARD LABEL
202	PT34441202	ELECTRICITY LABEL
203	PT34441203	GRIZZLY LOGO SMALL
204	PT34441204	COMBO WARNING LABEL
205	PT34441205	GRIZZLY LOGO LARGE
206	PT34441206	BLADE DIRECTION LABEL

REF	PART #	DESCRIPTION
207	PT34441207	QR CODE LABEL
208	PT34441208	BLADE TENSION LABEL
209	PT34441209	DO NOT REMOVE LABEL
210	PT34441210	MACHINE ID LABEL
211	PT34441211	SPEC/WARNING LABEL
212	PT34441212	TOUCH-UP PAINT, GLOSSY BLACK

WARNING

Safety labels help reduce the risk of serious injury caused by machine hazards. If any label comes off or becomes unreadable, the owner of this machine **MUST** replace it in the original location before resuming operations. For replacements, contact (800) 523-4777 or www.grizzly.com.

