


T34606 Parts Breakdown & List



REF	PART #	DESCRIPTION
1	PT34606001	TABLE
2	PT34606002	LEG
3	PT34606003	SHELF
4	PT34606004	SHELF SUPPORT BRACKET
5	PT34606005	BASE
6	PT34606006	FOOT M8-1.25 X 68
7	PT34606007	FOOT PEDAL
8	PT34606008	PIVOT SHAFT 10 X 75MM
9	PT34606009	SPACER 6 X 10 X 23MM
10	PT34606010	E-CLIP 8MM
11	PT34606011	CASTER 72.5MM, SWIVEL
12	PT34606012	CAM SHAFT 12.7 X 100MM
13	PT34606013	FLAT WASHER 12MM
14	PT34606014	EXT RETAINING RING 12MM
15	PT34606015	HEX NUT M5-.8
16	PT34606016	HEX BOLT M5-.8 X 8
17	PT34606017	LOCK NUT M8-1.25
18	PT34606018	CASTER SUPPORT
19	PT34606019	HEX BOLT M8-1.25 X 100
20	PT34606020	HEX BOLT M8-1.25 X 60
21	PT34606021	FLAT WASHER 8MM

REF	PART #	DESCRIPTION
22	PT34606022	HEX NUT M8-1.25
23	PT34606023	WHEEL 8 X 30 X 72.5MM
25	PT34606025	CARRIAGE BOLT M8-1.25 X 16
26	PT34606026	EXTENSION GUIDE BRACKET
27	PT34606027	TAP SCREW #6 X 3/8
28	PT34606028	TENSION BRACKET
29	PT34606029	BUTTON HD CAP SCR M5-.8 X 10
30	PT34606030	KNOB BOLT M8-1.25 X 14
31	PT34606031	END CAP
32	PT34606032	TAP SCREW #8 X 1/2
33	PT34606033	EXTENSION ARM
34	PT34606034	ROLLER SUPPORT SLEEVE
35	PT34606035	ROLLER SUPPORT
36	PT34606036	ROLLER 32 X 300MM, STEEL
37	PT34606037	ROLLER CAP
38	PT34606038	AXLE PIN
39	PT34606039	TOUCH-UP PAINT, GLOSSY BLACK
40	PT34606040	TOUCH-UP PAINT, GRIZZLY GREEN
41	PT34606041	MACHINE ID LABEL
42	PT34606042	MODEL NUMBER LABEL

Please Note: We do our best to stock replacement parts whenever possible, but we cannot guarantee that all parts shown here are available for purchase. Call (800) 523-4777 or visit our online parts store at www.grizzly.com to check for availability.

