


T34657 Parts



REF PART # DESCRIPTION

1	PT34657001	HANDLE 16"
2	PT34657002	POWER CORD BRACKET
3	PT34657003	CASTER, 6" LOCKING SWIVEL
4	PT34657004	CASTER, 6" FIXED
8	PT34657008	LED WORKLIGHT 120V 7W 22"
9	PT34657009	MOUNTING CLIP
10	PT34657010	ANTI-TIPPING BRACKET
11	PT34657011	HEX BOLT M6-1 X 20
12	PT34657012	FLAT WASHER 8MM
13	PT34657013	LOCK WASHER 8MM
14	PT34657014	HEX BOLT M8-1.25 X 25
15	PT34657015	PHLP HD SCR M6-1 X 15
16	PT34657016	TAP SCREW M4.8 X 57
17	PT34657017	EXPANSION ANCHOR 5/16" X 2"

REF PART # DESCRIPTION

18	PT34657018	TAP SCREW M4 X 20
19	PT34657019	PHLP HD SCR M4-.7 X 12
20	PT34657020	FLAT WASHER 5MM
21	PT34657021	FLANGE NUT M4-.7
22	PT34657022	RESTRAINING STRAP W/BRACKETS
23	PT34657023	POWER STRIP TA1424121F12 125V 5-15P
24	PT34657024	LOCK SET W/2 KEYS
25	PT34657025	DRAWER MAT, SMALL 14-3/4" X 17-1/4"
26	PT34657026	DRAWER MAT, LARGE 32-1/4" x 17-1/4"
27	PT34657027	FLAT HD SCR M4-.7 X 10
28	PT34657028	WRENCH 10 X 14MM OPEN ENDS
50	PT34657050	GRIZZLY PRO LABEL 75 X 40MM
51	PT34657051	MACHINE ID LABEL
52	PT34657052	COMBO WARNING LABEL

Please Note: We do our best to stock replacement parts whenever possible, but we cannot guarantee that all parts shown here are available for purchase. Call (800) 523-4777 or visit our online parts store at www.grizzly.com to check for availability.

