


PARTS

Trunnions & Blade




REF PART # DESCRIPTION

10	X18750010	TAP SCREW M4 X 12
11	X18750011	FENDER WASHER 5MM
12	X18750012	LOWER BLADE GUARD
13	X18750013	ARBOR NUT 5/8"
14	X18750014	OUTER ARBOR FLANGE
15	X18750015	SAW BLADE 10" X 36T
16	X18750016	INNER ARBOR FLANGE
17	X18750017	TRUNNION MOUNTING SCREW
18	X18750018	REAR TRUNNION
19	X18750019	TRUNNION SLIDE
20	X18750020	FRONT TRUNNION
21	X18750021	TRUNNION MOUNTING SCREW
22	X18750022	PHLP HD SCR M5-.8 X 12
23	X18750023	TILT INDICATOR BRACKET
24	X18750024	BLADE TILT INDICATOR
25	X18750025	PHLP HD SCR M4-.7 X 12
26	X18750026	CAP SCREW M6-1 X 16
27	X18750027	BLADE TILT LOCK PLATE
28	X18750028	SPACER
29	X18750029	BLADE TILT STOP
30	X18750030	CAP SCREW M5-.8 X 20
31	X18750031	TRUNNION GEAR PLATE
32	X18750032	FLAT WASHER 5MM
33	X18750033	CAP SCREW M5-.8 X 16
34	X18750034	CAM WASHER
35	X18750035	CAMLOCK STUD M10-1.5

REF PART # DESCRIPTION

36	X18750036	CAP SCREW M4-.7 X 25
37	X18750037	BLADE TILT LOCK HANDLE
38	X18750038	HEX NUT M10-1.5
39	X18750039	SET SCREW M5-.8 X 10
40	X18750040	FLAT WASHER 12MM
41	X18750041	COMPRESSION SPRING
42	X18750042	MICRO ADJUST WHEEL
43	X18750043	BLADE TILT ADJUSTMENT HANDWHEEL
44	X18750044	HEIGHT WHEEL CLAMP SLEEVE
45	X18750045	LOCK NUT M6-1
46	X18750046	BLADE HEIGHT ADJUSTMENT HANDWHEEL
47	X18750047	BLADE HEIGHT LOCK
48	X18750048	BLADE HEIGHT HANDLE GRIP
49	X18750049	SHOULDER SCREW M6-1 X 10, 8 X 43
50	X18750050	BLADE HEIGHT HANDLE CAP
51	X18750051	TAP SCREW M4 X 16
52	X18750052	ON/OFF SWITCH JIABEN FD2-12G-2116A 125V
53	X18750053	SWITCH BRACKET
54	X18750054	SWITCH BOX
55	X18750055	STRAIN RELIEF TYPE-3 1/16 - 1/8
56	X18750056	STRAIN RELIEF TYPE-3 1/16 - 1/8
57	X18750057	FLANGE BOLT M6-1 X 16
58	X18750058	BUTTON HD CAP SCR M6-1 X 55
59	X18750059	LOCK NUT M6-1
60	X18750060	FENDER WASHER 8MM


Fence



REF	PART #	DESCRIPTION
100	X18750100	FENCE ASSEMBLY
101	X18750101	PHLP HD SCR M4-.7 X 10
102	X18750102	FLAT WASHER 4MM
103	X18750103	INDICATOR
104	X18750104	FENCE BASE
105	X18750105	FRONT SLIDER
106	X18750106	MICRO ADJUST SUPPORT
107	X18750107	PHLP HD SCR M5-.8 X 10
108	X18750108	PHLP HD SCR M5-.8 X 25
109	X18750109	MICRO ADJUST WHEEL
110	X18750110	FENCE LOCK LEVER
111	X18750111	LOCK BUSHING
112	X18750112	LOCK ROD
113	X18750113	FLANGE BOLT M6-1 X 16

REF	PART #	DESCRIPTION
114	X18750114	FENCE
115	X18750115	FENDER WASHER 6MM
116	X18750116	COMPRESSION SPRING
117	X18750117	REAR SLIDER
118	X18750118	CLAMPING PLATE
119	X18750119	TAP SCREW M5 X 10
120	X18750120	LOCK NUT M6-1
121	X18750121	END CAP
122	X18750122	FENCE FACE FRONT COVER
123	X18750123	FENCE FACE
124	X18750124	FENCE FACE REAR COVER
125	X18750125	SQUARE NECK SCREW M6-1 X 50
126	X18750126	FENDER WASHER 6MM
127	X18750127	WING NUT M6-1


Miter Gauge



REF	PART #	DESCRIPTION
200	X18750200	MITER GAUGE ASSEMBLY
201	X18750201	HANDLE CAP
202	X18750202	FIXED HANDLE 18 X 33, M6-1 X 10
203	X18750203	FENDER WASHER 6MM
204	X18750204	MITER GAUGE BODY
205	X18750205	TAP SCREW M5 X 8
206	X18750206	COMPRESSION SPRING
207	X18750207	BALL

REF	PART #	DESCRIPTION
208	X18750208	MITER GAUGE INDICATOR
209	X18750209	MITER HINGE PIN
210	X18750210	FLAT WASHER 4MM
211	X18750211	TAP SCREW M4 X 16
212	X18750212	MITER BAR
213	X18750213	MITER BAR GUIDE WASHER
214	X18750214	FLAT HD SCR M6-1 X 10


Anti-Kickback Pawls & Blade Guard



REF	PART #	DESCRIPTION
300	X18750300	ANTI-KICKBACK PAWLS ASSEMBLY
301	X18750301	PHLP HD SCR M4-.7 X 10
302	X18750302	PIN
303	X18750303	BUSHING
304	X18750304	ANTI-KICKBACK PAWL
305	X18750305	TORSION SPRING
306	X18750306	RELEASE LEVER
307	X18750307	ANTI-KICKBACK PAWL BODY
308	X18750308	ANTI-KICKBACK PAWL SUPPORT
309	X18750309	TAP SCREW M4 X 10
400	X18750400	BLADE GUARD ASSEMBLY
401	X18750401	PHLP HD SCR M5-.8 X 50

REF	PART #	DESCRIPTION
402	X18750402	FENDER WASHER 5MM
403	X18750403	COTTER PIN RETAINING
404	X18750404	LOCK NUT M5-.8
405	X18750405	RIGHT BLADE GUARD
406	X18750406	PIN
407	X18750407	TORSION SPRING
408	X18750408	HEADED PIN 5 X 30MM
409	X18750409	BLADE GUARD SUPPORT
410	X18750410	LOCK HANDLE
411	X18750411	LEFT BLADE GUARD
412	X18750412	BALL BEARING
413	X18750413	PIN 5 X 16MM


Table



REF	PART #	DESCRIPTION
600	X18750600	TABLE ASSEMBLY
601	X18750601	FLAT HD SCR M4-.7 X 12
602	X18750602	HANDLE
603	X18750603	HEX NUT M4-.7
604	X18750604	BLADE GUARD STORAGE BRACKET
605	X18750605	PHLP HD SCR M6-1 X 16
606	X18750606	FENCE RAIL NUT
607	X18750607	FENDER WASHER 5MM
608	X18750608	CAP SCREW M5-.8 X 16
609	X18750609	EXTENSION TABLE
610	X18750610	FRONT RAIL END CAP (RH)
611	X18750611	FRONT RAIL
612	X18750612	CAP SCREW M5-.8 X 10
613	X18750613	FRONT RAIL END CAP (LH)
614	X18750614	REAR RAIL
615	X18750615	REAR RAIL END CAP
616	X18750616	LOCK PAD
617	X18750617	LOCK BLOCK
618	X18750618	COMPRESSION SPRING
619	X18750619	FRONT LOCK BAR
620	X18750620	LOCK LEVER
621	X18750621	REAR LOCK BAR
622	X18750622	CARRIAGE BOLT M6-1 X 40

REF	PART #	DESCRIPTION
623	X18750623	EXTENSION ROD HOLDER
624	X18750624	FLAT WASHER 6MM
625	X18750625	LOCK NUT M6-1
626	X18750626	FLAT HD SCR M6-1 X 12
627	X18750627	FENCE ROLLER SHOULDER SCREW
628	X18750628	FENCE ROLLER
629	X18750629	CAP SCREW M5-.8 X 14
630	X18750630	CAP SCREW M5-.8 X 30
631	X18750631	NUT M6-1
632	X18750632	INDICATOR
633	X18750633	PHLP HD SCR M4-.7 X 12
634	X18750634	RAIL GUIDE
635	X18750635	TABLE
636	X18750636	ALIGNMENT DISC
650	X18750650	TABLE INSERT ASSEMBLY
650-1	X18750650-1	RIGHT WEAR PLATE
650-2	X18750650-2	LEFT WEAR PLATE
650-3	X18750650-3	SET SCREW M5-.8 X 6
650-4	X18750650-4	TABLE INSERT
650-5	X18750650-5	PHLP HD SCR M4-.7 X 10
650-6	X18750650-6	SPRING PLATE
650-7	X18750650-7	LOCK NUT M4-.7
651	X18750651	DADO TABLE INSERT

Motor & Gear Box




Motor & Gear Box Parts List

REF	PART #	DESCRIPTION
701	X18750701	PHLP HD SCR M4-.7 X 12
702	X18750702	DUST COLLECTION COVER
703	X18750703	TAP SCREW M4 X 12
704	X18750704	LOWER BLADE GUARD
705	X18750705	MOTOR BRACKET
706	X18750706	ARBOR
707	X18750707	KEY
708	X18750708	PHLP HD SCR M4-.7 X 16
709	X18750709	GEAR BOX COVER
710	X18750710	BALL BEARING 6003-2RS
711	X18750711	PHLP HD SCR M4-.7 X 10
712	X18750712	BUSHING
713	X18750713	GEAR
714	X18750714	EXT RETAINING RING 5MM
715	X18750715	BALL BEARING 608-2RS
716	X18750716	GEAR BOX
717	X18750717	BALL BEARING 6201-2RS
718	X18750718	FRONT MOTOR SHIELD
719	X18750719	MOTOR STATOR
720	X18750720	TAP SCREW M5 X 60
721	X18750721	MOTOR ARMATURE
722	X18750722	BALL BEARING 6000-2RS
723	X18750723	BEARING SLEEVE
724	X18750724	MOTOR HOUSING
725	X18750725	CARBON BRUSH END CAP
726	X18750726	CARBON BRUSH
727	X18750727	CARBON BRUSH HOLDER
728	X18750728	PHLP HD SCR M5-.8 X 45
729	X18750729	SET SCREW M6-1 X 10
730	X18750730	REAR MOTOR SHIELD
731	X18750731	STRAIN RELIEF TYPE-1 1/16 - 1/8
732	X18750732	MOTOR CORD 14G 2W 15"
733	X18750733	UPPER SHAFT COLLAR
734	X18750734	LOWER SHAFT COLLAR
735	X18750735	ELEVATION SHAFT

REF	PART #	DESCRIPTION
736	X18750736	BEVEL GEAR
737	X18750737	TAP SCREW M4 X 22
738	X18750738	BUSHING
739	X18750739	CAP SCREW M5-.8 X 20
740	X18750740	ELEVATION SHAFT PLATE
741	X18750741	GUARD PLATE
742	X18750742	ROD
743	X18750743	BEVEL GEAR
744	X18750744	DRIVE ROD BUSHING
745	X18750745	DRIVE ROD BRACKET
746	X18750746	DRIVE ROD
747	X18750747	BUTTON HD CAP SCR M6-1 X 20
748	X18750748	ROD COLLAR
749	X18750749	ECCENTRIC SLEEVE
750	X18750750	ROD
751	X18750751	GEAR BOX GUARD PLATE
752	X18750752	RIVING KNIFE ASSEMBLY
752-1	X18750752-1	FLANGE BOLT M6-1 X 30
752-2	X18750752-2	LOCK LEVER
752-3	X18750752-3	TORSION SPRING
752-4	X18750752-4	RIVING KNIFE CLAMP PLATE
752-5	X18750752-5	RIVING KNIFE/SPREADER
752-6	X18750752-6	RIVING KNIFE CLAMP BRACKET
752-7	X18750752-7	FENDER WASHER 6MM
752-8	X18750752-8	LOCK NUT M6-1
753	X18750753	CAP SCREW M6-1 X 20
754	X18750754	FLAT WASHER 8MM
755	X18750755	FLAT WASHER 8MM
756	X18750756	LOCK NUT M8-1.25
757	X18750757	WAVY WASHER 18MM
758	X18750758	SLEEVE
759	X18750759	FENDER WASHER 5MM
760	X18750760	PHLP HD SCR M5-.8 X 25
761	X18750761	MOTOR 2HP 120V 1-PH

Base




REF PART # DESCRIPTION

800	X18750800	TABLE SAW BASE ASSEMBLY
801	X18750801	ROUND KNOB M8-1.25
802	X18750802	ARBOR WRENCH
803	X18750803	KNOB CLAMP M8-1.25
804	X18750804	CARRIAGE BOLT M6-1 X 28
805	X18750805	CIRCUIT BREAKER 15A TS L2 SERIES
806	X18750806	CIRCUIT BREAKER WIRE
807	X18750807	WIRE CLIP

REF PART # DESCRIPTION

808	X18750808	TAP SCREW 4 X 16
809	X18750809	ANTI-KICKBACK PAWLS STORAGE BRACKET
810	X18750810	CORD STORAGE BRACKET
811	X18750811	CORD CLAMP
812	X18750812	CORD SLEEVE
813	X18750813	BASE
814	X18750814	POWER CORD 14G 2W 80" 5-15P
815	X18750815	PUSH STICK


Mobile Stand



REF	PART #	DESCRIPTION
900	X18750900	MOBILE STAND ASSEMBLY
901	X18750901	TAP SCREW M5 X 10
902	X18750902	FOOT PAD
903	X18750903	RIVET 5MM BLIND
904	X18750904	UPPER STAND
905	X18750905	CARRIAGE BOLT M6-1 X 40
906	X18750906	STAND SPACER
907	X18750907	LOCK NUT M8-1.25
908	X18750908	MIDDLE STAND
909	X18750909	END CAP
910	X18750910	REAR STAND
911	X18750911	WING NUT M10-1.5
912	X18750912	FOOT SHAFT
913	X18750913	FOOT
914	X18750914	FOOT COVER
915	X18750915	PHLP HD SCR M4-.7 X 12

REF	PART #	DESCRIPTION
916	X18750916	SHOULDER SCREW M6-1 X 15, 8 X 43
917	X18750917	STAND LOCK PLATE
918	X18750918	STAND SPACER
919	X18750919	LOCK PLATE BRACKET
920	X18750920	COMPRESSION SPRING
921	X18750921	FLAT WASHER 6MM
922	X18750922	LOCK NUT M6-1
923	X18750923	END CAP
924	X18750924	FENDER WASHER 8MM
925	X18750925	STAND WHEEL
926	X18750926	FRONT STAND
927	X18750927	RIGHT HANDLE
928	X18750928	GRIP
929	X18750929	HANDLE END CAP
930	X18750930	LEFT HANDLE

Labels & Cosmetics



REF	PART #	DESCRIPTION
1001	X18751001	FENCE SCALE LABEL
1002	X18751002	MITER GAUGE SCALE LABEL
1003	X18751003	AMPUTATION HAZARD LABEL
1004	X18751004	BLADE GUARD WARNING 1 LABEL
1005	X18751005	BLADE GUARD WARNING 2 LABEL
1006	X18751006	BLADE ANGLE LABEL
1007	X18751007	DISCONNECT 110V BLADE GUARD LABEL
1008	X18751008	TABLE SAW WARNING LABEL

REF	PART #	DESCRIPTION
1009	X18751009	READ MANUAL LABEL
1010	X18751010	DISCONNECT 110V LABEL
1011	X18751011	MACHINE ID LABEL
1012	X18751012	EYE EAR LUNG HAZARD LABEL
1013	X18751013	RIVING KNIFE LABEL
1014	X18751014	MODEL NUMBER LABEL
1015	X18751015	ELECTRICITY LABEL
1016	X18751016	TOUCH-UP PAINT, SHOP FOX BLACK

⚠ WARNING

Safety labels warn about machine hazards and how to prevent serious personal injury. The owner of this machine **MUST** maintain the original location and readability of all labels on this machine. If any label is removed or becomes unreadable, **REPLACE** that label before allowing machine to be operated again. Contact us at (360) 734-3482 or www.woodstockint.com to order new labels.